

General Purpose Robot Arm for Industry Use

ZERO

VERTICAL ARTICULATED ROBOT USER MANUAL

Support Version of R1.3.0 or higher

Document Number: M-0101-231214

December 2023

Thank you for your purchase of the industrial robot “ZERO”



- When using this product, knowledge and skills in “Occupational Safety and Health Training”, “Electrical Engineer Certificate” and “Python” programming language are required.
- Please read the user manual and other instructions carefully before using and use it correctly.
- To improve product performance, specifications may change without prior notice.
- Instructions such as the User manual,
 - Must be safely stored by product users.
 - May be modified without notice due to changes in product specifications.
 - Unauthorized copying of part or all of the content is prohibited.

This user manual supports the following models:

Robot	Controller (version)	JOG stick	Teaching Pendant
ZERO ZRA Series	ZC1*** (Over R1.3.0)	ZJ1000	ZP1000

Trademarks and patents:

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany. Other names used in this publication may be trademarks utilized by third parties for their own purposes and may infringe the rights of the owners.



EtherCAT is an open real-time telecommunications network developed by Beckhoff Automation GmbH, Germany, and its rights are protected by Beckhoff.

This product includes the following instructions.

Installation Guide

This is a simple guide, from unpacking to installation.

Before Unpacking

Safety Precautions
Mounting the Manipulator and Controller Installation
JOG Stick
Connecting Teaching Pendant and PC
Wiring and Power Supply
JOG Operation and ABS Homing
Troubleshooting Guide

Safety Precautions

The following safety contents must be complied with.

Compliance Terms
Safety Instructions
Risk Assessment
Industrial Health and Safety Education
Maintenance/Inspection
Safety Measures
Warranty and Disclaimer

User Manual (this document)

This is a guide for the product and programs.

A Overview
B Hardware
C Instructions
D Software
Z Documentation

A OVERVIEW

- | | |
|------------------------|--|
| 1. System Introduction | Product information, international specifications |
| 2. System Installation | Start-up procedure, unpacking, attachments/accessories, transportation |

B HARDWARE

- | | |
|----------------------------|--|
| 1. System configuration | Model name, system configuration |
| 2. Manipulator | Overview, part names, installation, dimension drawings, specifications, connectors, movement range, end-effector design |
| 3. Controller | Model name and label, part names, installation, external drawings, specifications, connectors, and controller status display |
| 4. JOG stick | Product label, part names, installation, external drawings, specifications, functions |
| 5. Teaching pendant | Product label, part names, installation, external drawings, specifications, functions |
| 6. Wiring and power supply | Wiring system, power supply |

C TEACHING

- | | |
|----------------------------------|--|
| 1. JOG operation | JOG operating mode |
| 2. PC connection | Connecting Teaching Pendant and PC |
| 3. Restoring ABS | Notes, order, confirmation |
| 4. Teaching | Basic operations, instruction sequence, instruction data transmission |
| 5. Coordinate system and posture | Coordinate system, general coordinate system, world coordinate system, base coordinate system, tool coordinate system, user coordinate system, posture |

D SOFTWARE

- | | |
|---------------------------------|--|
| 1. Programming Instructions | PC and operating environment, programming instructions |
| 2. Robot Library | Data types, modules, method summary, robot library |
| 3. Memory Map | Overview, Shared memory, Memory I/O |
| 4. Program implementation steps | Overview, how to proceed |

Z DOCUMENTATION

- | | |
|--------------------|--|
| 1. Block diagram | System's block diagram, hardware's block diagram |
| 2. Maintenance | Inspection, maintenance |
| 3. Glossary | Glossary |
| 4. Troubleshooting | Error log, troubleshooting |

NOTE



A

OVERVIEW


- 
1. SYSTEM OVERVIEW
 2. SYSTEM INSTALLATION

NOTE

A decorative graphic consisting of five light blue squares arranged in a staircase pattern, with the largest square at the bottom left.

1

SYSTEM OVERVIEW

A decorative graphic consisting of two light blue squares arranged in a staircase pattern, with the largest square at the bottom left.

1. Product information	2
1. Robot "ZERO" structure	2
2. Manufacturer, system integrator, and user	2
3. Notes in the instructions	3
4. Purpose of use	3
2. International specifications	4
1. Suitable standards	4
2. Environmental specifications	4


1. PRODUCT INFORMATION

1. ROBOT "ZERO" STRUCTURE

This product contains the following components:


"ZERO" (= Robot)

"ZERO" includes manipulator and robot controller



Manipulator

The manipulator is a 6-axis vertical articulated 6-axis robot actuated by servo motors. Attaching different end-effectors to the manipulator-tip allows the robot to be adapted for various tasks.




Controller

The controller is a control board that includes control circuitry and a power supply board. The controller handles communications with the host controller through I/O interfaces, and comprehensively controls motions of the manipulator.

2. Manufacturer, system integrator, and user

Manufacturers, system integrators, and users are defined in this document as follows:



3. Notes in the instructions

- The specification values (ratings, performance) are those obtained under the conditions of an individual test and cannot guarantee the values obtained under combined conditions.
- Specifications may change or production may be discontinued without notice due to product improvements or company circumstances.

4. PURPOSE OF USE

This product is an industrial robot. It is designed and manufactured for typical industrial products at factories. It is not suitable for home use or for the following purposes. The company does not guarantee the following:

Usage related to military or weapons

All military-related applications where the end user and the ultimate purpose of use are military or weaponry.

Applications requiring high safety and reliability

Nuclear energy control devices, combustion devices, aerospace equipment, transportation, railway equipment, shipbuilding equipment, lifting devices, amusement vehicles, medical equipment, nursing machinery, safety equipment, automotive production loading equipment

Other devices that pose a risk to life.

Use in harsh conditions or environments

Outdoor works, chemically polluted works, electronically disturbed works, works subject to vibration or impact, dusty locations, and mining operations in mines

Use in conditions or environments not described in the User Manual

Failure to follow the warnings and precautions stated in the Terms of use, etc., may lead to injury (death or serious injury), accidents, or malfunctions. The company is not responsible for this.

The company cannot predict all possible risk and problem situations. The warnings, cautions, and other information stated in the Terms of use, etc., are within the scope of what our company can predict.

1. SUITABLE STANDARDS

Machine type instructions

.... 2006/42/EC

Machine safety – Electrical equipment of machine – Part 1: General requirements

.... EN60204-1:2018

Robots and robot devices – Safety requirements for industrial robots – Part 1: Robot

.... EN/ISO 10218-1 : 2011

EMC

.... EN61000-6-2:2005

.... EN55011 : 2009+A1:2010

KCs

..... S2-W-5-2017


2. Environment specifications

Specifications	Manipulator	Controller
IP	IP40	
Vibration – impact	—	JIS B3502

A decorative graphic consisting of five light blue squares of varying sizes arranged in a staggered, descending pattern from the top left towards the center of the page.

2

SYSTEM INSTALLATION

A decorative graphic consisting of three light blue squares of varying sizes arranged in a staggered, descending pattern on the left side of the table of contents.

1. Start-up procedure.....	2
2. Unpacking	4
3. Attachements/Accessories	5
4. Transportation	6
1. Moving to installation space	6
2. Transporting when changing locations.	7

1. START-UP PROCEDURE

UNPACKING



A OVERVIEW

- Check for any signs of damage during transportation.
- Please lift the device up to avoid putting pressure on the plastic lid.
- Check if the contents inside are damaged or deformed.
- Ensure that the product received matches the ordered product and is complete.
- Check if it includes a manipulator and controller.
- Ensure there is enough space on a flat surface.
- Wear protective gear such as helmets, goggles, safety shoes, gloves, and remove anything that may get caught, such as straps, before taking the device out.
- Please preserve the opened box and fixtures in case it is needed when moving.

TRANSPORTATION Moving to installation space



A OVERVIEW

- The installation must be performed by at least two people.
- Use a crane or trolley to move as close to the installation space as possible.
- Be careful not to cause excessive impact or vibration when moving to the installation space or when transporting onto the trolley.
- Be careful not to apply too much force to protruding parts such as switches, terminals, connectors, and cooling fans.
- Be careful not to place any heavy objects on the plastic casing during transportation.
- When temporarily fixing, use at least one bolt to tighten.
- Proceed while maintaining the transportation posture until it is fixed to the installation space.

INSTALLATION



B HARDWARE

- Secure the manipulator to the horizontal mounting surface within the safety zone (inside the safety fence) using fixed hex bolts (M8) and prevent it from skewing or falling.
- Ensure the manipulator is rigid enough and fixed in the appropriate position. The recommended roughness of the mounting surface is Rz25 or above. The mounting surface must have sufficient strength and rigidity to withstand the reaction force and load during operation.
- Ensure a space that does not affect the manipulators or other peripheral devices.
- Fix the controller horizontally using screws outside the safety zone (outside the safety fence) where the controller can be easily seen. Please do not remove the rubber feet.
- Installation should consider the location and method of work necessary for future inspection, repair, and maintenance.
- Ensure fixation even when temporarily installed for operational testing and trial runs.

WIRING AND POWER SUPPLY



B HARDWARE

- Be careful not to incorrectly plug in connectors or cable them incorrectly.
- Plug in the connector firmly until you hear a “click”.
- Securely install and fix the screw connector.
- Please connect the power supply after completing the entire electrical wiring system.
- When installing cables and pipes, be careful not to trip or fall.
- Keep the cables between devices or external input/output cables separate from the power lines or ground lines of other devices.
- Ensure the use of protective cables for external input/output cables.
- Do not apply a voltage different from the voltage specified in the User Manual for each end-effector.
- Be careful to ensure that the terminal connections and poles (+ and -) are not incorrect.
- Ensure the wiring space and fixation so that the cable mass, reaction force, load, etc., do not affect the connectors. Protect the connections when necessary.
- Ensure prevention of electric shock, static electricity, improved noise performance, and elimination of unnecessary electromagnetic wave radiation.
- Use cables of the specified size for grounding and keep the distance to the grounding point as short as possible.
- Use a dedicated grounding method and separate grounding when installing other large devices.

HOMING, TEACHING



C TEACHING

- Connect the controller to the teaching PC.
- Teaching by using the JOG stick outside the safety zone (outside the safety fence).
- Only TURN ON the activation switch when you want to operate the manipulator.
- If it is unavoidable to conduct teaching within the safety zone (inside the safety fence), ensure safety.
- Check the priority level of robot control and use the lock key, emergency stop switch, and interlock key to indicate during the teaching operation.
- Ensure an emergency exit in case of an emergency.
- After working, return the safety protection equipment to its original condition.
- Confirm that there are no obstacles such as peripheral devices within the range of operation of the manipulator before operating.

PROGRAMMING



D SOFTWARE

- Basic knowledge of Python is required.
- Programming can be easily done with this product's "Robot Library".
- Sample programs for basic operations are available.
- A memory map is provided.

OPERATION CONFIRMATION AND CHECKING



D SOFTWARE

- Ensure that there are no people within the safety zone (inside the safety fence) and no obstacles within the operating range of the manipulator.
- Operate outside the safety zone (outside the safety fence). When working within the safety zone (inside the safety fence), ensure safety.
- Check operation after confirming that all emergency stop switches are active.
- Check if the manipulator, including peripheral devices, can be stopped by the emergency stop switch.
- Perform a full operation check and ensure that the device can be operated safely.

BEFORE AUTOPILOT



D SOFTWARE

- Ensure that there are no people in the safety zone and no obstacles within the operator's range of motion.
- Check if everything in the system, including related peripheral devices, is capable of automatic operation.
- When starting control, first drive at a low speed and check if the vehicle is operating normally.

Complete the start-up procedure



Testing methods, troubleshooting, and other technical information are listed in the documentation Z section.



Z DOCUMENTATION

2. UNPACKING

RECEIVING

- Check for any signs of damage during transportation.
If there are any signs of damage, please unpacking in the presence of the carrier.
Preserve all packaging materials. They may be necessary when filing a claim for damages.
- Check if the controller and manipulator are concluded.
- Please check if the received product matches the order details.

UNPACKING PREPARATION

- Ensure there is enough space on a flat surface. The product may fall from unstable positions.
- Wear protective gear such as helmets, safety shoes, gloves, and remove anything that may get caught, such as straps.

UNPACKING

- Two or more people must work together.
 - Use a crane or trolley to move as close to the installation space as possible.
- When being carried by one person, ensure there is no significant difference in strength between the two people.
Also, ensure stability is not lost due to opening or closing doors, etc.
- Do not hold anything except the fixed fixtures. In particular, plastic parts may become the cause of damage.

AFTER UNPACKING




- When temporarily installing the manipulator, secure it by tightening it with at least one bolt.
- Do not remove the fixtures until the installation process is complete.
- Please preserve the packaging materials or the original fixing accessories, they can be used for repackaging in the same condition as when delivered if relocation or transportation is needed.



Preparation before moving

Please forward all User manuals related to this product to the end user.
The system integrator must prepare a User Manual for the entire system, including this product, and deliver it to the user.
Please preserve all packaging materials and packages in the same condition as when delivered.
When reusing wooden pallets for international transportation, please check International Standard No. 15 "Regulations on wooden packaging material in international trade".

3. ATTACHMENTS/ACCESSORIES

Attachments/Accessories	Model (Manufacturer)	Quantity	Note
Manipulator	ZRA-05***	1 pcs	—
Controller	ZC100*	1 pcs	—
User Manual	—	1 copy	PDF File
Installation Manual	—	1 copy	Manual / PDF File
Safety Manual	—	1 copy	Manual / PDF File
I/O Connector	DFMC 1,5/10-ST-3,5-LR (1790564) (PHOENIX CONTACT COM)	3 pcs	(20 pin) 
Safety Connector	As above	1 pcs	As above
Coding profile keys	CP-DMC 1,5 NAT (1790647) (PHOENIX CONTACT COM)	1 set (6 pcs)	
Jumper Connector	E2010101 (ZEUS CO., LTD.)	1 pcs	
Manipulator Cable	E2021701 (ZEUS CO., LTD)	1 pcs	<ul style="list-style-type: none"> • Length 3m • The supplied ferrite cores cannot be removed
Ferrite Core	—	2 pcs	<ul style="list-style-type: none"> • For power cable • Diameter 4.5 - 8.5 mm

4. TRANSPORTATION

1. MOVING TO INSTALLATION SPACE



At least two people must work together.

Use a crane or trolley to move as close to the installation space as possible.

When transporting by manpower, ensure there is no significant difference in strength between the two people.

Do not lift with one hand when opening or closing door, etc.




· Controller

Lift and move the lower part to avoid bumps to the front and intake/exhaust vents.

· Manipulator


Do not hold the articulation (joint part) or bottom flange.

ZRA-05**P



Transportation posture







ZRA-05**N



Padding material is used to avoid damage to the manipulator.

Keep the padding material along with the product box as it will be reused when it needs to be transported.

2. TRANSPORTING WHEN CHANGING LOCATIONS

	<p>At least two people must work together.</p> <p>Damage caused by improper packaging is not covered by the warranty.</p>	  
	<p>Please pack safely with the packaging materials provided at the time of purchase.</p> <p>Transport the device as a “machinery requiring precision” transaction.</p> <p>There is a risk of damaging the manipulator if it is subjected to impact or load on the joints during transportation.</p>	 

Controller

Be careful not to damage the front vents and the intake/exhaust vents, and place them in a dedicated cardboard box in the same condition as when delivered.

Manipulator

Please pack the product in the same condition as when delivered, in the transport position, using the packaging materials available at the time of delivery.

Transporting the product under conditions different from those specified may cause accidents or malfunctions.

When reusing wooden pallets for overseas transport, please check International Standard No. 15 “Regulations on wooden packaging material in international trade”.


PACK THE MANIPULATOR

1. Manipulator transportation posture


To change the position, connect the controller and the manipulator with a cable and then TURN ON the power of the controller. When the power is plugged in and the brake release button is pressed on each joint, the brake will be released. (The brakes are only released when the button is pressed.)

Brake Release Button

The brake will not release unless power is connected to the robot




ZRA-05**P



Transportation posture

ZRA-05**N



Transportation posture


Ensure to insert padding material to avoid damaging the manipulator

Be careful not to let the padding material fall off.


2. Use dedicated packing box

Place the manipulator into the packing box.
Use padding material to ensure proper protection.

ZRA-05**P




ZRA-05**N



Pack the Controller

1. Use dedicated packing box


Place the controller on its side in a dedicated packing box, and when placing the controller, disconnect all connectors.





B

HARDWARE

- 
1. SYSTEM CONFIGURATION
 2. MANIPULATOR
 3. CONTROLLER
 4. JOG STICK
 5. TEACHING PENDANT
 6. WIRING AND POWER
SUPPLY

NOTE



B HARDWARE

1

SYSTEM CONFIGURATION



1. Model name	2
2. System configuration	3

1. MODEL NAME

ZERO

This product is supplied with manipulator and controller.

Manipulator model name: **ZRA - 05 15 P**

ZEUS Robot Type A (First)

Maximum load

Symbol	Dimension
XX	XX kg

Classification number


No.	Total length (mm)	Arm length 1 (mm)	Arm length 2 (mm)	Model name
1	590	320	270	ZRA-0501N
2	660	320	340	ZRA-0502N(*)
3	660	390	270	ZRA-0503P(*)
4	690	320	370	ZRA-0504N
5	690	420	270	ZRA-0505P
6	730	390	340	ZRA-0506N
7	760	320	440	ZRA-0507N
8	760	390	370	ZRA-0508N
9	760	420	340	ZRA-0509N
10	760	490	270	ZRA-0510P
11	790	420	370	ZRA-0511N
12	830	390	440	ZRA-0512N
13	830	490	340	ZRA-0513P
14	860	420	440	ZRA-0514N(*)
15	860	490	370	ZRA-0515P(*)

*) 4 models are typical models.
Only use 590mm ~ 860mm models.

Arm type

Symbol	Dimension
N	Turn Around Motion Type
P	Pass Through Type

Models with a difference of 120mm or more between
1st Arm and 2nd Arm are Pass Through Type




It is possible to match the length of the arm in accordance with the customer's layout because the total length of the first and second arms is less than 860mm. For more details, please contact.


Use both model names interchangeably when necessary.

Example: Model name on label of Manipulator



2. System configuration





B Hardware

2

MANIPULATOR




1. Overview	2
1. Characteristics	2
2. Label.....	3
2. Part name	4
3. Installation	5
4. Dimensional diagram	7
5. Specifications.....	11
6. Connector	12
1. Connector connect to manipulator cable	12
2. Arm I/O connector	13
3. Arm I/O input/output circuit	14
7. Movement range	15
8. End-effector design.....	17

1. Characteristics

It is possible to match the length of the arm in accordance with the customer's layout because the total length of the first and second arms is less than 860mm.


It can be divided into “pass-through type” and “turn around motion type” based on the difference in the length of the first arm and the second arm. For more details, please contact.

Example of Arm length



What is pass-through motion?


As the characteristic operation of the manipulator has the 1st arm longer than the 2nd arm. As shown on the right, do not rotate the J1 but can move to the completely opposite side of the manipulator.



2. Label

The product label and C.CODE label are pasted on the manipulator.

Product label



Specifications
Power specification
Body weight
Maximum operating range
Weight

Model
ZERO Series **LQGXXWULDO URERW**
MODEL **ZRA-0515P**
Serial Number **21060001**

Serial number
Serial number description
21 06 0001
Year of manufacture Month of manufacture Manufacture number

Input **DC48V 8A, DC24V 1A** Supplied from ZC100*
Weight **17.5kg** Transport Robot lower frame
MAX. Reach **860m** | Load Capacity **5kg**
Reference Document No. M0101-210524
MADE IN KOREA


Label location

Reference number of the User Manual

Year of manufacture: "21" = 2021 (last 2 digits)
Month of manufacture: "01" = January ~ "12" = December
Manufacture number: "0001" ~ "9999"

For example, this product label has model name of manipulator is "ZRA-0515P", serial number is "21060001".

C. CODE LABEL



Only connect manipulator and controller that have the same C.CODE (Connector code)

C. CODE
ZRA-0515P-21060001

CAUTION Only Connect Manipulator and Controller that have the same C.CODE.

부착 위치

For example, this C.CODE label has model name of manipulator is "ZRA-0515P", serial number is "19030006".

2. Part names

ZERO

Joint 5 (J5)

Small joint

Arm I/O connector

Located in the back

2nd ArmJoint 3 (J3)

Middle joint

Joint 4 (J4)

Small joint

1st ArmJoint 2 (J2)

Middle joint


Junction Box

This is a cover of the manipulator cable connecting to the controller. Junction Box connected to Manipulator

Top flangeJoint 6 (J6)

Small joint


Details of Arm I/O

Arm I/O connectorJoint 1 (J1)

Middle joint

Bottom flange

Details of 4th, 5th and 6th Joints




State display LED

Brake Release Button

EtherCAT Status LED
LOUTEtherCAT Status LED
LIN

Details of 1st, 2nd, and 3rd Joints



Details of Junction Box

Remove the cover to see the following connectors

Connector for the EtherCAT communication cable


LIN

Connect the EtherCat connector end of the manipulator cable

Connector for the EtherCAT communication cable

LOUT

Use this for connecting Slave Device

Power supply connector



Caution



Install correctly according to the installation conditions.



Installation conditions

Item	Specifications
Operating temperature	0 °C - 40°C
Operating humidity	30 %RH - 85 %RH (non-condensing)
Operating atmosphere	Indoor use only (no direct sunlight). Free from corrosive gases, flammable gases, oil mist, any liquids including water, dust, flammables, and grinding agent. Good ventilation.
Pollution degree	2 (Comply with IEC60664-1)
Vibration and impact	Comply with IEC61131-2 (controller only) Vibration during operation 0.5G or less (No excessive vibration or shock)
Degree of protection	IP40 (manipulator, controller)
Power Supply	Supplied from compatible controller
Grounding	Class D (Ground resistance of 100 Ω or less)
Noise	No strong electromagnetic field in proximity (*)

*) The robot may operate incorrectly due to strong electromagnetic field.

The specifications mentioned in this document are general specifications. For detailed content, please refer to the delivery specification sheet.



Caution



We recommend independently testing all operating programs and features outside the operational space of other devices in case the robot is used together or in combination with devices that have the potential to damage the robot.




Mounting styles




Caution




Observe the mounting styles specified and mount the manipulator properly



Floor-mount



Ceiling-mount



Wall-mount
NG




Caution





Do not allow cables or connectors to be impacted within the operating range of the manipulator in the case of installing the manipulator on a cylinder table.



Watch out for interference of the manipulator and the cable.



Cylinder table



Manipulator cable



Caution



Please refer to the dimensional diagram for top flange installation in relation to the end-effector installation, and the dimensional diagram for the fixed installation of the bottom flange when installing the manipulator. It is recommended to attach all 7 screws for the bottom flange.



4. DIMENSIONAL DIAGRAM

ZERO


ZRA-0503P

Arm length: 660 mm

Pass Through Type

Not to scale

(mm)

**Mounting bottom flange**

To mount bottom flange, using M8 hex sockethead cap screws of at least 30 mm long is recommended.

The recommended tightening torque is 22 Nm.


ZRA-0515P

Arm length: 860 mm


Pass Through Type

Not to scale

(mm)



J1 rotational range





Top flange


For end-effector attachment

Bottom flange

For mounting



Cross section E-O-É



BOTTOM VIEW

Mounting bottom flange

To mount bottom flange, using M8 hex sockethead cap screws of at least 30 mm long is recommended.

The recommended tightening torque is 22 Nm.


ZRA-0502N

Arm length: 660 mm

Turn Around Motion Type

Not to scale

(mm)



Mounting bottom flange

To mount bottom flange, using M8 hex sockethead cap screws of at least 30 mm long is recommended.

The recommended tightening torque is 22 Nm


ZRA-0514N

Arm length: 860 mm

Turn Around Motion Type

Not to Scale

(mm)



Mounting bottom flange

To mount bottom flange, using M8 hex sockethead cap screws of at least 30 mm long is recommended.
The recommended tightening torque is 22 Nm.

Item		Unit	ZRA-0503P	ZRA-0515P	ZRA-0502N	ZRA-0514N
Structure		—	Vertical Articulated robot			
Degrees of motion freedom (DOF)		—	6			
Mount direction		—	Floor, Ceiling			
Drive system		—	BLDC motor			
Position detection method		—	Multi-turn Absolute Encoder (Battery Backup)			
Position control method		—	Servo control			
Break		—	J1, J2, J3: Holding brake (Disc brake) J4, J5, J6: Holding brake (Mechanical stopper)			
Payload ^(*1)	Standard Maximum	kg	7	5	7	5
Arm Length (1st Arm + 2nd Arm)		mm	660 (390 + 270)	860 (490 + 370)	660 (320 + 340)	860 (420 + 440)
Work area		mm	1320	1720	1320	1720
Motion range ^(*2)	J1	deg	480 (± 240)	480 (± 240)	480 (± 240)	480 (± 240)
	J2		480 (± 240)	480 (± 240)	480 (± 240)	480 (± 240)
	J3		480 (± 240)	480 (± 240)	480 (± 240)	480 (± 240)
	J4		480 (± 240)	480 (± 240)	300 (± 150)	300 (± 150)
	J5		480 (± 240)	480 (± 240)	480 (± 240)	480 (± 240)
	J6		480 (± 240)	480 (± 240)	480 (± 240)	480 (± 240)
Resultant Velocity ^(*3)		mm/sec	4420	5540	4570	5700
Repeatability		mm	±0.02			
Permissible load inertia ^(*5)	J4	x10 ⁻⁴	0.15	0.15	0.15	0.15
	J5		0.27	0.27	0.27	0.27
	J6	kg · m ²	0.33	0.33	0.33	0.33
Outer Dimensions		—	149 x 331 x 873	149 x 331 x 1073	149 x 331 x 873	149 x 331 x 1073
Body Weight		kg	17.2	17.5	17.2	17.5
Compatible controller		—	ZC1***			
Arm I/O (for Tool)		—	8 input ports, 4 output ports / Asynchronous communication RS-422 1 port / DC 24 power output			
Manipulator cable length		m	3			
Manipulator mount		—	M8 screws at 7 spots (refer the dimension drawing) ^(*6)			
End-effector mount		—	M5 screws at 4 spots (refer the dimension drawing)			
Noise		dB	Under 70 (Based on our test)			

*1) The payload includes loads of tasks, weight of tools, and so. Allowable torque exceeding error c13 and overload error c14 may occur even within specification depending on the posture, speed, acceleration/deceleration time, direction of operation, etc. Adjust motion factors and variables then.

*2) Refer to "5. Coordinate Systems and Posture" for information on definitions of axes. Depending upon arm postures, unreachable points exist even within the work envelop.

*3) Value is for a reference.

*4) In case of the maximum load at the maximum speed.

*5) Depends on operating conditions, such as acceleration and deceleration.

*6) Using screws of at least 30 mm long is recommended.


Replenishment) This product is a stop category "0". Corresponds to PL = d.

The compressed air pipe cannot pass through inside of the manipulator.

1. Connecting the manipulator cable


Remove the Junction Box, refer to the drawing below, then connect the connector of the manipulator cable.

(Manipulator cable is an accessory)




Connecting method

- 1 Connect the power supply connector to the EtherCAT Communication connector.
- 2 Tighten bolts of Junction Box
Bolts: Hexagon countersunk bolts (M3, 4 pieces)
- 3 Fasten the connector cover panel bracket.



2. Arm I/O connector

Arm I/O is the I/O port used for the tool attached to the end of the manipulator.



Connector and cable are not included.
Customer should provide when needed.


Connector pinout

Connector	Signal Name	Description	Connector	Signal Name	Description
1	24V_OUT	24V power supply output	11	24V_OUT	24V power supply output
2	I1	Common input	12	I2	Common input
3	I3	Common input	13	I4	Common input
4	I5	Common input	14	I6	Common input
5	I7	Common input	15	I8	Common input
6	O1	Common output	16	O2	Common output
7	O3	Common output	17	O4	Common output
8	D+	RS422_TXD+/RS485_D+	18	D-	RS422_TXD-/RS485_D-
9	RD+	RS422_RXD+	19	RD-	RS422_RXD-
10	G24	GND power supply	20	G24	GND power supply

3. Output/input circuit of Arm I/O


Common input circuit

Item	Specifications
Method	Comparator circuit input (non-isolated)
Rated voltage	DC24 V
Input ON voltage	9 V typ. n)
Input impedance	4.3 k Ω typ.



Common output circuit

Item	Specifications
Method	High side switch (non-isolated)
Rated voltage	DC24 V
Rated current	0.5 A (output current limit 0.7 A - 2.1)




Example of common output/input connection

Notes


- The total current consumption of the device connected to the Arm I/O should be kept below 100mA (maximum 200mA)
- It is mandatory to prepare countermeasures for any increase in case of using inductive loads such as relays, magnetic induction at the output.
- Arm I/O wiring,

- ① Ensure sufficient reduction from motor transmission cables or high voltage cables.
- ② Prepare noise countermeasures such as using shielded cables.
- ③ Use a length of less than 1m.



Asynchronous transmission circuit

Is the interface of asynchronous transmission
RS485 or RS422



It is strictly forbidden to connect with asynchronous transmission circuits other than the devices specified by our company.



ZRA-0503P

Arm length: 660 mm

Pass Through Type

Maximum reachable range of the top flange:

R725 sphere (around J2 rotational axis)

1st Arm movable range:

(where contact with the manipulator or pinch point risk exists)


R500 sphere (around J2 rotational axis)

J1 minimum rotational range

(where contact with the manipulator or pinch point risk exists at

J2=0° J3=180°)

Unreachable points of the top flange when top flange faces up or down

R215 cylinder (around J1 rotational axis)

ZRA-0515P

Arm length: 860 mm

Pass Through Type

Maximum reachable range of the top flange:

R925 sphere (around J2 rotational axis)

1st Arm movable range


(where contact with the manipulator or pinch point risk exists)

R600 sphere (around J2 rotational axis)

J1 minimum rotational range:

Where contact with the manipulator or pinch point risk exists at J2=0° J3=180°)

Unreachable points of the top flange when top flange faces up or down


R100 cylinder (around J1 rotational axis)Replenishment

Depending upon arm postures, unreachable points exist even within the work envelop.

ZRA-0502N

Arm length: 660 mm


Turn Around Motion Type



ZRA-0514N

Arm length: 860 mm

Turn Around Motion Type



Replenishment

Depending upon arm postures, unreachable points exist even within the work envelop.



Caution




When designing a tool which will be attached to the top flange, thoroughly validate manipulator postures and motion ranges. See below for examples.



Example 1

Recommended


The tool center point coincides with the J6 rotational axis. If the distance from the top flange to the outermost part of the tool is large, the load on the manipulator will be significant, leading to vibration or a low operating speed.



Example 2

Not recommended


There is an offset between the central axis of the tool and the J6 rotational axis, the robot may become unable to handle a work piece.



Example 3

Not recommended

Because the central axis of the tool and the J6 rotational axis are not coaxial, the robot may become unable to handle a work piece.



This image shows a single sheet of white paper with horizontal blue ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



B Hardware

3

CONTROLLER



1. Model name and label	2
1. Model name.....	2
2. Label.....	2
2. Part names.....	3
3. Installation	4
4. Dimension drawing.....	5
5. Specifications.....	6
1. General specifications	6
2. Output/input circuit of I/O connector	7
6. Connector.....	8
1. I/O connector.....	8
2. Safety Connector 9	
3. Coding profile key.....	10
7. Controller status representation	11

1 . MODEL NAME AND LABEL

ZERO

1. Model name

Model name of controller

ZC

1001

Product
code

Model

Product code

Model



Symbol	Robot
1000	ZERO series
1001	ZERO series + ZP1000

2. Label


Labels

Label location

Product label



C. Code Label



For example, this label has the manipulator's serial number as "21060001", C. CODE "0515P-21060001". This representation varies with each product. The serial number system is the same as that of the manipulator.



Please connect the controller to the manipulator according to the same C.CODE combination.

C.CODE represents the combination of the controller and the manipulator.
Please verify the C.CODE label and then connect the C.CODE accordingly.



2. PART NAME

ZERO





Caution



The PE end-effector is dedicated for internal voltage testing.

- Do not remove the screws.
- Do not connect anything.





Caution



Do not install in enclosed spaces.
Do not block the air intake and exhaust vents




Please install in an environment with an ambient temperature below 40 °C.

Refer to the drawing below and install the controller in a flat position with sufficient space.

It is recommended to use dedicated screws (M3 x 4 pieces) on the side of the controller, with anti-reversal treatment.



Replace the designated filter periodically.



*) User-supplied

4. Dimension drawing


ZERO



Caution



When designing a metal fitting, make it so that the cover fixing screws are 20 mm away from the controller mount holes and also the air inlets will not be blocked.



1. General specifications

Item		ZC1000		ZC1001	Note
General Specifications	Compatible Manipulator	ZERO series			In case using Teaching Pendant(ZP1000) ZC1001 is necessary
	Dimensions	(See a dimension drawing)			The overhang is not included
	Weight	5 kg			—
	Number of Control Axes	6 axes			—
	ProgrammingMethod	Off-line programming with a PC			Application programs are transferred with TFP and executed.
	Programminglanguage	Python			Use the special libraries for the robot operation
	Storage Memory	eMMC			—
	Teaching method	PC Jog Stick	PC Jog Stick Teaching Pendant		Monitoring, storing and controlling data via http with a web browser
Display function	7-segment display panel	3 digits			—
	Status LED indicators	3 lamps			—
Interface (Controller)	Manipulator Connector	1 Port			—
	Input	16 Bit			Isolated; selection of high-side or low-side
	Output	16 Bit			Isolated; selection of high-side or low-side
	Safety	1 Port			EMS x 2; Mode; Servo-On input Servo power monitor
	Ethernet	2 Port			—
	USB	2 Port			—
Interface (Arml/O)	JOG Stick	1 Port			A special input device I/F for teaching
	Digital input	8 Bit			Not isolated; comparator input
	Digital output	4 Bit			Non-isolated; high-side switch
	Asynchronous communication	1 Ch			RS422/RS485
	Power output	24 V			0.2 A max
Power supply specifications (*)	Voltage	Single-phase 100 VAC - 240 VAC			—
	Frequency	50 Hz - 60 Hz			—
	Current	2.7 A, 230 VAC / 5.4 A, 115 VAC			—
	In-rush current	75 A, 230 VAC			—
	leakage current	5.0 mA, 240 VAC			—
	Rated short circuit current	1,500 A			UL File No. E10480
Grounding		Type 3 grounding or above			Grounding resistance value of 100 Ω or below
Safety	Rating	ISO 10218-1			Certified
	Voltage-resistance	1,500 VAC			Primary-FG, 1 minute
	Insulation resistance	1 M Ω or above			I/P - FG 500VDC / 25°C / 70%RH
EMC		EN61000-6-2:2005			Heavy industrial level
		EN55011 : 2009+A1:2010			

*) Input voltage

Be no power outage for more than 20ms

Gain sufficient power including in-rush current


Use fuses with rated current: 8A, rated breaking capacity: AC250 V / 1,500 A

The specifications mentioned in this document are general specifications. For detailed content, please refer to the delivery specification.

2. Output/input circuit of I/O connector

Input circuit


Item	Specifications
Method	Port coupling unit (16-point common power supply)
Rated voltage	DC 24 V
Input ON current	5 mA typ. (Input OFF current less than 2.5mA)



Output circuit

Item	Specifications
Method	Independent output drain, source (separate top and bottom correspondence)
Rated voltage	DC 24 V
Rated current	0.5 A (output current limit 0.6 A - 1.2 A)

- The output can be connected to various devices such as signal devices, relays, and buzzers.
- Please refer to the wiring example in the user manual of the connection device.
- Please connect a protective circuit (diode) when connecting devices with inductive components such as relays.



1. I/O connector

CN3: I/O connector 1 (input)

Connector	Signal Name	Description	Connector	Signal Name	Description
1A	P24	24V output of controller (*1)	1B	—	—
2A	IN1	Common input	2B	IN2	Common input
3A	IN3	Common input	3B	IN4	Common input
4A	IN5	Common input	4B	IN6	Common input
5A	IN7	Common input	5B	IN8	Common input
6A	IN9	Common input	6B	IN10	Common input
7A	IN11	Common input	7B	IN12	Common input
8A	IN13	Common input	8B	IN14	Common input
9A	IN15	Common input	9B	IN16	Common input
10A	G24	Common input	10B	ICOM	Common input


CN4: I/O connector 2 (output)

Connector	Signal Name	Description	Connector	Signal Name	Description
1A	P24	24V output of controller (*1)	1B	VBB	24V power input for output circuit (*2)
2A	O1P	Common output drain	2B	O1N	Common output source
3A	O2P	Common output drain	3B	O2N	Common output source
4A	O3P	Common output drain	4B	O3N	Common output source
5A	O4P	Common output drain	5B	O4N	Common output source
6A	O5P	Common output drain	6B	O5N	Common output source
7A	O6P	Common output drain	7B	O6N	Common output source
8A	O7P	Common output drain	8B	O7N	Common output source
9A	O8P	Common output drain	9B	O8N	Common output source
10A	G24	Controller GND 24V (*1)	10B	GBB	GND 24V for output circuit (*2)

CN5: I/O connector 3 (output)

Connector	Signal Name	Description	Connector	Signal Name	Description
1A	P24	24V output of controller (*1)	1B	VBB	24V power input for output circuit(*2)
2A	O9P	Common output drain	2B	O9N	Common output source
3A	O10P	Common output drain	3B	O10N	Common output source
4A	O11P	Common output drain	4B	O11N	Common output source
5A	O12P	Common output drain	5B	O12N	Common output source
6A	O13P	Common output drain	6B	O13N	Common output source
7A	O14P	Common output drain	7B	O14N	Common output source
8A	O15P	Common output drain	8B	O15N	Common output source
9A	O16P	Common output drain	9B	O16N	Common output source
10A	G24	Controller GND 24V (*1)	10B	GBB	GND 24V for output circuit (*2)

Model name of I/O connector, safety
connector: DFMC 1,5/10-ST-3,5-LR
1790564
(Phoenix Contact JSC.)



Feature division

of reference I/O Software

Memory map

*1) Dòng điện tiêu thụ sử dụng ở I/O thiết bị đầu cuối, đầu vào, đầu ra hãy để tổng dưới 100mA.

*2) Thiết bị cung cấp nguồn điện mạch điện đầu ra (VBB, GBB) I/O connector 2 và VBB, GBB của 3 được nối với nhau. Không được nối nguồn điện khác vào thiết bị đầu cuối này.

2. Safety connector



Connect the safety connector correctly

If not, the manipulator cannot be operated.



5 Refer to the wiring and power supply


N6: Safety connector

Connector	Signal Name	Description	Connector	Signal Name	Description
1A	EMS1_H+ (P24)	Emergency stop switch 1a, Controller 24V	1B	EMS1_L+ (P24)	Emergency stop switch 1a, Controller 24V
2A	EMS1_H-	Emergency stop switch 1a (*3)	2B	EMS1_L-	Emergency stop switch 1a (*3)
3A	EMS2_H+	Emergency stop switch 2a (*3)	3B	EMS2_L+	Emergency stop switch 2a (*3)
4A	EMS2_H-	Emergency stop switch 2a (*3)	4B	EMS2_L-	Emergency stop switch 2a (*3)
5A	MODE_H+	Mode switch (*3)	5B	MODE_L+	Mode switch (*3)
6A	MODE_H-	Mode switch (*3)	6B	MODE_L-	Mode switch (*3)
7A	SVON_MON+	Servo-ON monitor output	7B	SVON_MON_-	Servo-ON monitor output
8A	READY_H	READY contact output	8B	READY_L	READY contact output
9A	SVON_H+	Servo-ON input	9B 10B	SVON_H- G24	Servo-ON input
10A	NC				

Safety connector(*)

model name: DFMC 1,5/10-ST-3,5-LR 1790564
(Phoenix Contact JSC.)

Same as I/O connectors 1, 2, and 3



Connecting I/O connector and safety connector

- Separate the motor drive cable from the high-voltage cable and then use a sheathed cable.
- Consider the interference to use under 15m.
- It is mandatory to use a protective circuit (diode) and increased coping in case of connecting devices with self-inductive components such as relays, electromagnets at the output.

*1), *2) : The internal circuit has polarity.

+ 24V is output at the (signal name) input circuit.

If short-circuited with GND including FG, the controller may be damaged.

Route the wiring appropriately so that the output signal does not contact the DC 24V line and the output is not turned ON.

*3) : Please refer to the connector connection example and then connect.

3. Coding profile keys




Caution



Please insert each of the provided coding profile keys into the safety connector and I/O connectors 1, 2, 3 to prevent incorrect connector connections.



The controller is equipped with coding profile keys.





Connector		Pin No.									
		1	2	3	4	5	6	7	8	9	10
Controller side	CN3 I/O Connector 1		⊙	⊙	⊙						
	CN4 I/O Connector 2	⊙		⊙	⊙						
	CN5 I/O Connector 3	⊙	⊙		⊙						
	CN6 Safety connector	⊙	⊙	⊙							

(⊙Insert coding profile keys into place)

Connector		Pin No.									
		1	2	3	4	5	6	7	8	9	10
Cable side	CN3 I/O Connector 1	●									
	CN4 I/O Connector 2		●								
	CN5 I/O Connector 3			●							
	CN6 Safety connector				●						

(●Insert coding profile keys into place)

In case of CN3 I/O connector 1



7. Display the status on the controller

Display the robot's status on the LED indicators and the 7-segment Display Panel of the controller

7-segment LED's displays

Display the item below in the 7-segment display device.

The period blinking in the bottom right corner of the 7-segment display panel indicates that the controller system is in operation.



Display	Description
---	Starting the controller
ini	Initializing the controller
rdy	READY state (stand-by)
inc	ABS Lost state (*1)
tch	Teach Mode
JoG	JOG Operation Mode
run	Executing User program
PAu	Pausing User Program
PoF	Processing Power OFF
E**	System-Defined Error (*2, *4)
c**	System-Defined Error Fatal (*2, *5)
u**	User-Defined Error (*3, *4)
r**	User-Defined Error Fatal (*3, *5)

*1) When started for the first time, the manipulator is in a state of the absolute position being lost.

*2) For more information on system-defined errors, refer to "Troubleshooting".

*3) Any user-defined errors can be created using Python programming.


*4) For a non-fatal error, eliminate the cause, and then recover with "Error reset signal".

*5) For a fatal error, eliminate the cause, then power cycle.



LED Indicators

LED



NOTE



B. Hardware

4



JOG stick



1. Product label	2
2. Part name	3
3. Installation	4
4. Dimension drawing	5
5. Specifications	6
6. Features	7

1. Product label


B

Label	Label location
<p>Product label</p> 	 <p>Label on the back</p> <p>On the back</p>

For example, the serial number of the label above is '21060001'. Each product has a different serial number.
The serial number system is the same as that of manipulator.

2. Part name

The JOG stick (optional) can be used to JOG the axes of the manipulator. JOG operation moves to the home position or is used in teaching operation.




3. Installation

ZERO



Please store the JOG Stick in the designated location when the it is not in use.

4. Dimension drawing



5. Specifications

	Item	Specification	Remark
General Specifications	Model	ZJ1000	—
	Dimensions	H56 mm × D155 mm × W40 mm	Not including a cable
	Weight	600 g or less	—
	Frame material	ABS resin	Color: Yellow, Black
	Power supply volatage	DC24 V ± 10%	—
	Power consumption	5 W or less	—
	Cable length	5 m	—
Environmental Specifications	Operating temperature	0 °C - 40 °C	—
	Operating humidity	30 % - 85 %	—
	Storage temperature	— 40 °C - 85 °C	—

6. Features

Name	Features												
Emergency Stop Switch	If pressed hard, it will return to emergency stop state. To turn the servo back on, turn it clockwise, remove the emergency stop, and then press the Enable switch.												
Enable Switch	Press and turn on the servo. If you lift your hand or press deeper, the servo will turn off												
L Slide Switch	Change the operating connection <table><tr><td>Switch Positions</td><td>Top</td><td>Center</td><td>Bottom</td></tr><tr><td>Joint coordinate system</td><td>J1, J2</td><td>J3, J4</td><td>J5, J6</td></tr><tr><td>Orthogonal coordinate system</td><td>X axis, Y axis</td><td>Z axis, Rz axis</td><td>Ry axis, Rx axis</td></tr></table>	Switch Positions	Top	Center	Bottom	Joint coordinate system	J1, J2	J3, J4	J5, J6	Orthogonal coordinate system	X axis, Y axis	Z axis, Rz axis	Ry axis, Rx axis
Switch Positions	Top	Center	Bottom										
Joint coordinate system	J1, J2	J3, J4	J5, J6										
Orthogonal coordinate system	X axis, Y axis	Z axis, Rz axis	Ry axis, Rx axis										
R Slide Switch	Change “operating panel activity” on browser screen and “JOG stick operation” <table><tr><td>Operating position</td><td>Top</td><td></td></tr><tr><td>Operating</td><td>JOG Stick</td><td>Operating panel</td></tr></table>	Operating position	Top		Operating	JOG Stick	Operating panel						
Operating position	Top												
Operating	JOG Stick	Operating panel											
Circuit Breaker Switch	If you press and supply power to the controller at the same time, it will run in “JOG operation mode”												
Control Lever	Is the control lever + fuse switch. <ul style="list-style-type: none">Control Lever Tilt up, down, left and right and use the supporting arm. <div>Select the connection to be operated with the L slide switch</div> <ul style="list-style-type: none">Fuse switch (Not applicable)												
LED1	Indicates the status of the robot with a green LED Power on JOG stick (green) /power off (light off)												
LED2	(Not applicable)												
LED3	(Not applicable)												
Buzzer	Indicates status with a buzzer sound. <ul style="list-style-type: none">Sounds when teaching												
Vibration Motor	Indicates status by vibrating alarm <ul style="list-style-type: none">If the end of the manipulator is close to a point where it cannot be moved, it will vibrate.												

Buzzer pattern



Alarm sound	Meaning
「Pi」	Sound once in the following cases. <ul style="list-style-type: none"> When the controller operates. When starting the “Hand Homing” or “Direct Move” operating in the “Move To” of the operation when teaching.

NOTE



B. Hardware

5

Teaching pendant







1. Product label	2
2. Part name	3
3. Dimension drawing	4
4. Specifications	5
5. Features	6

1. Product label

ZERO


B

Label	Label location
<p>Product label</p> <div data-bbox="304 443 762 573"> <p>ZERO Series MODEL ZP1000 Serial Number 21060001</p> <p>ZEUS Made in Korea ZEUS CO., LTD. 132, Anmyeongnam-ro, Hwaseong-si, Gyeonggi-do, SOUTH KOREA</p> <p> </p> </div>	 <p>Label on the back</p>  <p>On the back</p>


For example, the serial number of the label above is "21060001". Each product has a different serial number.
The serial number system is the same as that of manipulator.

2. Part name

ZERO



3. Dimension drawing



Dimension excluding rubber feet and cable)

4. Specifications



Item		Specification	Remark
General Specifications	Model	ZP1000	—
	Dimensions	H95.1 mm × D257 mm × W205 mm	Not including a cable
	Weight	1.2 kg or less	—
	Frame material	PC + ABS resin	Color: Black
	Power supply volatage	DC24 V ± 10%	—
	Power consumption	12 W or less	—
	Cable length	3 m	—
Environmental Specifications	Operating temperature	0°C - 40 °C	—
	Operating humidity	30 % - 85 %	—
	Storage temperature	- 40 °C - 85 °C	—
	Storage humidity	10 % - 90 %	—
	Cooling	Natural cooling	—

5. Features



Name	Features						
Emergency Stop Switch	If pressed hard, it will return to emergency stop state. To turn the servo back on, turn it clockwise, remove the emergency stop, and then press the Enable switch.						
Enable Switch	Press and turn on the servo. If you lift your hand or press deeper, the servo will turn off						
Mode Switch	Convert from operating mode to teachning mode and remote mode (automatic operating mode) <table><tr><td>Switch Positions</td><td>Left</td><td>Right</td></tr><tr><td>Mode</td><td>Teaching mode</td><td>Remote mode</td></tr></table>	Switch Positions	Left	Right	Mode	Teaching mode	Remote mode
Switch Positions	Left	Right					
Mode	Teaching mode	Remote mode					
External Power Adapter Terminal	If the power adapter is connected, the teaching pendant’s power will turn on. It should not be used in normal circumstances. 24VDC ± 10%, 1A or higher External diameter (-) 5.5 mm / internal diameter (+) 2.1 mm ※ Do not connect the adapter while power is being supplied.						
USB Terminal	Open data such as error logs, teaching points saved in the teaching pendant. Upload the software update file. USB 2.0 x 1/ USB 3.0 x 1						
LED Indicators	Indicates the status of the robot and teaching pendant with LEDs. <ul style="list-style-type: none">• PWR: Power on teaching pendant (green) /OFF (light off)• SVON: Power on servo of robot (green) /OFF (light off)						
LCD	Displays the teaching screen of teaching pendant Can confirm the status of robot and teaching pendant.						
Speaker	Indicates status by sound <ul style="list-style-type: none">• Sounds when teaching						
Vibration Motor	Indicates status by vibrating alarm <ul style="list-style-type: none">• If the end of the manipulator is close to a point where it cannot be moved, it will vibrate.						

Speaker sound pattern



Alarm sound	Meaning
「Pi」	Sound once in the following case. <ul style="list-style-type: none"> • When approaching the area near the joint angle limit, speed limit, special areas.



6

B. Hardware


Wiring and Power Supply

1. Wiring	2
1. Complete wiring diagram	2
2. Power cable	4
3. Manipulator cable	5
4. Nối I/O Connector	6
5. Wiring of safety connector	7
6. Ethernet cable	8
7. JOG stick and jumper connector	9
8. Teaching pendant cable	10
2. Power Supply	11
1. Turning on the Power	11
2. Homing, teaching	11

1. Wiring


1. Complete wiring diagram

Wiring is arranged exactly as shown below



I/O controller

(Customer-supplied)



Connect to I/O connectors 1, 2, 3.

CN3 : I/O1 input

CN4 : I/O2 output


CN5 : I/O3 output

For wiring work, refer to the signal pinouts and the circuit diagram.

An input signal is detected at a rising edge of the input.

When an output becomes ON, its corresponding output port will be high.

Input Signal



I/O Cable

(Customer-supplied)


- Provide sufficient separation from high voltage lines and motor power lines.
- AWG16-24
- Take noise into account and keep the cable length within 15 meters.

Manipulator cable


Included

Cable length 3m

The manipulator cable is integrated with the junction box.



Ferrite core (included)




Do not remove any of the included ferrite cores.

The C.CODE is unique to each robot. Connect the controller with its C.CODE matching manipulator. Check the C.CODE labels on the manipulator and the controller. Only a C.CODE matching pair of them may be connected.


Safety Circuit

(Customer-supplied)



Emergency Stop Switch

Servo-ON Switch




Connect to the safety connector.

Connect an emergency stop switch or a Servo-ON switch.

Improper connections disable Servo-ON

End-Effector


(Customer-supplied)



2 Manipulator

Connect to the arm I/O connector.

End-Effector for tooling attachment




Arm I/O Connector

(customer-supplied)

Keep the current consumption of a device connecting to the Arm I/O to be no higher than 100 mA.



Connecting the Manipulator Cable

Connect the EtherCAT cable to the port "LIN" on the right



Power supply connector

EtherCAT Communication connector



2. Power cable


請用合適的電纜
Please use cables with recommended specifications.

- Rated voltage: 250 VAC
- Rated current: above 10A
- IL13 socket (without locking device)
- Outer diameter: 4.5 - 8.5 mm



Method of connecting to the power supply

In case of use in an environment with a lot of electrical noise, wrap a ferrite core as shown in the figure below around the end of the cable connected to the power source, then install a round socket with an insulating cover. For the round socket installation, choose a shape or size that fits the power supply device being used.



Caution



You must use a power cable that matches the specifications for the voltage and current used. The electrical wiring work must be carried out by a person with professional certification. There is a risk of fire or electric shock.








3. Manipulator cable (included)

The cable connecting the controller to the manipulator. Used to supply power and perform signal transmission.



Method to connect to the controller


	<p>Fully insert the connector matching the 'open' assembly symbol.</p> 
	<p>Rotate the connector housing approximately 90 degrees and lock it securely.</p>
	<p>Confirm whether it has been locked correctly.</p> 

Method to connect to the manipulator

1. Connect the power connector to the EtherCAT communication connector

2. Tighten the screws of the Junction box.
Screws: hexagonal screws (M3, 4 pieces).

3. Tighten the panel mount locking device.




Please connect the controller and the manipulator to form the correct combination. Confirm the C.CODE label of the manipulator and the controller, then connect so that the C.CODE is consistent.



4. Connecting of I/O connector

Please firmly attach the connector to the controller until the lock engages. If the connector is correctly connected, the operation lock lever on both the left and right sides should automatically lock.

Method to connect to the controller



- Keep the wiring away from high-voltage lines or motor drive cables, and use a sheathed cable.
- Use AWG16-24.
- Consider the interference and use within 15m.



Regarding turning on the servo

Turn on the side servo.

Use a mechanical inspection operation switch (contact a).

SVON

OFF (Open)

ON (Close)

OFF (Open)

5. Wiring of safety connector




Caution



Let's use the mechanical contact switch type.



Controller



The emergency stop switch must be installed in one position. Short-circuit the unused EMS input switch

If a dual electrical circuit like is not connected even on one side, it will result in an error.



Do not connect any ends.




Caution



Refer to the following and then process the cable sheath.
For handling the sheath, use a cable stripper. If the electrical cable is not properly processed, it may result in contact errors or unintended operations.



The method of stripping the cable sheath of the I/O connector and the safety



Suitable



Bent



Loose

6. Ethernet cable


Use Ethernet 0 (below) when connecting to PC or Tablet for maintenance.

Use Ethernet 1 (above) when connecting to PC for monitoring the factory network.

The cable can be used for both straight and curved lines. Use a cable on Ethernet CAT5.



- Ethernet 1** : Connecting to PC for monitoring the factory network
 IP address: 192.168.1.23
 Subnet mask: 255.255.255.0
- Ethernet 0** : Connecting to PC for teaching or maintenance (dedicated)
 IP address: 192.168.0.23
 Subnet mask: 255.255.255.0



포인트!!



Wiring connection

The cable must not be used in in contact with oil or water.

Do not allow the cable to be bent or heavily compressed
 Ensure the bending radius of the cable is the largest possible.

In case of wiring that allows the cable moves, a flexible cable must be used. Place the cable in the cable tray to minimize bending or heavy compression.

Keep as far away as possible to prevent incorrect operation due to interference when arranging signal cables and high voltage cables, high-frequency current cables in the cable tray.

7. JOG stick and jumper connector

Switch the robot's operating mode by connecting to CN 2 of the controller.


If the jumper connector is connected ...> it is remote mode (automatic operation mode)

If the JOG stick is connected...> it is teaching mode.

Remote mode (automatic operation mode)

Is the robot's automatic operation mode


Please connect the jumper connector



Teaching mode

Is teaching mode or JOG operation

Please connect the JOG stick




Except when using JOG stick, the controller's CN2 must always be connected to the jumper connector (included).



8 Teaching Pendant cable

The teaching pendant cable consists of two cables. Connect the signal cable to Ethernet 0 (below) of the controller. Connect the main cable to CN2 of the controller.








Do not connect or disconnect the cable when power is supplied to the controller. Secure the teaching pendant accurately to the controller's Ethernet and CN2 ports. Additionally, be careful not to pull or bend the cable excessively.


If teaching is completed, remove the teaching pendant from the controller and protect it from damage or malfunction due to dropping or breaking. Connect the jumper connector to CN2 of the controller unless teaching.



2. Power supply


 Caution		
	Please confirm that all wiring connections have been completed before supplying power to the controller.	
	Do not connect or disconnect any connectors while power is on.	

1. Turning on the Power




If power is supplied, the status is displayed on the controller's 7-segment display panel.

7-segment display





	Start the controller
---	----------------------

(About 10s)

	Initialize the controller
---	---------------------------

(About 10s)

Display either if initialization is complete

	Loss of ABS homing Display when ABS homing is lost when starting for the first time. Please recover the homing (*).
	Ready (= standby state) ABS homing has been recovered. Standby state
 	Error Please confirm the error code and fix the error.

2. Homing, teaching



Please refer to the user manual

C Teaching

*) Manipulator's information is lost when starting for the first time. Export in the state of losing the ABS homing's information.

NOTE



Teaching

- 1.JOG stick operation
- 2.PC access
- 3.ABS homing recovery
- 4.Teaching
- 5.Coordinate system and posture

NOTE



Teaching

1

JOG Stick Operation



1. JOG operation mode.....	2
1. What is JOG operation mode	2
2. Move and finish	3
3. Operation	4


1. What is JOG operation mode

It is the mode used to operate the JOG Stick and control the manipulator. It is not used to access the PC but can control the robot.

- The operator can safely control the robot at a distance from the robot.
- The robot can be controlled even when ABS is lost.
- The robot operates using a joint coordinate system.
- The manipulator can be easily changed using the homing posture.
- It can control the robot by axes, but cannot control multiple axes.

Item	Specifications
Control speed	5% of maximum specification speed J1 ~ J4 : 8.9 deg/s J5, J6 : 13.4 deg/s
Control range	0.25deg increments (If the controller lever is pressed, change in 5deg increments)

Name and features of parts used in the JOG operation




2. Move and finish

Move

Step 1. Access

Wiring as shown below

It is mandatory to connect the electrical circuit of the safety connector (*)
(emergency stop switch and MODE switch)



*) Refer to safety circuit

5 "5. Wiring and Power Supply" 5 "Wiring of safety connector".

Step 2. Move

Press the push switch of the JOG stick and turn on the controller.

Press continuously until the controller's
7-segment display appears

JOG

Push switch

7-segment display


111

Moving



JOG

Completed move



참고

Turn off the power of the controller.



In case an error occurs

c04

JOG operation error


Turn off and turn on the controller again.

3. Operation

Step 1. Turn on servo

Press the Enable switch


If you release or press harder the Enable switch, the servo is turned off.















Step 2. Operation

After changing the upper/middle/lower L slide switch, select the connection you want to move.

Tilt the controller lever and then move the robot.



J1,J2	J3,J4	J5,J6
<p>L slide switch</p> 	<p>Middle</p> 	<p>Bottom</p> 
<p>Controller's 7-segment display</p> 		
<p>Controller lever</p> 		
		




Confirm the working connection on the controller's 7-segment display panel and then operate the controller lever.



Step 3. Homing posture alignment

Control the JOG stick, align all joints exactly at the zero mark to create the home position posture. Home position posture (*)

(Example: ZRA4937)



*) The home position varies depending on each model. Please confirm the exact location of the zero mark. The zero mark is emphasized in this document. Please proceed according to the actual position standards.



Please align the zero mark within 1mm.



In case the JOG stick is released from the controller while the JOG stick is in operation

Stop the robot's operation.

Reconnect the JOG stick to the controller to run again
(Do not restart the controller)

NOTE



Teaching

2

PC Access



1. Connect the PC to the controller	2
1. Software preparation.....	2
2. IP address setting	3
3. Access setting	4

1. Connect the PC to the controller

1. Software preparation

Prepare the two following software



「FFFTP」: FTP client software

Use FTP (File Transfer Protocol) to transmit files between the PC and the controller.

URL <https://osdn.net/projects/ffftp/>

Select 32-bit or 64-bit versions depending on the computer used. When installing, use the original settings.

(FFFTP is a product of FFFTP Project)



「FFFTP」: FTP client software

Use FTP (File Transfer Protocol) to transmit files between the PC and the controller.

URL <https://osdn.net/projects/ffftp/>

Select 32-bit or 64-bit versions depending on the computer used. When installing, use the original settings.

(FFFTP is a product of FFFTP Project)

1 Connect the PC to the controller

2. IP address setting

Set up the network of the access PC with the controller.

IP address of PC:
192.168.0.xx (xx: other than 23)




Controller

Connect to below (Ethernet 0)
IP address of Controller:
192.168.0.23


Step 1

Click on “Ethernet” of the “Network and Internet” on the control panel.



Step 2

Click on “Change adapter options” of “Ethernet”, right click on the ethernet icon and then click on Properties.



Step 3

Click on Properties of internet protocol 4 version (TCP/Ipv4).




Step 4

Set up IP address and subnet mask as follows:

IP address (I)	192.168. 0. XX
Subnet mask (U)	255.255.255. 0

(XX: set with a number other than 23)




(Above example is for Windows 10)


1 Connect the PC to the controller

3. Access setting

Set up the two following software to access the controller.

 「FFFTP」Run FFFTP


New Host... Click on new host and set up host.



Host setting

Profile Name	i611
Host Name/Address	192.168.0.23
Username	i611usr
Password/Phrase	i611

Connect Click to Connect

 「Tera Term」 Run 「Tera Term」


Host setting

Host (T)	192.168.0.23
Service	Telnet
TCP Port # (P)	23

(The controller's power must be turned on)

Controller confirmation

login	i611usr
Password	i611



(Above example is for Windows 10)



C. Teaching

3

ABS Homing



1. Notes	2
2. Order	3
3. Confirmation	4



It is essential to return to the ABS home position when connecting the power supply to the Robot for the first time.

Ensure all joints are aligned to the zero mark (illustrated mark) using the JOG operation.

Align the zero mark within a range of 1 mm.

The servo must be turned on during the process of ABS homing. Connect the servo ON switch to the JOG stick first.




Homing should only be done once when unpacking. It is not necessary to do it frequently.

Step 1 Adjust the home position of the manipulator

Operate the JOG stick to precisely align all axes to zero mark to create the homing posture.



1 Operate the JOG stick

**Step 2** Activate the Robot software `enc_reset.py`

Connect to the controller by Telnet

Activate the software to ABS homing

In case all joints are performed consistently

\$`enc_reset.py`

In case of indicating joint

Add joint number into blank space

\$`enc_reset.py` 56 ← In case of joints 5, 6

Confirmation message is displayed

Target Joint(s) : All ← In case all joints are performed consistently

OK? [Y/n] Y ← Enter "Y" (in uppercase)

Message displays

Reset target = 3F ← In case all joints are performed consistently

Please turn servo power on to continue

When the servo is turned ON, the confirmation message is displayed.

Enter Y to turn servo power off

Ready? [Y/n] Y ← Enter "Y" (in uppercase)

Message displays

Please adjust each joint position to the bar label.


Done? [Y/n] Y ← Enter "Y" (in uppercase)

Message displays

[OK] Reset encoder success!

Please reboot controller...


Reboot the controller



Example: ABS homing consistently

Turn servo power ON

Press Enable switch

**Step 3** Reboot the controller

When the ABS homing is completed, the rdy display of the controller appears.



about 10 sec.



about 10 sec.



Complete !



3. Confirmation



After ABS homing is completed, please ensure to check if the ABS homing is performed correctly according to the method below?



Step 1 Run the confirmation program confirm_home.py

Connect to the controller by Telnet

Run the confirmation program

```
$confirm_home.py
```

While pressing the Enable switch on the JOG stick, perform confirm_home.py

The confirmation message will be displayed

Are you ready to move? (y/n) y

Enter "y" (in lowercase)

When you enter "y" and press Enter, all joints will return to the zero mark of each joint.

The manipulator's speed of confirm_home is 1%.

J1~J4 : 1.8deg/s

J5, J6 : 2.7deg/s

The confirmation message will be displayed when the operation is complete.

Position OK? (y/n) y

Enter "y" (in lowercase)

```
192.168.0.23 - Tera Term VT
$ enc_reset.py
```

```
192.168.0.23 - Tera Term VT
$ confirm_home.py
Target Joint(s): All

New target (SN=*****):
initial_offset = [0,0, -775680, 0, 0, 0]
adjust_offset = [0, 0, 0, 0, 0, 0]
move_pulse = [0,0, -775680, 0, 0, 0]
Current Pls: [xxx, xxx, xxx, xxx, xxx, xxx]
Target Pls : [0,0, -775680, 0, 0, 0]
Are you ready to move? (y/n) y
```


```
adjust_offset = [0, 0, 0, 0, 0, 0]
move_pulse = [0,0, -775680, 0, 0, 0]
Current Pls: [xxx, xxx, xxx, xxx, xxx, xxx]
Target Pls : [0,0, -775680, 0, 0, 0]
Are you ready to move? (y/n) y
Position OK? (y/n) y
```

Step 2 Confirm after performing confirm_home.py


Please check if the position of zero mark of all joints is correct?

Example after performing confirm_home.py

Successful



Unsuccessful







Is the zero mark misaligned?

1. Simple operations.	2
1. Operating mode.	3
2. Preparations.	4
Connect to the training computer.	4
Pitch and movement speed settings	5
3. Jog motion method of power-assisted lifting arm	6
4. Training screen.	9
Teach Main screen	10
Menu Button	11
Coord ▾ Tool ▾ Base ▾ Speed ▾ Buttons.	12
Pitch1 Pitch2 Speed Buttons	13
Pos&Param Expand Buttons	13
Copy Adjust Replace Buttons	14
OUT24 ... OUT49 Buttons	15
Error/warnings information.	15
Move To screen	16
Direct Move Hand Homing Hand Alignment Buttons	17
M.SPD ▾ M.Type ▾ Buttons	17
Position coordinate settings.	18
Teaching data operations.	18
Control panel	19
MDI Screen	22
Monitor Screen.	23
2. Teaching order	24
Move to the original coordinates using 「Hand Homing」	25
Move robot using 「Direct Move」	26
Move robot using 「Hand Alignment」	29
Save coordinates data	31
Recover from unmovable point.	32
3 Transfer teaching data	34
1. Transfer from the control panel to PC	34
2. Transfer from PC to the control panel	35



ATTENTION

	<p>When operating the power-assisted lifting arm for the first time, <u>Always choose the common coordinate system..</u></p> <p>After confirming that there are no obstacles within the operating range of the power-assisted lifting arm, proceed with the Jog operation.</p> <p>Keep your eyes on the power-assisted lifting arm during the Jog operation. In case of emergency, stop the power-assisted lifting arm by pressing the emergency stop switch on the JOG stick</p>	
	<p>Do not turn off the control panel while the power-assisted lifting arm is operating.</p>	

1 Simple operations


1.Simple operations

The operating mode of the robot is switched by connecting the CN2 connector of the controller


Teaching mode (JOG stick))

This is the mode to perform Jog operations or teaching

Please connect the JOG stick



JOG stick
(optional)



Control panel

Teaching mode (Teaching screen)


Connect to the teaching screen.



Teaching screen
(optional)

Connect the Ethernet 0 communication cable

Connect the main cable




Control panel


Remote mode (autonomous operating mode)

This is the mode to perform automatic operations of the robot.

Please connect to the jumper connector



jumper connector
(accessory)



컨트롤러



Always connect to the jumper connector, unless when using the JOG stick or the teaching screen



1 Simple operations


2. Preparations

Connect to the teaching computer

Start a web browser (Google Chrome) in Incognito mode.


Enter the connect address and run the teaching screen.

Step 1 Start a web browser in Incognito mode. .




Step 2 Connect the control panel and PC..

Connect LAN cable to Ethernet 0.



Ethernet 0

Below : 192.168.0.23 . . .




Enter the follow address to the browser

Connect address to the control panel

<http://192.168.0.23>

When connect to the control panel, the index screen appear




When the JOG stick is unable to connect

Teaching is impossible.

Return to the index screen .

After connect to the JOG stick, please press the Teach Main symbol.



Pitch and movement speed settings

Pitch and movement speed settings of the power-assisted lifting arm when operating 1 time on the JOG stick



Continuous motion setting (constant speed)

Continuous operation when the JOG stick control is tilted.

- Speed** Press the Sped button to select..
 - ▲ ▼ Adjust Jog operation speed(%) using the slider or the up down buttons
- Speed** The maximum speed (100%) is as follows .

World coordinate system	XY	80 mm/s
Common coordinate system	Joint	J1~J4 5.3 deg/s J5 ,J6 8.0 deg/s
- OK** Click OK to return to the Teach Main screen

Movement level of Pitch setting

Tilt the JOG stick control one time to create a determined amount of movement. .

Pitch1 **Pitch2** Press Pitch1 or Pitch2 button to select

Pitch movement amount can be set separately in the common coordinate system and the world coordinate system / **XY** Coordinate system can be changed using Joint button or XY

Two types of Pitch movement levels can be set for each joint Pitch1 and Pitch2

- Choose a joint you want to set and input it using PC keyboard or the 10-button panel. Setup the range
 - Common coordinate system : 0 ~ 2 [deg]
 - World coordinate system : 0 ~ 10 [mm]

OK Click OK to return to the Teach Main screen

Pitch & Speed Joint

보충

Pitch 1	Pitch2
J1: 2	J1: 1
J2: 2	J2: 1
J3: 2	J3: 0.5
J4: 2	J4: 0.5
J5: 2	J5: 0.25
J6: 2	J6: 0.25

Speed Pitch movement speed according to option Pitch 1 or Pitch 2

Input using PC keyboard

Choose the joint you want to set and input a value directly by pressing Enter on the PC.

Input using 10-button panel

Choose the joint you want to set, press the **Edit** button and input a value using 10 buttons.

Close button (X icon)

BS Backspace button

Ent. Enter

3. Jog operating method of the power-assisted lifting arm .




When the teaching screen is displayed and completes settings on operation amount and speed, you can perform Jog operations of the power-assisted lifting arm. Operations of the power-assisted lifting arm can be operated by using “JOG stick” or “control panel”.

Method 1 Using JOG stick

 P.7

Pull the R stick of the JOG stick to “High”

(Control panel on the teaching screen is not displayed.)





Method 2 Using the control panel

 P.8

Pull the R stick of the JOG stick to “Medium” and “Low”

(The control panel of the teaching screen is displayed. Operation of the control handle of the JOG stick and the L stick is not shown.)




1 Simple operations

Method 1 Using the JOG stick



Use the JOG stick (optional) to control the operations of the joints of the power-assisted lifting arm. Move Jog back to the original position or use during teaching.




Step 1 Pull sliding switch R to “High”.

Step 2 Press Enable switch to turn on the servo.

Step 3 Tilt the control handle to perform Jog operations.

Pull sliding switch L to choose the joint you want to operate.



Common coordinate system

(Display “Joint” on the teaching screen)

Joint J1, J2

Sliding switch L
High

Current Position	
J1:	0.000
J2:	0.000
J3:	0.000
J4:	0.000
J5:	0.000
J6:	0.000

Joint J3, J4

Medium

Current Position	
J1:	0.000
J2:	0.000
J3:	0.000
J4:	0.000
J5:	0.000
J6:	0.000

Joint J5, J6

Low

Current Position	
J1:	0.000
J2:	0.000
J3:	0.000
J4:	0.000
J5:	0.000
J6:	0.000

World coordinate system

(Display “XY” on the teaching screen)

Axis X, Y

High

Current Position	
X:	0.00
Y:	0.00
Z:	0.00
Rx:	0.00
Ry:	0.00
Rz:	0.00

Axis Z, Rz

Medium

Current Position	
X:	0.00
Y:	0.00
Z:	0.00
Rx:	0.00
Ry:	0.00
Rz:	0.00

Axis Ry, Rx

Low

Current Position	
X:	0.00
Y:	0.00
Z:	0.00
Rx:	0.00
Ry:	0.00
Rz:	0.00

1 Simple operations

Method 2 Using the control panel



The control panel operates each joint by using the operating buttons placed on the teaching screen of the PC.



Step 1 Pull sliding switch R to “Medium” or “Low”

Operating UI display on the teaching screen.



Step 2 Press the Enable switch to turn on the servo.

Step 3 Choose the coordinate system you want to operate on and press the stick button to perform Jog operations.



When the control panel is activated, the operations of JOG stick control handle and sliding switch L is not used



Common coordinate system








World coordinate system



4. Teaching screen

Press the switch buttons on the Teach Main screen to switch screens



1 Simple operations

Move To screen


Control panel

MDI screen

Monitor screen

Teach Main screen

This is the main screen of the teaching activity. Setup and change the teaching data, setup the Jog operating speed, setup and change the coordinate system and adjust the offset.



A Change Menu and screens

Menu P.11	Move To P.16	MDI P.22	Monitor P.23
Display the Menu screen	Change to Move To screen	Change to MDI screen	Display Monitor screen

B Display and setup P.12

Coord Joint	Tool ---	Base ---	Speed 50%
Change coordinate system	Select Tool offset	Select Base offset	Setup Jog operation speed

C Change Jog operation Mode P.13

Pitch1	Pitch2	Speed
Pitch mobile mode		continuous operation mode

D Filter teaching data P.13

Pos&Param	Expand
Change display category	Change expand display

E Interact to coordinate data, teaching data P.14

Copy	Adjust	Replace
Copy the displayed coordinates to clipboard	Display coordinate values right before TURNING OFF servo	Save coordinate data

F Output port activity P.15

OUT24 . . . OUT49
Control the user I/O port

G Coordinate information

C : coordinate system	T : Tool Offset setup value
B : Base Offset setup value	
H : Posture	CC : cross counter

H Error/warning information P.15

Display the content in the text inbox
Clear Clear text

I Display comment

Display the comment inputted to the data
--

J Control panel P.19

Is displayed when change the sliding switch R on the JOG stick to "Medium" or "Low". You can control Jog power-assisted lifting arm using the operating buttons displayed on the screen...

Move To screen

Control panel

MDI screen


Monitor screen

Teach Main screen

A

Nút Menu

Offset settings



① Select Offset setup


Tool Offset : Tool Offset setup

Tool Offset is set according to the end-device, with Top Flange center set as the original point.

Base Offset : Base Offset setup

With Bottom Flange center as the original point, from the world coordinate system set the Base offset appropriately to the state of the power-assisted lifting arm

(Offset has set an option using ,)




② Select and input into each setup field.

Select the axis you want to setup and input using PC keyboard or a 10-button panel.

Select the axis you want to setup and input a value directly by pressing Enter on the PC keyboard.

Select the axis you want to setup and input a value by pressing the Edit button and input a value using 10 buttons



Close button

Backspace button

Enter button

③ OK

Click OK to complete the setup.



Color of the buttons on the teaching screen

Identify colors according to function groups.

Orange: Action groups

Blue: Setup and menu groups

Light blue: Edit group (have only edit functions)

Purple: Select option group

Yellow: Important operations group

The symbol ▼ next to a button



When you press a button with the symbol ▼ a popup will show. To close the window, press the button with the symbol ▼ again.

Purple button



The second purple button displays the selected option.

Move To screen

Control panel

MDI screen

Monitor screen

Teach Main screen

B

Coord
JointTool
----Base
----Speed
50%

Buttons

Coord
Joint

Switch coordinate



Select a coordinate system when moving the power-assisted lifting arm

The current position of the power-assisted lifting arm displayed in Current Position is also switched to the selected coordinate system screen.

XY : World coordinate system (orthogonal coordinate system)

((Include Base coordinate system, Tool coordinate system and user coordinate system))

Joint : Common coordinate system

Tool
----Base

Select Offset

Change Offset setup

Tool

: Select Tool Offset

With Top Flange center set as the original point, select according to The installed end-device. .

Base

: Select Base Offset


With Top Flange center set as the original point, select according to the setup state of the power-assisted lifting arm from the world coordinate system.

• Select Tool Offset or Base Offset will automatically switch to the Tool coordinate system or the Base coordinate system.


Please select 「----」 when deleting Offset.

• This button can be used in the Teach Main screen and the Move To screen

Tool offset



Base offset

Speed
50%

Speed setup

Set movement speed or movement amount of the power-assisted lifting arm when operating once on the Jog stick.


• For example: You can use independently, Pitch 1 for large movement and Pitch 2 for small movement (accurate positioning).

The maximum of Speed (100%) is as follows

World coordinate system **XY** : 80 mm/s

Common coordinate system **Joint** : J1~J4 5.3 deg/s
J5, J6 8.0 deg/s





C Pitch1 Pitch2 Speed Buttons

Change Jog operation mode.

Speed : continuous operation mode
 Move continuously while the handle of the JOG stick is tilted.

Speed Speed according to the setup.

Pitch1 Pitch2 : Pitch move mode
 When the handle of the JOG stick tilt once, a determined amount of movement is made.

Speed is according to the setting values **Pitch1 Pitch2**

Reference P.5 to know the operate level and speed setup method..

D Pos& Param Expand Buttons

Teachdata screen Change display category of the Teach Data screen

Filter 1 : **Pos& Param** Change displayed data

Click → Click → Click → Click

Pos& Param → Position → Joint → Param

Displayed data

- Position Data
- Joint Data
- Param Data

Position Data

- pos1[0] Home position
- pos2[0]
- pos3[0]
- pos4[0]
- pos5[0]
- pos6[0]
- pos7[0]
- pos8[0]
- pos9[0]
- pos10[0]
- pos11[0]
- pos12[0]

Position Fold

Joint Data

- joint1[0] Home position
- joint2[0]
- joint3[0]
- joint4[0]
- joint5[0]
- joint6[0]
- joint7[0]
- joint8[0]
- joint9[0]
- joint10[0]
- joint11[0]
- joint12[0]

Joint Fold

Param Data

- param[0]
- param2[0]
- param3[0]
- param4[0]

Param Fold

화면 예시

Filter 2: **Expand** Change layout display

Expand ↔ Click ↔ Fold

Expanded layout

- pos1[0] Home position
- pos1[1] Picking point1
- pos1[2]
- pos1[3]
- pos1[4]
- pos1[5]
- pos1[6]
- pos1[7]
- pos1[8]
- pos1[9]
- pos2[0]
- pos2[1]

Expand

Fold layout

- pos1[0] Home position
- pos2[0]
- pos3[0]
- pos4[0]
- pos5[0]
- pos6[0]
- pos7[0]
- pos8[0]
- pos9[0]
- pos10[0]
- pos11[0]
- pos12[0]

Fold



Copy
Adjust
Replace
Buttons


Copy

Copy a displayed coordinate value

Replace

Save positional data

Save the coordinate of the current position screen into a selected teaching data in the teaching data screen.




Confirm message window

Adjust

Adjust and save positional data.

Use the edit current position function (*) to save a selected teaching data on the teaching data screen

*) the add coordinate value function right before TURNING OFF the Servo



Confirm message window



Do not turn off the power of the control set during saving the data.

10%




The case of mismatch coordinate system

Current position screen

If the coordinate system displayed on the screen is different from the coordinate system of the saved training point, an error message will appear.
After aligning the coordinate systems, please save..

Clear Warning : Unreachable point.





F OUT24 ... OUT49 Buttons


Operate output ports...

Control registered output ports.
(Port No.16 ~ 31)

Output state is represented using text colors.

Black text: OFF state for output port


Yellow text: ON state for output port



II Error/warning information

If a warning occurs during the teaching process, a notification will be shown.

Clear : Clear message



Display	Meaning
Warning - Angle limit over	The operate position of the target exceeds the operating range ($\pm 240^\circ$)
Warning - Unreachable point	Go through an unreachable point during Direct Move
Warning - Area over	Exceeds movement range ($\pm 240^\circ$) during Direct Move
Warning - Speed over	Upper speed limit of the teaching mode has been exceeded.

1 Simple operations

Teach Main screen


Control panel

MDI screen

Monitor screen

Move To screen

Have the Operation "Direct Move" to move directly to a saved teaching point and the Operation "Hand Homing" to move to the original position..



A Select operation P.17

<p>Direct Move</p> <p>Operate displayed position on the screen. Instructive position/parameter</p>	<p>Hand Homing</p> <p>Return each axis to the original position. Move to the 0° position on each axis</p>	<p>Hand Alignment</p> <p>Perform the operation Hand alignment.. Adjust the direction of the end-device according to the vertical direction or the horizontal direction.</p>
---	--	--

B Display and setup P.17

<p>Coord ▾ Joint</p> <p>Change coordinate system.</p>	<p>Base ▾ ----</p> <p>Select Base Offset .</p>	<p>M.SPD ▾ 50%</p> <p>Set working speed of Direct Move.</p>
<p>Tool ▾ ----</p> <p>Select Tool offset..</p>	<p>Speed ▾ 50%</p> <p>Setup Jog operation.</p>	<p>M.Type ▾ Linear</p> <p>Select operation method of Direct Move .</p>

C Setup coordinate position P.18

<p>TBH</p> <p>Setup Tool Offset, Base Offset and posture.</p>	<p>CC</p> <p>Setup cross counter..</p>
--	---

D Teaching data operation P.18

Cur. Copy

Copy current coordinates.

E Exit Move To screen

Exit

Return to Teach Main screen.

F Control panel P.19

Is display when the sliding switch R of the JOG stick is placed in the "Medium" position or the "Low" position. Can control the power-assisted lifting arm using the operation buttons on the screen.

The Operation panel on the Teach main screen is also similar

1 Simple operations



Teach Main screen Control panel MDI screen Monitor screen

Move To screen

A Direct Move Hand Homing Hand Alignment Buttons

Direct Move Move to the coordinate displayed on the Target Data screen.

P.26 Operate of the robot using 「Direct Move」

Hand Homing Move the power-assisted lifting arm to the original position

P.25 Move back to the original coordinate using 「Hand Homing」

Hand Alignment Perform operations of hand adjust..

P.29

B M.SPD ▼ 50% M.Type ▼ Linear Buttons

M.SPD ▼ 50% Direct Move Hand Homing Hand Alignment Use Direct Move, Hand Homing, Hand Alignment. to setup working speed

M.SPD ▼ 100% of MSPD is based on the speed of the move axis on the longest distance, as follows:

M.Type ▼ Linear : 80mm/s M.Type ▼ PTP J1~J4 : 5.3 deg/s
J5, J6 : 8.0 deg/s

M.Type ▼ Linear Setup automatic mode.

Coord ▼ XY Select movement mode to move between 2 points in the world coordinate system.

- M.Type ▼ Linear : Linear interpolation operation
- M.Type ▼ PTP : PTP operation
- M.Type ▼ PTP(C2) : PTP operation (C2= Use information of the cross counter set)



When the coordinate system of the target position does not match the selected coordinate system

Display a dialog. The coordinate system is inconsistent.

Direct Move

Even when you press Direct Move

the power-assisted lifting arm cannot operate for safety reasons.

Coord ▼ Joint

After selecting the coordinate system with

Coord Joint

Direct Move

Please press Direct Move again

When move to the target position... . . .

1) When reach the target position

An incoming inbox dialog is displayed..

(The displayed notification is different in Direct Move and Hand Homing)

2) When you miss the control handle or the Enable switch of the JOG stick while operating

The operation is cancelled.

(A notification dialog Abort appears.)

3) When go through an unmovable point

Stop the operation. (A notification dialog Unreach appears.)

1 Simple operations



Teach Main screen

Control panel

MDI screen

Monitor screen

Move To screen

C Setup positional coordinates

TBH

Setup Tool offset, Base offset and posture. .

T : Tool offset

Select according to the end-device. Setup value: "-" (cancel setup), "1" ~ "7"

B : Base offset

Select according to the setup state of the power-assisted lifting arm. Setup value: "-" (cancel setup), "1" ~ "3"

H : Position

Select according to the position of the power-assisted lifting arm. Setup value: "0" ~ "7"



CC


Setup cross counter.

Rotation information from J1 to J6 is recorded according to 0° of each axis, regardless whether the axis rotates in the direction – or the direction +..


-1 : Rotate more than 180° in the direction -

0 : Do not rotate

1 : Rotate more than 180° in the direction +

If you do not use the information of the cross counter, please select ☒ No Information

The case of not using the information of the cross counter



D Operations on teaching data

Cur.
Copy

Copy current coordinate

The coordinate of the current position screen is copied on the target position screen..



When save as teaching data, make edits on the MDI screen.

The target position modified in the Move To screen is for confirming movement and should not be reflected in the training data

1 Simple operations

Teach Main screen


Move To screen

MDI screen

Monitor screen

Control panel

Can be used to control the power-assisted lifting arm using the operation panel instead of the JOG control lever. Can setup operation board, check error codes, verify “posture” of the power-assisted lifting arm and check the definition of the coordinate system and common axes.



1 Simple operations

Teach Main screen

Move To screen

MDI screen


Monitor screen

Control panel

Control board description

XY Joint Change coordinate system

Press and hold the button (about 1 second) to change.



Coord Joint link to the coordinate system set by the Coord Joint button.


UP DW Change movement speed

For each button press, Setting changes to "1%, 3%, 5%, 10% 15%, 20%, 30%, 50%"...

Operation speed when set into 100%

world coordinate system XY : 80 mm/s

common coordinate system : J1~J4 5.3 deg/s
J5 J6 8.0 deg/s



Display current setup.



Axis control buttons

Display change buttons depending on select coordinate system..

Common coordinate system Nut J1- ... J6+

Orthogonal coordinate system Nut X- ... Rx+


Button operations

Quick press: perform 1 time Pitch movement
Hold press: continuous movement

offset Display offset information

Display setting values of Tool offset, Base offset .

Offset is set using buttons



Orthogonal coordinate system



Common coordinate system

1 Simple operations

Teach Main screen

Move To screen

MDI screen

Monitor screen

Control panel

Settings

Setup operation control panel

Screen:

Switch between full screen display and normal screen display.

Layout:

Change button position..

Language:

Change display language of the error code list..

「English」 「Japanese」 「Chinese」

Interval Appearance:

When an operation occur, set the display mode of the current operation invalid before accepting the next operation. .

Interval 1: Display the window 「Data in Process...」 .

Interval 2: Display a dimmed screen.



Error Code

Display error code list.

Detailed information about the errors can be changed to English, Japanese and Chinese.




Posture

Display “posture” of the power-assisted lifting arm.



Angle

Display the axis angle definition or the common axis of the power-assisted lifting arm



Teach Main screen

Move To screen


Control panel

Monitor screen

MDI screen

MDI = [Manual Data Input]

Change selected teaching data.



Step 1 **Teach data** Select the teaching data you want to make changes in the teach data screen.

Click : Select data

Double click to the background : Input description (32 characters max).

Step 2 **Import the Position data.**

The coordinate values of the teaching data selected in the previous data are displayed before the screen changes.

Input using PC keyboard

Select the axis you want to set and enter the value directly by pressing the Enter key on the PC keyboard.

Input using 10-button panel

Select the axis you want to change and input the value using the PC keyboard or a 10-button panel.

Step 3 **Register position data**

Replace

Save position data

Replace the selected teaching data with position data from the Change Data screen.

포인트



Number of teaching points that can be set

Data	Display	Points
Orthogonal coordinate system data	pos1[0] ~ [9] ... pos20[0] ~ [9]	200
Common coordinate system data	joint1[0] ~ [9] ... joint20[0] ~ [9]	200
Parameters data	param[0] ~ [9] ... param4[0] ~ [9]	40

1 Simple operations

Teach Main screen

Move To screen

Control panel

MDI screen

Monitor screen

Monitor different data such as coordinates of the power-assisted lifting arm and I/O. It is possible to perform Jog operations or output port operations during monitoring.

Display Change

Change the display items




Select display items from physical I/O, current control set position, version information, and OSS license information.

Physical I/O

Physical I/O

Monitor physical I/O ports.

Operate by using **ON** **OFF** buttons output state.



Current Position

Display current position of the power-assisted lifting arm

Three types of information are displayed on the screen: world coordinates, common coordinates, and encoded pulse set.



Version

Version information


Display version of each software on the system



OSS License

OSS license information

Display license information for open-source software used in this product



2. Teaching order

Teaching progress

Connect the robot to the teaching PC perform teaching after completing the setup of movement amount and speed. Perform teaching on the movement coordinates of the robot and operations in Hand Homing, Direct Move, Hand Alignment, etc. After confirming the training points, save the coordinate data as training data.

Hand
HomingDirect
MoveHand
Alignment

Move back to the original coordinate using “Hand Homing”

 P.25
Hand
Homing

Restore the power.

Move the robot using 「Direct Move」

 P.26
Direct
Move

Move the power-assisted lifting arm to a set position..

Move robot using 「Hand Alignment

 P.29
Hand
Alignment

Orient the terminal vertically or horizontally.

Save coordinate data

 P.31

Save the current coordinate value of the power-assisted lifting arm as teaching data.


Recover from an unmovable point

 P.32

Exit the power-assisted lifting arm from an unmovable position...

Note: Jog, Direct Move, and Hand Alignment operations cannot be performed on in the orthogonal coordinate system at the original position.

original position



Axis values

J1 = 0 deg

J2 = 0 deg

J3 = 0 deg

J4 = 0 deg

J5 = 0 deg

J6 = 0 deg

The original position is a position that cannot be operated with the world coordinate system due to the structure of the power-assisted lifting arm. Individual operations of J1~J6 are performed through swivel movements in the joint coordinate system, or exit the robot through direct movements in the joint coordinate system

Direct
Move
 P.32

Recover from an unmovable point

Move to the original coordinate using "Hand Homing"

Hand Homing : Recover the original point

Step 1 Set the move speed.

In the Teach Main screen **Speed** Click Speed .


Speed ▾
10%

Check if the speed is set to 10%..

It is recommended to use an operating speed of around 10%..
In case of accelerating operation, please operate after ensuring full safety confirmation..


Speed ▾ 100% of Speed is based on the speed of the longest travel distance of the axis .

J1 ~ J4 : 5.3 deg/s J5, J6 : 8.0 deg/s



Step 2 Hand Homing Click Hand Homing.

Turn on servo



Step 3 Start moving .



When use the Jog stick


If the control handle of the control set is tilted then start moving.

Tilt the handle of the control set in any direction.

Only move when tilted

【Stop】: Release the control handle.

Complete]: Notify the completion using a popup screen




When use the Control Panel

Start Hand Homing

Press the button Start Hand Homing to start moving.

【Stop】 **Cancel** Press Cancel.

【Complete】 : Notify the completion using a popup screen.



Move to the original coordinate using 「Hand Homing」

Move robot using
「Hand Alignment」Save coordinates
data

Recover from unmovable point

Move robot using 「Direct Move」

Direct
Move

: Operate the control set back to a preset position.

Step 1 Select or input a target position.


- When register teaching data :

→ file: Select target position from Teach_data .

- When change teaching data or When set up

a new target position :

→ Select target joint for Target Data .



Input using PC keyboard

Press Enter on the PC keyboard to input a value directly...

Input using 10-button panel

Edit Press Edit to input a value using 10-button panel.

- When setup Tool offset, Base offset and posture: :

→ TBH Press TBH to select a parameter.

T: Tool offset

Select an end-device. Setup value: "-" (cancel setup), "1" ~ "7"


B: Base offset

Select according to the setup status of the power-assisted lifting arm. Setup value: "-" cancel setup, "1" ~ "3"

H: posture

Select according to the posture of the power-assisted lifting arm.

Giá trị cài đặt: "1" ~ "7"





- When setup the cross counter (*1): :

→ CC Press CC set up the values below within the angular range of each joint from J1 to

Setup value	Angle of each joint
1	180° ~ 540°
0	-180° ~ 180°
F (*2)	-540° ~ -180°

When not using the information of the cross counter,

Please select: ☒ No Information

In case the cross counter information is not used

*1) The cross counter is set up to convert Position data into characteristic Joint angle data. Setup multiturn arguments of the Position data.

For details, please refer to

software Robot Library

*2) On the training screen, setting "F" will display "-1"

Move to the original coordinate using 「Hand Homing」

Move robot using
「Hand Alignment」Save coordinates
data

Recover from unmovable point


Move robot using 「Direct Move」

Step 2 : Select coordinate system, operation method and speed.

Coordinate system :

Synchronize selected teaching data to the coordinate system you want to operate on..

- Coord ▼
XY World coordinate system
- Coord ▼
Joint Common coordinate system



Operation method :

- Coord ▼
XY Select movement mode between 2 points in the world coordinate system.
- M.Type ▼
Linear Linear interpolation
- M.Type ▼
PTP PTP operation
- M.Type ▼
PTP(C2) PTP operation (C2= use cross counter information)

Movement speed

Adjust movement speed (%) using a slider or the buttons "Up" "Down"

100% of Speed is based on the speed of the longest travel distance of the axis and is calculated as so:.

M.Type ▼
Linear 80 mm/s

M.Type ▼
PTP J1~J4 : 5.3 deg/s
J5, J6 : 8.0 deg/s


Next page



The coordinate values and offset information set in the MoveTo screen are temporary settings for operation verification purposes. They should not be reflected in the training data

Move to the original coordinate using 「Hand Homing」

Move robot using
「Direct Move」Save coordinates
data

Recover from unmovable point

Move robot using 「Direct Move」 (detailed)

Order 3 Direct Move Click direct move.

Turn on servo.



Order 4 Start movement.



When use the JOG stick


If the control handle of the control set is tilted then start moving.

Tilt the handle of the control set in any direction.

Only move when tilted.

【Stop】: Release from the control set handle.

【Complete】: Notify the completion using a popup screen




When use an operation panel

Start
Direct Move

If press this button then start moving.

【Stop】: Press cancel.

【Complete】: Notify the completion using a popup screen.



Move to the original coordinate using 「Hand Homing」

Move robot using 「Direct Move」

Save coordinates data

Recover from unmovable point

Move robot using 「Hand Alignment」


Hand Alignment

: Align the orientation of the end effector horizontally or vertically.

Hand Alignment

Click Hand Alignment.

Turn on servo.



Order 2

Start moving.



When use the JOG stick


If the control handle of the control set is tilted then start moving.

Tilt the handle of the control set in any direction.

Only move when tilted.

【Stop】 : Release from the control set handle..

【Complete】 : Notify the completion using a popup screen




When use the operation panel

Start Hand Alignment.

If press this button then start moving

【Stop】 Press cancel.

【Complete】 : Notify the completion using a popup screen.



Move to the original coordinate
using 「Hand Homing」

Move robot using 「Direct Move」

Save coordinates data

Recover from unmovable point

Move robot using 「Hand Alignment」




Explain the Hand Alignment operation

Hand Alignment is an operation that maintains the position coordinates (x, y, z) of the end effector flange and adjusts the orientation of the end effector flange. The direction of the Hand Alignment operation varies depending on the orientation of the end effector flange.

Pattern 1

When end effector Flange is near the downwards direction




Pattern 2

When end effector Flange is near the direction of the plane



Pattern 3

When end effector Flange is near the upwards direction



Save coordinates data

Current position screen Save coordinates value of the current position screen using teaching data.


Order 1 Select teaching data of the intended subject.

When you are in the Move To screen, click Exit to return to the Teach Main screen.

Exit

For example : Save the coordinates of the current position screen on pos1[0].


Teach Main screen



Order 2 Replace Click replace.


Save the coordinates of the current position on pos[0].

Display on a popup screen.



OK Click ok to save.

If you are done with saving then the popup screen will close.



Move to the original coordinate using
[Hand Homing]

Move robot using
"Direct move"

Save coordinates data

Recover from unmovable point

Restore the power-assisted lifting arm from the non-operational position.

Method 1 Using the JOG stick

Coord
Joint

Control individual joints J1~J6 using the JOG stick in a joint-connected coordinate system Coord Joint, and move the power-assisted lifting arm to an operable position (a position that is not at the limit of the orthogonal coordinate system)

Order 1 Select a joint using the sliding switch L of the JOG stick.

Order 2 Turn on the servo.



Order 3 Tilt the handle of the control set, control the power-assisted lifting arm then move the power-assisted lifting arm to a controllable position.

Example: controllable position



Posture image


Adjust J1~J6 to have a similar posture to the drawing on the left.

Please confirm the angular positions of the joints at the current position screen before proceeding with the movement.

Example) value of joints

J1 : 0 deg
J2 : -20 deg
J3 : -100 deg
J4 : 0 deg
J5 : -60 deg
J6 : 0 deg


Move To screen



Joint operation methods



Joint J1, J2

Switch L
Above






Joint J3, J4

Switch
Middle



Joint J5, J6

Switch L
Below



Move to the original coordinate using
[Hand Homing]

Move robot using
"Direct move"

Save coordinates data

Recover from unmovable point

Method 2

Move using Direct Move at the teaching point of the joint coordinate system

Direct
Move

The world coordinate system stores the movable positions at the teaching point of the joint coordinate system (e.g., Joint1 [0]). Even if you are at a non-operational point in the world coordinate system during teaching, after switching to the joint coordinate system, you can easily restore by moving with Direct Move.

Direct
Move

After recover, you can change to the world coordinate system and rerun teaching.

For example: Register movable point at Joint1 [0] .




Posture image

Example value of joints

J1 : 0 deg
J2 : -20 deg
J3 : -100 deg
J4 : 0 deg
J5 : -60 deg
J6 : 0 deg

Move To screen



Use the joint coordinate system to avoid the non-movable points in the world coordinate system.

World coordinate system

There are immovable points depending on the posture, even within the operating range.

Joint coordinate system

Is able to move freely within the operating range.

If you encounter an unmovable point of the power-assisted lifting arm while operating in the world coordinate system Coord XY, Direct Move cannot be used. Switch to the joint coordinate system Coord Joint, use Direct Move, individually operate J1~J6 using the JOG stick, and then move from the unmovable position.

Coord
XY

Coord
Joint

Direct
Move

Direct
Move

3. Transfer teaching data

1. Transfer from the control set to PC



It is recommended to backup the teaching data into a PC.

The teaching data is stored into the control set.

It is possible to integrate the operation programs or teaching data of the robot in case of replacing the control set..


Order 1

「Run FFFTP」.



Save location of teaching data and file name


Save path	/home/i611usr
File name	teach_data








Order 2

Transfer file to PC .

Click upload



2. Transfer from PC to the control set

	Please confirm the operation in case of integrating operation programs or teaching data into another control set.	 
	Please save to the specified path when transferring teaching data to the control set.	

Order 1 Run 「FFFTP」.

Save location of the teaching data




Save path

/home/i611usr

Order 2 Transfer file into the control set.

Click upload.





Notes



C Teaching

5

Coordinate system and posture



1. Coordinate system.....	2
2. Joint coordinate system (standard coordinate)	4
1. Definition	4
3. World coordinate system (standard coordinate)	5
1. Definition	5
4. Base coordinate system	6
1. Definition	6
5. Tool coordinate system.....	7
1. Definition	7
6. User coordinate system.....	8
1. Definition	8
2. Tính năng tính pallet	9
7. Posture.....	10
1. Posture.....	10
2. Image on posture (referenced)	11
3. Operation range and posture.....	12

1. Coordinate system

ZERO


The defined coordinate systems in this product include 5 coordinate systems: joint coordinate system, world coordinate system, base coordinate system, tool coordinate system, and user coordinate system.

Please select the coordinate system (*) that best suits your purpose after reviewing the definitions.

*) The 'Teaching mode' corresponds to the joint coordinate system and the world coordinate system. The base coordinate system and the Tool coordinate system are set with offsets in the world coordinate system and is utilized.

Please consider both 'unmovable point' and 'posture' of the power-assisted lifting arm when deciding on the coordinate system. The posture includes a total of 8 types based on the combination of angles of the joints J1~J6, defined by the parameter 'posture'.

Joint coordinate system




Set individual angles at the joints to determine the posture of the power-assisted lifting arm.
The joints operate independently.

Use when confirming visually with the teaching mode to determine the position or when restoring from an unmovable point.

Because the joint coordinate system moves the power-assisted lifting arm through independent operations of the axes, 'posture' is not used (the parameter posture)

p. 4

World coordinate system




The orthogonal coordinate system that takes an arbitrary point in space to setup the power-assisted lifting arm as the origin, representing the orientation and position of the end effector.

The standard absolute coordinate system in a multi-power-assisted lifting arm system.

The world coordinate system and the base coordinate system is setup in the same way on first setup.

p. 5

Base coordinate system




The orthogonal coordinate system that takes the center of the lower flange as the origin, representing the orientation and position of the upper flange.

The world coordinate system and the base coordinate system is setup in the same way on first setup.

p. 6


Tool coordinate system



The orthogonal coordinate system that takes the center of the upper flange as the origin. .

p. 7

User coordinate system



The orthogonal coordinate system that applies the base coordinate system, taking a position with arbitrary offset as the origin. It is used during pallet operations.

p. 8


2. Joint coordinate system (standard coordinates)

1. Definition

Joint coordinate system is the coordinate system showing the angles of joints (J1, J2, J3, J4, J5, J6) .

Each joint and angle can be operated separately.

Do not use posture (parameter posture)



Posture at the left image (original point posture)

Axis	Angle
J1	0°
J2	0°
J3	0°
J4	0°
J5	0°
J6	0°


Functions	Parameters		
Standard coordinates	Joint coordinate system		
Current position information	Angles of axes (J1, J2, J3, J4, J5, J6)		
Teaching data	200 points Take 10 teaching points as 1 pattern, can use up to 20 patterns (Position teaching points: pos1[0] ~ [9] ... pos20[0] ~ [9])		
JOG operation	Maybe		
Direct Move	Commands move through teaching data in a concatenated form		
Hand Homing	Maybe		
Move between 2 points	Operation	Robot program	Teaching
	PTP	move() reljntmove()	Move To
	Line (linear interpolation)	line()	
	Optline (Optimal linear interpolation)	optline()	Impossible

3. World coordinate system (standard coordinates)

1. Definition

World coordinate system is a direct coordinate system that takes an arbitrary point of the space where the power lift arm is installed as the origin point, representing the direction and position of the power lift arm above.

The world coordinate system and the base coordinate system are set the same during initial installation.



Functions	Parameters		
Standard coordinate system	World coordinate system		
Current position information	Coordinate value of the upper wing surface of the last segment in the Tool view from the origin of the world coordinate system (x, y, z, rz, ry, rx)		
Teaching data	200 points Take 10 teaching points as 1 pattern, can use up to 20 patterns (Position teaching points: pos1[0] ~ [9] ... pos20[0] ~ [9])		
JOG operation	Maybe		
Direct Move	Command to move through teaching data of orthogonal coordinate system in world coordinate system		
Hand Homing	Impossible		
Move between 2 points	Operation	Robot program	Teaching
	PTP	move ()	Move To
	Line (linear interpolation)	line () relline()	
	Optline (Optimal linear interpolation)	optline()	Impossible


4. Base coordinate system

1. Definition

Base coordinate system is an orthogonal coordinate system that takes the center of gravity of the lower wing as the origin point. Base offset setting matches the power lift arm installation status from the world coordinate system.

Base offset setting is (xb, yb, zb, rzb, ryb, rxb) .

The offset of the initial setting is (xb, yb, zb, rz, ryb, rxb)=(0, 0, 0, 0, 0, 0), the origin of the base coordinate system is the same as the origin of the world coordinate system.




Functions	Parameters		
Standard coordinate system	World coordinate system		
Offset	Up to 3 can be installed Offset of initial setting is (xb, yb, zb, rzb, ryb, rxb) = (0, 0, 0, 0, 0, 0)		
Current position information	Coordinates of the upper flange face of the last section of the Tool except the base offset value from the world coordinate value (x, y, z, rz, ry, rx)		
Teaching data	200 points Take 10 teaching points as 1 pattern, can use up to 20 patterns (Position teaching points: pos1[0] ~ [9] ... pos20[0] ~ [9])		
JOG operation	Maybe		
Direct Move	Command to move through teaching data of orthogonal coordinate system in base coordinate system		
Hand Homing	Impossible		
Move between points	Operation	Robot program	Teaching
	PTP	move ()	Move To
	Line (linear interpolation)	line () relline()	
	Optline (Optimal linear interpolation)	optline()	Impossible

5. Tool coordinate system

1. Definition

Tool coordinate system is a coordinate system that takes the center of gravity of the upper wing as the origin point. Take the last paragraph of the Tool as a standard. Set the offset (x_t , y_t , z_t , rz_t , ry_t , rx_t) according to the installation tool.

The tool coordinate system has a different direction and world coordinate system (base), so please pay attention.




Functions	Parameters		
Standard coordinate system	World coordinate system		
Offset	Can be set up to 8		
Current position information	Coordinate value viewed from the origin of the Tool coordinate system (x, y, z, rz, ry, rx)		
Teaching data	200 points Take 10 teaching points as 1 pattern, can use up to 20 patterns (Position teaching points : pos1[0] ~ [9] ... pos20[0] ~ [9])		
JOG operation	Maybe		
Direct Move	The command moves through the teaching data of the orthogonal coordinate system in the Tool coordinate system		
Hand Homing	Impossible		
Move between 2 points	Operation	Robot program	Teaching
	PTP	move ()	Move To
	Line (linear interpolation)	line () relline()	

6. User coordinate system

1. Definition

User coordinate system is a coordinate system defined for the user to conveniently operate, suitable for the operating location. The power lift arm can be operated depending on the pallet..




Functions	Parameters		
Standard coordinate system	World coordinate system		
Offset	Up to 3 can be installed		
Current position information	Coordinates viewed from the origin of a user coordinate system except the user offset value from the base coordinate value (x, y, z, rz, ry, rx)		
Teaching data	200 points Take 10 teaching points as 1 pattern, you can use up to 20 patterns (Position teaching points): pos1[0] ~ [9] ... pos20[0] ~ [9])		
JOG operation	Maybe		
Direct Move	Command to move through teaching data of an orthogonal coordinate system in the user coordinate system		
Hand Homing	Impossible		
Move between 2 points	Operation	Robot program	Teaching
	PTP	move ()	Move To
	Line (linear interpolation)	line () relline()	

2. Pallet calculation feature

For finished square pallets in lines $n \times \text{row } n_j$, automatically calculate the coordinates of the pallet cells (x, y, z, rz, ry, rx) by specifying the quantity Pallet cells and user coordinate values of 4 corners (x, y, z, rz, ry, rx).

The power lift arm operates based on the pallet coordinates $P(i, j)$ ($0 \leq i \leq n_i - 1, 0 \leq j \leq n_j - 1$).



Teaching at least 3 points m $P(0, 0)$, $P(n_i - 1, 0)$, $P(0, n_j - 1)$. The 4th teaching point $P(n_i - 1, n_j - 1)$ is used to compensate for the shape error of the pallet used..



The forward direction of the pallet vertical direction is changed according to the order of the teaching point

예 ① $i \times j \rightarrow$ For a flat surface (pallet face), it becomes a vertical vector $+z$.

예 ② $j \times i \rightarrow$ to $-z$ of the opposite direction from example 1















7. Posture

1. Posture

Power lifts have many postures that are determined by (1) arm position and (2) joint angle. Define a total of 8 postures through 3 parameters: shoulder, elbow and wrist..

By switching posture on the operation program, points that cannot be manipulated and points that cannot be moved can be avoided.

Parameter		Explanation			
shoulder (bit0)	Look at the power lift arm from a position where arm 1 is visible to the left of the J1 swivel shaft. If the main part of the upper wing is in front of the plane formed by axis J1 and J2 then it is "1", if it is on the opposite side then is "0".				
	bit 0	0	1		
	Picture				
Elbow (bit1)	If the Z coordinate of axis J3 is above the line connecting J2 and J5, it is "1", if it is below, it is "0".				
	bit1	0	1		
	Picture				
Wrist (bit2)	Determined by the angle of J5 and bit0. .				
	bit0	0	1		
	J5 angle	-180° ~ 0°	0° ~ 180°	-180° ~ 0°	0° ~ 180°
	bit2	1	0	0	1
	Pictures	<u>In case the top flange face is facing down</u> When the joint unit of the last segment inserts arm 2 and is on the opposite side of arm 1, "bit2=1", when on the same side, "bit2=0". (The photo below is an example)			
					
	Pictures	<u>In case the upper wing face is facing up</u> When the joint unit of the last segment inserts arm 2 and is on the opposite side of arm 1, "bit2=0", when on the same side, "bit2=1". (The photo below is an example)			
					

【 Calculation formula 】 : Posture = (4 × bit 2) + (2 × bit 1) + bit 0


wrist

elbow

shoulder

【 Setting range 】 : 0 - 7 (8 types)

2. Coordinate system image (reference)



3. Range of manipulation and posture

The power lift arm has a point where it cannot move on the structure.



To avoid the immovable point, use it in the recommended posture below, above the mounting surface to satisfy conditions 1 and 2.




Condition ① : Range

- The range where the Z coordinate of the center of the upper flange surface $Z > 0$, is not related to the angle of J5


Recommended range: $Z > 148$ (is the range above the height of the rotation axis of J2.)

Condition ② : Posture

- Posture where the coordinates of the rotation axis of J3 are above the lines connecting J2 and J5



Condition ② Posture recommends satisfying condition 2 (operating range : $Z > 0$)



Supplement

If the Z coordinate of the upper wing is close to 0, then even if J5 is rotated in a fixed state, J2 and J3 satisfy condition 2, there is a point where the Z coordinate of the wing is above to $Z < 0$.

Please ask the service desk in case of using operating range $Z < 0$.

Important: The point of no movement exists near the position change point of the power lift arm.

For example, even if the angle of J5 satisfying condition 1 and condition 2 is near 0 deg or 180 deg (range is about ± 5 deg), it is still the same.

There are cases where a point that cannot be moved arises.



D

SOFTWARE

1. Programming instructions
2. Robot Library
3. Mind map
4. Steps to perform the program

NOTES



D SOFTWARE

1

Programming instructions



1. PC and operating environment	2
1. PC	2
2. Required software	3
2. Programming instructions	4
1. Write robot programs	8
2. Sample program	27



ATTENTION



Complete the check before starting automatic operation.
First, operate the robot at low speed to check whether the motion chain operates safely, then slowly increase the operating speed and check the operation.



Robot motion programs are written in Python language.

1.PC

The following equipment is required to use this product. Please refer to this manual and safety instructions to create the operating system. The software may not function in operating environments other than recommended specifications.

Specifications		
Personal computer (PC)	OS	WindowsR 10 (32bit /64bit) WindowsR 8/8.1 (32bit /64bit) WindowsR 7 (32bit /64bit)
	Languages	Korean, English, Japanese
	CPU	32bit or 64bit processor with speed of 1GHz or higher
	Memory	RAM 1 gigabyte (GB) (32 bit) or RAM 2 GB (64 bit)
	Hard drive capacity	Requires 512 MB or more of space
	Communication function	Wired LAN port (recommended) USB port (*) (if there is no wired LAN port)
Screen	Resolution	1366 × 768 pixel or higher
	Color	24 bit color (TrueColor) or higher

*) Separate USB Ethernet adapter required. (Recommended product: LUA3-U2-ATX from Buffalo)

2. Necessary software



Python

Compliant with Python2.7.
For Python language and specifications, please refer to general reference books or specialized books.



Text editor

Python robot programs are written by using a text editor. (Recommended: VSCode) Character codes are UTF-8 and line breaks are LF.



Terminal software Tera Term)

Control the controller by executing the operating program via Telnet



FTP client software (FFFTP)

Transfer files between PC and controller.



Web browser (Google Chrome)

Instructions are performed on a web browser (Google Chrome). Install on the PC you will be teaching on.
(Google Chrome: 61 and up)

- Microsoft® and Windows® operating systems are trademarks of Microsoft Corporation and its affiliates in the United States.
- “Python” and the Python logo are trademarks of the Python Software Foundation or registered trademarks.
- Google Chrome is a registered trademark of Google Inc..
- Tera Term is the work of Takashi Teranishi and the Tera Term Project. Tera Term is free software distributed under the BSD license.
- FFFTP is a product of Jun Sota and the FFFTP Project.
- FFFTP is free software distributed under the BSD license.
- Copyright of the sample program described in the document belongs to Zeus Company Limited.

This chapter briefly explains typical usage examples of modules, methods, and functions. Select from “Entire process” or “Motion model”.

For details on modules and methods, please refer to “Robot Library” ◆

Search through the entire process



Page 5

Description of the entire program of activities.

Each step of “Initial setting”, “Teaching point setting”, “Operating condition setting”, “Operation definition” and “Ending is explained in detail.

Search in “Motion Models”



Page 6

From the actual operating model, we propose an operating program suitable for your purposes. The operating program using the “Pallet function” is described in “Basic Operations”.



Python robot programs distinguish between uppercase and lowercase letters

Search in "Full progress "

Set the robot's dynamic speed and acceleration time.
Motion conditions are optional items, but if omitted,
it will be set as the default value.

Select the desired program block "1. Write a robot program"



Complete the robot program

```
#!/usr/bin/python
# -*- coding: utf-8 -*-

## 1. Initial setting ① #####
.....

## 2. Initial setting② #####
.....

## 3. Set teaching points ###
.....

## 4. Set operating conditions #####
.....

## 5. Definition of robot motion #####
.....

## 6. End #####
.....
```

Block of Program

1. Initial setting (1)



Page 8

Specify the path and character code for the Python interpreter. Import module that uses robots library.

2. Initial setting (2)



Page 9

Create object.
If using an override function to limit the robot's movement speed, define it here.

3. Set the teaching point



Page 10

Set and adjust teaching points.
Saved teaching data can be read and used. If you want to use the Pallet function, specify it here.

4. Set the operation condition



Page 15

Set the robot's movement speed and acceleration time.
Motion conditions are optional items, but if omitted, it will be set as the default value.

5. Definition of robot motion



Page 16

Set the robot's movements.
There are anti-cross functions, linked manipulation of I/O input signals and conversion of the coordinate system in

6. End



Page 26

End of robot program

Search in "Motion Models"

Select desired movement pattern "2. Sample program"




Model 1 : Default activity



Page 27

Set the guide point and perform PTP movement or linear interpolation movement towards the specified point.



Model 2 : overwrite




Page 28

In the basic motion above, the limit placed on the speed of motion is set by using MotionParam().

Speed limit operates in percentage (%) set in override mode.

Used when checking the operation of this operating program,.



Model 3 : overlapping




Page 29

At the moment of approaching the target teaching point, the subsequent movement will be overlapped.

The Robot can be moved by performing the following operations without waiting for the completion of the Robot's movement, passing through prepared reference points to avoid obstacles.

The amount of overlap can be set arbitrarily. (Set to 30 mm in the example on the right)




Model 4 : Wait for I/O input



Page 30

The robot's movements are controlled by I/O signals input to the controller from an external device..

If I/O input is used, it will be possible to start a Robot program pre-registered in the controller via I/O.




Model 5 : Pallet function



Page 31

After determining the number of transfer pallet cells and the coordinates of the four points, the controller will automatically calculate the coordinates of each cell. Set the calculated Pallet coordinates (i, j) as the teaching point.



- | | | |
|---------------------------------|-------------------------------|----------------------------|
| 1. Initial setting (1) | 2. Initial setting (2) | 3. Set the teaching points |
| 4. Set the operation conditions | 5. Definition of robot motion | 6. End |
| 1. Initial setting (1) | | |

Import modules

Install Korean language processing and specify the Python interpreter path

Using full-width characters without specifying a character code that may cause errors.

Example about the program

#!usr/bin/python	Thông dịch Interpreter
# -*-coding: utf-8 -*-	Mã văn bản Text code

Import modules

We can import various modules (standard libraries, robot libraries, customer-made modules) and use the necessary commands to control the robot.

Modules	Functions
i611_MCS	Use the basic functions needed to control the robot
teachdata	Use the teaching data
i611_extend	Using extension functions (Pallet functions)
rbsys	Use administration program
i611_common	Exception handling in methods of class i611Robot (*)
i611_io	Control I/O signals
i611shm	Access shared memory

1 . Initial setting ① Import modules

```
from i611_MCS import *
from teachdata import *
from i611_extend import *
from rbsys import *
from i611_common import *
from i611_io import *
from i611shm import *
```

*) The Exception class can be imported and used in the i611_MCS module. Loading from i611_common import * in module i611_MCS.

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

Create objects

Robot constructor

Create robot object.

```
# Robot i611 constructor
rb = i611Robot( )
```

Definition of world coordinate system

Setting when using world coordinate system.

```
# Definition of world coordinate system
_BASE = Base( )
```

Start connecting to the robot, initialize

```
# Start connecting to the robot, initialize
rb.open( True )
```

Initialize I/O input/output functions

```
# Initialize I/O input/output functions (can be omitted when not using I/O)
IOinit( rb )
```

Overwrite

Set the ratio (%) of operation speed for PTP operation and joint operation.

```
#Override speed 50%
rb.override(50)
```

```
## 2 . Initial settings②: Set operating conditions ##### #
Robot i611 constructor
rb = i611Robot( )
# Definition of world coordinate system
_BASE = Base( )
# Start connecting to the robot, initialize
rb.open( True )
# Initialize I/O input/output functions (can be omitted when I/O is not used)
IOinit( rb )
#Override speed 50%
rb.override(50)
```

1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

3. Set the teaching points

Definition of teaching point

Position() Create an entity that defines the teaching point in the world coordinate system.

Argument	Significance	Variable state	Unit
x, y, z	Position (Descartes coordinate system)	float	mm
rz, ry, rx	Pose (Euler angle based on Z-Y-X)	float	deg
parent	Set the use of the world coordinate system	float	-
posture	Pose	integer	-
multiturn	Cross counter information	long	-

Joint() Creates an entity that defines the teaching point of the joint coordinate system.

Argument	Significance	Variable state	Unit
j1, j2, j3, j4, j5, j6	Joint type data for each axis Original value [0.0, 0.0, 0.0, 0.0, 0.0, 0.0])	float	deg

3 . Set the teaching points

```
p1 = Position( -50, -250, 350, 90, 0, 180 )  
p2 = Position( -300, -250, 350, 90, 0, 180 )  
p3 = Position( -50, -250, 350, 90, 0, 180 )  
  
j1 = Joint( 10, 30, 10, 0, 5, 30 )
```

The teaching points are set as Position Type or Joint Type.



Omit arguments

Enter arguments to the parameters you want to specify.

(Example)

If the argument after rz is omitted and p = Position (x, y, z), then the parameters after rz are set to their original values.

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

Adjust the teaching points

replace()

Replace the world coordinate system object.

(Update the original object)

Argument	Significance	Variable state	Unit
x, y, z	Position (world coordinate system) (original value = 0,0)	float	mm
rz, ry, rx	Pose (angle Z-Y-X Euler) (original value = 0,0)	float	deg
parent	Set the use of world coordinate system	float	-

change of pl value and self-updated

pl = Position (-50, -250, 350, 90, 0, 180)

pl.replace(x=100, rz=-50)

[100, -250, 350, -50, 0, 180]

shift()

Moves objects in world coordinates.

(Update the original object)

Argument	Significance	Variable state	Unit
dx, dy, dz	Position (world coordinate system)	float	mm
drz, dry, drx	Pose (Euler angle based on Z-Y-X)	float	deg

Move pl value and self-updated

p1.shift(dx=10)

pl = Position(-50, -250, 350, 90, 0, 180)

[-40, -250, 350, 90, 0, 180]

Kết quả

Result

offset()

Add the offset coordinate value to the Position coordinate value.

(Create a new object while maintaining the original object)

Argument	Significance	Variable state	Unit
dx, dy, dz	Offset amount of position (Descartes coordinate system)	float	mm
drz, dry, drx	Pose Offset (Euler angle based on Z-Y-X)	float	deg

Create p2 offset while maintaining pl

p1 = Position(-50, -250, 350, 90, 0, 180)

p2 = p1.offset(dx=10)

Result

p1 = [-50, -250, 350, 90, 0, 180]

p2 = [-40, -250, 350, 90, 0, 180]

1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

Use teaching data saved in a file

Teachdata() Read the teaching data and create an instance of the Teachdata class

Argument	Significance	Variable state	Unit
fname	File name of Teaching data	string	-

get_position() Enter teaching data Position coordinate value.

Argument	Significance	Variable state	Unit
key	Position coordinate key name Need	string	-
index	Index of position coordinate Need	integer	-
tool	tool ID collection flag	bool	-
base	base ID collection flag	bool	-
comment	Flag when receiving Comment	bool	-

get_joint() Enter teaching data Joint coordinate value.

Argument	Significance	Variable state	Unit
key	Joint coordinate key name Need	string	-
index	Joint coordinate index Need	integer	-
comment	Comment flag	bool	-

Read teaching data files

data = Teachdata("teach_data")

Read teaching points

p1 = data.get_position("pos1", 0)

j1 = data.get_joint("joint1", 0)

"pos1" Load position type data at index [0]

"joint1" Load joint type data at index [0]

get_param() Enter the parameters of teaching data

Argument	Significance	Variable state	Unit
key	Key name of the parameter Need	string	-
index	Parameter Index Need	integer	-
axis	Axis number in parameter Need	integer	-
comment	Parameter's Comment collection flag	bool	-

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

Use Pallet functions

init_3() Identify Pallet (3 teaching points)

Argument	Significance	Variable state	Unit
pos_0	[Position] Teaching point in Pallet (origin)	Need	float -
pos_i	[Position] Teaching point on Pallet (direction i)	Need	float -
pos_j	[Position] Teaching point on pallet (direction j)	Need	float -
ni	Number of cells in direction i of the pallet	Need	integer -
nj	Number of cells in direction j of the pallet	Need	integer -

Identify Pallet by 3-point teaching data

pal = Pallet()

pal.init_3(pos_0, pos_1, pos_2, 5, 4)

init_4() Identify Pallet (4-point teaching data)

Argument	Significance	Variable state	Unit
pos_0	[Position] Teaching point in Pallet (origin)	Need	float -
pos_i	[Position] Teaching point on pallet (direction i)	Need	float -
pos_j	[Position] Teaching point on pallet (direction j)	Need	float -
pos_ij	[Position] Teaching point on pallet	Need	float -
ni	Number of cells in direction i of the pallet	Need	integer -
nj	Number of cells in direction j of the pallet	Need	integer -


Identify pallet by 4-point teaching data

pal = Pallet()

pal.init_4(pos_0, pos_1, pos_2, pos_3, 5, 4)

Difference between init_3() and init_4()

Correct the Pallet form errors installing the 4th teaching point for use. Robot can be moved more exactly than init_3 ()



1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

Use Pallet functions

get_pos() Enter the Cell Position

Argument	Significance	Variable state	Unit
i	Index determines cell position in Pallet (i direction) Need	integer	-
j	Index determines cell position in Pallet (j direction) Need	integer	-
dk	Offset in vertical direction (defaults to 0 if omitted)	integer	mm

adjust() Adjust the Pallet cell

Argument	Significance	Variable state	Unit
i	Index determines cell position in Pallet (i direction) Need	integer	-
j	Index determines cell position in Pallet (j direction) Need	integer	-
di	Offset amount of direction cell position i Need	integer	mm
dj	Offset amount of direction cell position j Need	integer	mm




Vertical direction of pallets


The vertical direction of the pallet (+k direction) changes depending on the position of the guide point.

Example ① $i \times j$: Vector $z+$ points up perpendicular to the pallet plane. Example ② $j \times i$: Vector $z-$ perpendicular to the bottom of the Pallet plane.

Ex.1 $i \times j$



Ex.2 $j \times i$



1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

4. Set the operation conditions

Set the robot's motion parameters

MotionParam()

Create an instance of the robot's motion parameters class.

motionparam()

Set the operation parameters

Argument	Significance	Variable state	Unit
lin_speed	Speed (Line operation (linear interpolation operation)) Original value : 5.0	float	mm/s
jnt_speed	Speed (PTP operation, general operation, optimal linear interpolation operation) Original value : 5.0	float	%
acctime	Acceleration time Original value : 0.4	float	s
dacctime	Deceleration time Original value : 0.4	float	s
posture	Pose Original value : 2	integer	-
passm	Line activities Original value : 2	integer	-
overlap	Overlapping activities Original value : 0.0	float	mm
zone	Complete range of positioning Original value : 100	integer	pulse
pose_speed	Speed (pose interpolated motion) Original value : 20	float	%
ik_solver_option	Direction of rotation Original value 0x11111111	long	-

If the argument is omitted, the default value will be reset

```
## 4 # Set the motion condition in the Motion Param
```

```
m = MotionParam( jnt_speed=10, lin_speed=70 )
```

```
# Set the operating condition in MotionParam format
```

```
rb.motionparam( m)
```

1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

5. Definition of robot motion

Motion

Linear interpolated motion moves at a constant speed.

home() Move all axes to Odeg joint coordinates.

move() PTP moves at a constant speed. (*)

line() Linear interpolated motion moves at a constant speed.

optline()

*) As soon as the method is executed, it will work with the motion parameters set in the motionparam method. In case an action parameter is given in the eyebrow method, the next action will be changed.

##5. Set up robot movements #####

Move to each coordinate axis (0,0,0,0,0,0)

rb.home()

Movement

rb.move(p1.offset(dz=30))

Move the offset coordinates by dz = 30 relative to p1

rb.line(p2, p3, p4)

Move to p2, p3, p4 in the Line action

rb.move(j1)

Move to each coordinate axis (0,0,0,0,0,0)

rb.move(j1)

Move to j1 using PTP operation



PTP operation, linear interpolation operation and optimal linear interpolation operation

PTP operation (move())

All joints move at a constant speed and angle toward the target coordinates. Motion moves in a smooth curve.


Linear interpolation operation(line())

Is the act of moving at a constant speed so that the trajectory goes straight to the destination while simultaneously controlling the X-Y-Z axes.

Optimal linear interpolation operation (optline())

Is the operation of shifting gears and moving at the optimal speed so that the trajectory go straight to the destination while simultaneously controlling the X-Y-Z axes

Speed is indicated in %



1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

Use offset tools

settool() Set tool Offset

Argument	Significance	Variable state	Unit
id	Number of tool. Need 0 : Turn off tool Offset 1 - 8 : Choose tool Offset	integer	-
offx	Offset the X-axis tool in the tool coordinate system	float	mm
offy	Offset the Y-axis tool in the tool coordinate system	float	mm
offz	Offset the Z-axis tool in the tool coordinate system	float	mm
offrz	Offset around the Rz axis in the tool coordinate system	float	deg
offry	Offset around the Ry axis in the tool coordinate system	float	deg
offrx	Offset around the Rx axis in the tool coordinate system	float	deg

changetool() Choose tool Offset.

Argument	Significance	Variable state	Unit
tid	Number of tools. Need 0 : Turn off tool Offset 1 - 8 : Install tool Offset	integer	-

```
# Number of tools = 1 Register tools
rb.settool( 1, 0.0, 0.0, 137.0, 0.0, 0.0, 0.0 )

# Tools #Change into 1
rb.changetool( 1 )
```

Argument names for tool numbers vary across methods Change tool() and set tool().

Methods	Argument name for tool number
changetool()	tid
settool()	id

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

I/O input and output

din() Enter I/O

Argument	Significance	Variable state	Unit
*adr	Input port • When specifying an input port, adr: number of input ports □ When reading multiple input ports simultaneously, adr [0]: Number of input ports (start) adr [1]: Number of input ports (End)	string	-

Example 1: Specifying port 15

if din (15) == '1':

Example 2: Specifying port 8 and 10

if din (8, 10) [0] == '1': # When specifying port 10

...

elif din(8, 10) [1] == '1': # When specifying port 9

...

elif din(8, 10) [2] == '1': # When specifying port 8

dout() I/O Output

Argument	Significance	Variable state	Unit
adr	Output number, number starting address Need (Setting range: 16 ~ 31)	integer	-
data	Output data from I/O Need Set as bit field in string. '1' = ON '0' = OFF (original value) '*' = constantly	string	-

Specify ON/OFF start address and output data

dout(16, '11111')

For more information about port numbers, see "Memory Map".

**Set the gate from the bit field**

The data part of the dout(), layout(), shootOut(), wait() methods is a string in bitfield format.

Example) Install output port 16 - 31

dout(16, "10001010*****1111")

Install port 31 on the port

16 to 1

Set port 16 to 1

Do not change port 20 to 23.

1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

Wait for I/O input

wait() Wait until the specified I/O input pattern is reached.

Argument	Significance	Variable state	Unit
adr	Starting number of the input port Need	integer	-
data	Specify data to wait for input "1" = ON "0" = OFF Need	string	-
tm	Limited time Need	float, integer	s

Example 1: List

```
if wait( 8, '1', 10 )[0] == 1:
if wait( 9, '1', 10 )[1] == '1':
if wait( 9, '1', 10 )[2] > 10:
```

Example 2: Keywords

```
if wait( adr=1, data='1', tm=10 ) == 1:
```



Attention



Do not change the reserved ports in init.py.



(Incident)

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

Start the robot program according to I/O input

The pre-registered Robot program can be started according to the I/O input of the controller.

File name and position of the setup script

File name	init.py
Save location	/home/i611usr

Do not change the file name and location. The controller includes an example setup script.
Download to PC, modify as desired and use.

Reapply power to the controller and reboot the system.

(When the system boots, "init.py" is executed and the conditions for starting I/O are set.)
· Make sure the jumper connector is connected to the Safety connector.

· When the 7 segments indicator appears, press the on switch



Turn on the input signal to the set I/O port.

(Starts execution of the Robot program on the rising edge of the signal.)

```
#!/usr/bin/python
```

```
# -*- coding: utf-8 -*-
from rbsys import Robsys
if name == 'main':
    rbs = RobSys()
    #This is sample program for initial settings.
    rbs.open()
```

#Default assignment

```
rbs.assign_din( run=0, stop=1, err_reset=2, pause=3 )

rbs.assign_dout(running=16,svon=17,emo=18,hw_error=19,
               sw_error=20,abs_lost=21,in_pause=22,error=23)
```

```
#rbs.set_robtask( "sample.py" )
```

```
rbs.close()
```

The filename of the program you want to start
(File names are random)

Port	State name	Command
0	run	Run robot program
1	stop	Slow down to stop
2	err_reset	Reset error
3	pause	Pause

Port	State name	System states
16	running	Robot program state
17	svon	Servo state
18	emo	Emergency stop condition
19	hw_error	System-determined error condition (critical)
20	sw_error	Error state is determined by the system
21	abs_lost	Loss of ABS
22	in_pause	Pause state
23	error	System error status

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

Commands and system status can be assigned to any I/O port



DANGEROUS



Do not use the output signal for safety-critical purposes.

Processed only through software, it cannot guarantee the reliability needed for safety circuits.



The initial installation port is defined in init.py

Signal and port number		Significance
Input	run=0	Run robot program
	stop=1	Slow down to stop
	err_reset=2	Reset errors
	pause=3	Pause
Output	running=16	Robot program status
	svon=17	Servo status
	emo=18	Emergency stop condition
	hw_error=19	System-determined error condition (critical)
	sw_error=20	The error state is determined by the system
	abs_lost=21	Loss of ABS
	in_pause=22	Pause state
	error=23	System error status (*)

*) A system-determined error (non-fatal or critical) occurred.).

2 Used to check error status with a control line.



ATTENTION



Before pressing the trigger switch, make sure there are no obstacles within the operating range of the manipulator and ensure safety around the area..



Additional

- When the robot program ends due to an error:
..... The program cannot be restarted until the error is reset.
- The function outputs the status “Program running” and “An error occurred” to I/O:
..... Only valid when the robot program is started from the I/O input.
.....(If you start through a PC terminal emulation program, it will not work)

1. Initial setting (1)
2. Initial setting (2)
3. Set the teaching points
4. Set the operation conditions
5. Definition of robot motion
6. End

Convert coordinates

Joint2Position() Converts joint coordinate values to position coordinate values.

Argument		Significance
Position type	Position information in list format	Need
<div># Joint coordinate value j10=Joint(0, 30, 60, 0, 90, 90) # Convert to position coordinate value (j10 → convert → p10) p10=rb.Joint2Position(j10)</div>		

Position2Joint() Convert from Position coordinates to Joint coordinates.

Argument		Significance
Joint type	Each axis angle in list format	Need
<div>#Coordinate value of position type p10=Position(-50, -250, 350, 90, 0, 180) # Convert to joint type coordinate value (p10 → convert → j10) j10=rb.Position2Joint(p10)</div>		

1. Initial setting (1)

2. Initial setting (2)

3. Set the teaching points

4. Set the operation conditions

5. Definition of robot motion

6. End

Use the overrap operation

asyncm() Install the predicted movement part of the robot program.

Argument	Significance	Variable state	Unit
SW	1: Program before operation ON 2: Turn OFF before program operation (default)	integer	-

In the section where the overlapping operation is installed, the next movement will continue when approaching the target teaching point.

With transit points prepared for obstacle avoidance actions, the robot can be moved to perform the next task without waiting for the robot to complete the action.

```
rb.line (p10) # Linear interpolated motion to teaching point p10
rb.asyncm (sw = 1) # Program prediction operation ON (also available in rb.asyncm (1)
rb.line (p20, p21) # Move to teaching points p20 and p21 in the order of performing linear interpolation.

rb.join () # Waiting function for completion of predicted robot program operation

rb.asyncm (sw = 2) # Program prediction operation OFF (also available in rb.asyncm (2)
...
rb.close()
```



I/O input/output during execution overlaps

If overlapping motion is used, all commands are predicted, including those processed unrelated to robot motion, such as: I/O input/output functions.

To make actions synchronized with robot actions, please use join() method of i611Robot class.

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

set_behavior() Set pause operation (action)..

Argument	Significance	Variable state	Unit
only_hook	Pause only in user_hook method () True : Valid False : disable (original value)	bool	-
servo_off	Set servo to OFF when paused True : Valid False : disable (original value)	bool	-
restore_position	When resuming after pausing, the position will return to before pausing True : Valid False : disable (original value)	bool	-
no_pause	Pause only when the operation stops True : Valid (Compatible with system version R0.5.0) False : disable (original value)	bool	-

If restarted after a pause, the pose will return to the position before the pause

rb.set_behavior(only_hook=False, servo_off=False, restore_position=True, no_pause=True)

enable_interrupt() Sets an exception when decelerating to a stop and an emergency stop.

Argument	Significance	Variable state	Unit
eid	Event ID Need 0: An exception occurs when entering the deceleration stop command during operation 1: The exception occurs when an emergency stop command is entered during operation 2: Exception occurs when deceleration stop command is entered during temporary stop 3: Exception occurs when emergency stop command is entered during temporary stop If exception generation is disabled, the robot program will terminate normally.	integer	-
enable	An exception arises Need True : Valid False : Cancel	bool	-

Example 1: To enable exception generation when entering a deceleration stop command during operation
rb.enable_interrupt(0, True)

Example 2: To enable exception generation when there is an emergency stop input during operation
rb.enable_interrupt(1, True)

Example 3: To cancel an exception that occurs when entering the deceleration stop command during a pause
rb.enable_interrupt(2, False)

Example 4: To cancel an emergency stop exception occurring during a temporary stop
rb.enable_interrupt(3, False)

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

user_hook() Pause the robot program.

Use in paused position.

Pausing on user_hook() is possible only by specifying set_behavior(only_hook = True). If not specified, the robot program method may be paused.

```
...
rb.user_hook()    # Pause the program at this position
...
```

cause_user_error() A user-defined error arises.

Argument	Significance	Variable state	Unit
code	Error ID Need Setting range : 1 – 99	integer	-
critical	True : A user-defined fatal error has occurred False : A user-defined error occurred (default)	bool	-

```
# In case a user-defined error occurs (error ID: 19)
rb.cause_user_error (19, False)
```

```
# If a user-defined fatal error occurs (error ID: 01)
rb.cause_user_error (01, True)
```

release_stopevent() Reset the exception event that is occurring

Performed at the beginning of exception handling.

Repeat until the exception is rethrown.

```
try:
...    # Operation
except Robot_stop:
rb.release_stopevent()
...    # Avoidance action
```

Exception handling for methods in class i611Robot ()

Robot_emo()	Exception occurs when emergency stop (return is not possible)
Robot_error()	The exception occurred due to an error
Robot_fatalerror()	Exceptions are raised in case of fatal (irrecoverable) errors.
Robot_poweroff()	Exception occurs when power is turned off (cannot be recovered)
Robot_stop()	The exception occurs when decelerating to a stop.

1. Initial setting (1)

4. Set the operation conditions

2. Initial setting (2)

5. Definition of robot motion

3. Set the teaching points

6. End

6. End

End of robot program

close() Disconnect from the robot.

```
# End  
rb.close()
```



When ending the program or powering off the controller, the close() method must be executed for all using classes.

2. Sample program

Model 1 Default activity

```
#!/usr/bin/python
# -*- coding: utf-8 -*-

## 1. Initial setting ① #####
# Import the library
from i611_MCS import *
from i611_extend import *
from i611_io import *

def main():
    ## 2. Initial setting② #####
    # Robot i611 constructor
    rb = i611Robot()
    # Definition of world coordinate system
    _BASE = Base()
    # Start connecting to the robot, initialize
    rb.open()
    # Initialize I/O input/output functions (can be omitted when I/O is not
    # used)
    IOinit( rb )

    ## 3. Set teaching points #####
    p1 = Position( 95, -280, 425, -120, 84, -28 )
    p2 = Position( 95, -280, 240, 154, 80, -114 )
    p3 = Position( 300, -280, 240, 159, 86, -156 )
    p4 = p3.copy()
    p4.shift( dz=40 )
    j1 = Joint( 230, -1, -92, 90, 5, 89 )

    ## 4. Set operating conditions ##### # Set
    # the motion condition in the MotionParam constructor m =
    MotionParam( jnt_speed=10, lin_speed=70 )


    # Set the operating condition using the MotionParam type
    rb.motionparam( m )

    ## 5. Definition of robot movement ##### # start
    operation rb.home() rb.move( p1
    ) rb.line( p2
    rb.move( j1.offset(dz=30)
    , p3, p4 )
    rb.home()

    ## 6. End #####
# Disconnect from the robot
rb.close()

if __name__ == '__main__':
    main()
```

Operational model



PTP operating speed 10%, linear interpolation
operating speed 70mm/si

Go to Home position
PTP operation with 30 mm Z axis offset at guide point p1
Linear interpolation operation follows the order of points p2, p3, p4
PTP activity with teaching point j1
Go to the Home position



In the Python language, paragraphs are separated by indentation. If you copy the PDF file as is, the indentation will not be copied, so indent as in the example by pressing the Spacebar key 4 times or the Tab key once. The Tab key may not work as expected depending on the text editor.

Model 2 Overwrite

```
#!/usr/bin/python
# -*- coding: utf-8 -*-

## 1. Initial setting① #####
# Enter library
from i611_MCS import *
from i611_extend import *
from i611_io import *

def main():
    ## 2. Initial setting② #####
    # Robot i611 constructor
    rb = i611Robot()
    # Definition of world coordinate system
    _BASE = Base()
    # Start connecting to the robot, initialize
    rb.open()
    # INITIALIZING I/O I/O FUNCTIONS
    (CAN BE REMOVED WHEN I/O IS NOT IN USE)
    IOinit( rb )
    # Overwrite
    rb.override( 50 )


    ## 3. Set teaching points #####
    p1 = Position( 95, -280, 425, -120, 84, -28 )
    p2 = Position( 95, -280, 240, 154, 80, -114 )
    p3 = Position( 300, -280, 240, 159, 86, -156 )
    p4 = p3.offset( dz=40 )
    j1 = Joint( 230, -1, -92, 90, 5, 89 )

    ## 4. Set operating conditions ##### #Data
    motion condition in the MotionParam constructor m =
    MotionParam( jnt_speed=10, lin_speed=70 ) # Set
    the operating condition to type MotionParam
    rb.motionparam( m )

    ## 5. Definition of robot movement ##### # Start
    operation
    rb.home()
    rb.move( p1.offset(dz=30) )
    rb.line( p2, p3, p4 )
    rb.move( j1 )
    rb.home()

    ## 6. End #####
    # Disconnect from the robot
    rb.close()

if __name__ == '__main__':
    main()
```



rb.override(50) Set Override to 50%

```
## 3. Set teaching points #####
p1 = Position( 95, -280, 425, -120, 84, -28 )
p2 = Position( 95, -280, 240, 154, 80, -114 )
p3 = Position( 300, -280, 240, 159, 86, -156 )
p4 = p3.offset( dz=40 )
j1 = Joint( 230, -1, -92, 90, 5, 89 )
```

```
## 4. Set operating conditions ##### #Data
motion condition in the MotionParam constructor m =
MotionParam( jnt_speed=10, lin_speed=70 ) # Set
the operating condition to type MotionParam
rb.motionparam( m )
```

```
## 5. Definition of robot movement ##### # Start
operation
rb.home()
rb.move( p1.offset(dz=30) )
rb.line( p2, p3, p4 )
rb.move( j1 )
rb.home()
```

Go to the Home position

PTP operation with 30 mm Z axis offset at guide point p1

Linear interpolation operation follows the order of points p2, p3, p4

PTP activity with teaching point j1

Go to the Home position

```
## 6. End #####
# Disconnect from the robot
rb.close()
```

```
if __name__ == '__main__':
    main()
```

Model 3 Overlapping

```
#!/usr/bin/python
# -*- coding: utf-8 -*-

## 1. Initial setting① #####
# Enter library
from i611_MCS import *
from i611_extend import *
from i611_io import *
```

```
def main():
```

```
    ## 2. Initial setting② #####
```

```
    # Robot i611 constructor
```

```
    rb = i611Robot()
```

```
    # Definition of world coordinate system
```

```
    _BASE = Base()
```

```
    # Start connecting to the robot, initialize
```

```
    rb.open()
```

```
    # INITIALIZING I/O I/O FUNCTIONS
```

```
    (CAN BE REMOVED WHEN I/O IS NOT IN USE)
```

```
    IOinit( rb )
```

```
    ## 3. Set teaching points #####
```

```
    p1 = Position( 95, -280, 425, -120, 84, -28 )
```

```
    p2 = Position( 95, -280, 240, 154, 80, -114 )
```

```
    p3 = Position( 300, -280, 240, 159, 86, -156 )
```

```
    p4 = p3.offset( dz=40 )
```

```
    j1 = Joint( 230, -1, -92, 90, 5, 89 )
```

```
    ## 4. Set operating conditions ##### # Set the
    motion condition in the MotionParam constructor
```

```
    m = MotionParam( jnt_speed=10, lin_speed=70, overlap = 30 )
```

```
    # Set the operating condition using the MotionParam type
```

```
    rb.motionparam( m )
```

```
    ## 5. Definition of robot motion #####
```

```
    rb.home()
```

```
    rb.move( p1 )
```

```
    rb.line( p2 )
```

```
    # Program prediction
```

```
    operation is ON rb.asyncm(
```

```
    1 )
```

```
    rb.line( p3, p4 )
```

```
    rb.join()
```

```
    # Program prediction
```

```
    operation is OFF
```

```
    rb.asyncm( 2 )
```

```
    # Coordinates of each axis [0, 0, 0, 0]
```

```
    rb.home()
```


```
    ## 6. End #####
```

```
    # Disconnect from the robot
```

```
    rb.close()
```

```
if __name__ == '__main__':
    main()
```

Operational model



j1

p3

Overlap to 30mm

Go to the Home position

PTP activity with teaching point p1

Linear interpolation with teaching point p2

Program prediction operation ON (preparing to execute overlapping operation)

Switch to overlapping operation p3, p4

Overlapping deactivation positions. Wait for the prediction program to complete

Program prediction operation OFF

Go to the Home position

Model 4 Wait for I/O input

```
#!/usr/bin/python
# -*- coding: utf-8 -*-

## 1. Initial setting① #####
# Enter library
from i611_MCS import *
from i611_extend import *
from i611_io import *

def main():
    ## 2. Initial setting② #####
    # Robot i611 constructor
    rb = i611Robot()
    # Definition of world coordinate system
    _BASE = Base()
    # Start connecting to the robot, initialize

    rb.open()
    # Initialize I/O input/output functions
    IOinit( rb )


    ## 3. Set teaching points #####
    p1 = Position( 95, -280, 425, -120, 84, -28 )
    p2 = Position( 95, -280, 240, 154, 80, -114 )
    p3 = Position( 300, -280, 240, 159, 86, -156 )
    p4 = p3.offset( dz=40 )
    j1 = Joint( 230, -1, -92, 90, 5, 89 )

    ##4. Set operating conditions ##### #
    # motion condition in the MotionParam constructor
    m = MotionParam( jnt_speed=10, lin_speed=70 )
    # Set the operating condition to type MotionParam
    rb.motionparam( m )

    ## 5. Definition of robot movement ##### # Start
    # operation
    rb.home()
    # Wait for I/O input
    if wait( 5, "1", 10 )[0] == 1:
        rb.move( p1.offset(dz=30) )
        rb.line( p2, p3, p4 )
        rb.move( j1 )
    # When the input time is exceeded
    else:
        rb.home()

    ## 6. End #####
    # Disconnect from the robot
    rb.close()

if __name__ == '__main__':
    main()
```



Go to Home position

Set the timeout to 10 seconds until I/O input port number 5 becomes 1. If the input signal arrives before the waiting time ends,

PTP ACTION has a Z-axis offset of 30 mm from the lead point p1

Linear interpolation operation follows the order of points p2, p3, p4

PTP activity with teaching point j1

If exceeded

Go to Home position

(In this example, do not move from the Home position)

Model 5 Pallet functions

```
#!/usr/bin/python
# -*- coding: utf-8 -*-
```

```
## 1. Initial setting① #####
```

```
# Enter library
```

```
from i611_MCS import *
```

```
from i611_extend import *
```

```
def main():
```

```
    ### 2. Initial setting② #####
```

```
    # Robot i611 constructor
```

```
    rb = i611Robot()
```

```
    rb.open()
```

```
    # Definition about the world coordinate system
```

```
    _BASE = Base()
```

```
    ## 3. Set teaching point ##### # Read the teaching data file
```

```
    data = Teachdata( "teach_data" )
```

```
    pos_0 = data.get_position( "pos1", 0 )
```

```
    pos_1 = data.get_position( "pos2", 0 )
```

```
    pos_2 = data.get_position( "pos3", 0 )
```

```
    # Identify Pallet
```

```
    pal = Pallet()
```

```
    pal.init_3( pos_0, pos_1, pos_2, 5, 4 )
```

```
    # Adjust pallet pal.adjust( 3,
```

```
    2, 0.4, -0.3 ) # Search the
```

```
    operation position
```

```
    p0 = pal.get_pos( 3, 2, 30 )
```

```
    p1 = pal.get_pos( 3, 2 )
```

```
    ## 4. Set the operation condition #####
```

```
    # Set the operating condition by using the MotionParam type
```

```
    rb.motionparam( jnt_speed=30 )
```

```
    ## 5. Definition of robot movement ##### # Start
```

```
    action
```

```
    rb.home()
```

```
    rb.move( p0 )
```

```
    rb.line( p1 )
```

```
    rb.line( p0 )
```

```
    rb.home()
```

```
    ## 6. End #####
```


```
    # Disconnect from robot
```

```
    rb.close()
```

```
if __name__ == '__main__':
```

```
    main()
```

Operation model



Previously taught teaching data at pos1 [0], pos2 [0], pos3 [0]

Set the cell position by 3 points to calculate the cell position in the Pallet

Determine the size of the pallet position

Adjust the position of (i, j) = (3, 2)
(+0.4mm in i direction, -0.3mm in j direction)

PTP activity rate 30%

Go to Home position

PTP operation with p0 (30 mm above pallet position (3,2))

Linear interpolation action to p1 (Pallet position (3,2))






PTP operation with p0 (30 mm above pallet position (3,2))

PTP operation with Home position






[illegible]

1. Data type	2
2. Module	6
1. List of modules	6
2. How to use modules, classes and functions	10
3. Method category	15
4. Robot Library	21
1. Module : i611_MCS	23
Class : Base	23
Class : Coordinate	24
Class : Position	28
Class : Joint	33
Class : MotionParam	37
Class : i611Robot	47
2. Module: teachdata	
Class : Teachdata	83
3. Module : i611_extend	93
Class : Pallet	93
4. Module : rbsys	98
Class : RobSys	98
5. Module : i611_common	108
Class : Exception	108
6. Module : i611_io	113
7. Module : i611shm	119

Variable type

Type (icon)	Significance
string 	String type Enclose in single quotes (') or double quotes (").
float 	Real number type with floating point
integer 	Integer type
long 	Type of long integer
bool 	Logical type True / False

Type of data form 1

Type (Icon)	Significance
List 	Put the word part in [. . .].
Set 	Is a sequence of elements in (. . .). Tuple elements cannot be changed.
Dictionary 	{ . . . } separates the key (key) and value (value) called "Dictionary" with a colon (:). (e.g. key:value)
Variable argument 	Expand the list. Insert a "*" (asterisk)" before the argument. The received arguments will be stored in a tuple in the specified order.
Keyword argument 	Expand dictionary. Insert two "*" (asterisk)" signs before the argument. The order in which the arguments become "dictionary" at the time they are received is ignored.

Type of data form 2

Type (Icon)	Content								
Position	Position coordinates are expressed using the world coordinate system								
	[x, y, z, rz, ry, rx, parent, posture, multiturn] : List								
	x, y, z [mm] float Position (Descartes coordinate system) Original value : 0.0								
	rz,ry,rx [deg] float Shape (Euler angle in Z-Y-X system) Original value : 0.0								
	parent [-] float Set to use the world coordinate system ^(*) Original value : _BASE Pose ^(*)								
	posture [-] integer Original value : -1 Cross counter information ^(*)								
[Position]	<p>Original value : <u>0 X F F 0 0 0 0 0</u> FLAG J6 J5 J4 J3 J2 J1 (There is no cross counter information)</p> <p>The cross counter is an implementation that uniquely converts position data of type Position to angle data of type Joint. For example: We need to determine whether the joint angle is -200° or 160°. The cross counter will first be set up, then the movements of the operations confirmed during the teaching process can be reproduced. The value is updated when the angle of each joint is exceeded ±180°. Set the following values according to the angle range of each joint. The value applied depends on the number of joints. For example, in a 4-axis robot the values J5, J6 are ignored.</p> <ul style="list-style-type: none"> FLAG section: With or without FF cross counter information : No (Original value) 00 : Yes (Anything other than the above is invalid)) Part J1 -J6 : cross counter value <table border="1"> <thead> <tr> <th>Setting value</th><th>Angle of each joint</th></tr> </thead> <tbody> <tr> <td>1</td><td>Rotate more than 180° in + direction</td></tr> <tr> <td>0</td><td>180° ~ 180°</td></tr> <tr> <td>F ^(*)</td><td>Rotate more than 180° in - direction</td></tr> </tbody> </table> <p>Relationship between cross counter value and joint angle</p>	Setting value	Angle of each joint	1	Rotate more than 180° in + direction	0	180° ~ 180°	F ^(*)	Rotate more than 180° in - direction
Setting value	Angle of each joint								
1	Rotate more than 180° in + direction								
0	180° ~ 180°								
F ^(*)	Rotate more than 180° in - direction								

*1) The setting value is "_BASE".

*2) There are 8 postures depending on the position, direction and angle of the arms.

*3) Cross counter information can be abbreviated as "CC".

*4) Displayed as "-1" on the teaching screen.

(period Coordinates and pose)

5

period 4 Period)




API related to multiturn parameter

Implementing the use_mt() method in the i611Robot class will change the behavior of the following APIs. The multiturn parameter is used in the move() and Location2Joint() methods in the i611Robot class.

This API can be used regardless of whether or not multiturn information is present.

Class	API	Functions	p.
Position	has_mt()	Check cross counter information.	30
	Position() (Hàm tạo)	Create an entity that defines the teaching point in the world coordinate system.	28
	pos2dist()	Position coordinate values are entered in dictionary format.	31
	pos2list()	Position coordinate values are entered in list format.	31
	position()	Convert the Position coordinate value to the Parent coordinate system and import in list format	31
	replace()	Position Replace coordinate values. (Self-updated.)	32
MotionParam	ik_solver_option (Biến số)	Direction of rotation	41
i611Robot	getpos()	Get the current position of the Manipulator operator in the Position type	60
	Joint2Position()	Convert joint coordinate values to position coordinate values..	63
	move()	Move by PTP.	66
	Position2Joint()	Convert from Position coordinates to Joint coordinates..	70
	use_mt()	Cross counter on/off setting	80


Type (Icon)	Content	
Joint [Joint]	Angle of each joint	
	[j1, j2, j3, j4, j5, j6,] :	List
	j1, j2, j3, j4, j5, j6 [deg] float	Joint type data for each axis Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]
MotionParam [MotionParam]	The robot's motion parameters are made up of variables	
	lin_speed [mm/s] float	Speed (linear interpolated motion) Original value : 5.0
	jnt_speed [%] float	Speed (PTP motion, Joint motion, optimal linear interpolation operation) Original value : 5.0
	acctime [s] float	Acceleration time Original value : 0.4
	dacctime [s] float	Deceleration time Original value : 0.4
	posture [-] integer	Pose Original value : 2
	passm [-] integer	Path movement Original value : 2
	overlap [mm] float	Overlap motion Original value : 0
	zone [pulse] integer	Complete range of positioning Original value : 100
	pose_speed [%] float	Speed (pose interpolated motion) Original value : 20 When the manipulator operates while changing direction, set the upper limit of the machine head's Euler angular movement speed.
	ik_solver_option [-] long	<p>Direction of rotation</p> <p>Original value : $0 \times \underline{1 \ 1 \ 1 \ 1 \ 1 \ 1 \ 1 \ 1}$ (Rsv.) J6 J5 J4 J3 J2 J1</p> <p>Setting value J1 - J6 0 : Shortest line Rotation does not use information from the multiturn parameter. 1 : Use information from the multiturn parameter 2 : Rotation toward + direction 3 : Rotation toward - direction Refer to the picture on the right with + direction and - direction-</p>  <p>Definition of rotation direction</p>

2. Module



1. List of modules

Modules control robot

Modules	Classes	Summary
	Base P. 23 ~	Determine the world coordinate system (The pseudo class will be used in the Position class and the Coordinates class)
	Coordinate P. 24 ~	Handle world coordinate system objects
	Position P. 28 ~	Handling Position of coordinate values in the world coordinate system
	Joint P. 33 ~	Handles joint coordinate values in the joint coordinate system
i611_MCS	MotionParam P. 37 ~	Handle robot motion parameters
	i611Robot P. 47 ~	Handle robot motion

Methods							Lóp
	Base() p. 23						Base
	b2g() p. 25	clear() p. 25	Coordinate() p. 24	copy() p. 25	g2b() p. 26		Coordinate
	inv() p. 26	replace() p. 27	shift() p. 27				
	clear() p. 29	copy() p. 29	has_mt() p. 30	offset() p. 30	pos2dict() p. 31		Position
	pos2list() p. 31	Position() p. 28	position() p. 31	replace() p. 32	shift() p. 32		
	clear() p. 34	copy() p. 34	jnt2dict() p. 34	jnt2list() p. 35	Joint() p. 33		Joint
	offset() p. 35	replace() p. 36	shift() p. 36				
	clear() p. 43	confdefault() p. 43	copy() p. 44	MotionParam() p. 42	motionparam() p. 45		Motion Param
	mp2dict() p. 46	mp2list() p. 46					
	abort() p. 50	adjust_mt() p. 50	asyncm() p. 51	cause_user_error() p.52	changetool() p. 52		
	check_ready() p. 53	close() p. 54	disable_mdo() p. 54	enable_interrupt() p. 55	enable_mdo() p. 56		
	exit() p. 57	get_hw_info() p. 57	get_system_port() p.58	get_system_status() p. 59	getjnt() p. 59		
	getmotionparam() p. 60	getpos() p. 60	home() p. 60	i611Robot() p. 49	is_open() p. 61		
	is_pause() p. 61	join() p. 63	Joint2Position() p. 63	line() p. 64	MCS_version() p. 65		i611Robot
	motionparam() p. 65	move() p. 66	open() p. 67	optline() p. 68	override() p. 69		
	pause() p. 69	Position2Joint() p. 70	release_stopevent() p. 70	reljntmove() p. 71	relline() p. 72		
	restart() p. 73	set_behavior() p. 74	set_mdo() p. 75	settool() p. 76	sleep() p. 77		
	stop() p. 78	svoff() p. 78	svstat() p. 79	toolmove() p. 79	use_mt() p. 80		
	user_hook() p. 80	version() p. 81					

Shading method () is created function.

Modules control robot

Modules	Classes	Summary
teachdata <div>Teach data</div>	Teachdata P. 83 ~	Administration of teaching data
i611_extend <div>i611 Ext.</div>	Pallet P. 93 ~	Handle Pallet functions
rbsys <div>rbsys</div>	RobSys P. 98 ~	Use the system administrator (*)

*) System administrator is the controller's internal program, which has the function of managing the status of the robot program, controlling the teaching status and handling errors..

Module for handling exception

i611_common <div>i611 COM.</div>	Exception P. 108 ~	Exception handling in i611Robot class methods
----------------------------------	--------------------	---

Functional modules

Modules	Classes	Summary
i611_io (None) <div>i611 IO</div>	P. 113 ~	<div>Functional modules</div> I/O control
i611shm (None) <div>i611 shm</div>	P. 119 ~	<div>Functional modules</div> Access shared memory

Methods								Class
check_format()	p. 84	close()	p. 85	flush()	p. 85	get_coordinate()	p. 86	Teachdata
get_param()	p. 87	get_position()	p. 88	get_tool()	p. 89	is_open()	p. 89	
set_joint()	p. 90	set_param()	p. 91	set_position()	p. 92	Teachdata()	p. 84	
adjust()	p. 94	get_pos()	p. 95	init_3()	p. 90	init_4()	p. 97	Pallet
						Pallet()	p. 93	
assign_din()	p. 99	assign_dout()	p. 100	clear_robtask()	p. 101	close()	p. 101	RobSys
cmd_reset()	p. 102	cmd_run()	p. 103	cmd_stop()	p. 103	get_robtask()	p. 104	
req_mcmd()	p. 105	RobSys()	p. 98	set_robtask()	p. 106	version()	p. 107	

Methods ( handled are created functions.

The class inherits the Exception class								Class
Robot_emo()	p. 109	Robot_error()	p. 110	Robot_fatalerror()	p. 110	Robot_poweroff()	p. 111	Exception

Functions								Module
din()	p. 114	dlyOut()	p. 115	dout()	p. 115	IOinit()	p. 116	i611_io
shotOut()	p. 117	wait()	p. 118					
shm_read()	p. 119	shm_write()	p. 120					i611shm

2. How to use modules, classes and functions

STEP1 Import module

To use the robot library, import the module in use first. Inside this method there are some modules that need to be entered first. Modules to import are represented by an icon in each method.






Module to be imported	
Method	position()
Function	Convert the Position coordinate system to the original coordinate system and import in list format (*1)
Receive	None
Return value	[Position] : List

Display and enter modules

Module	Example input program	Inclusion classes
		Base
		Coordinate
i611_MCS	from i611_MCS import *	Position
		Joint
		MotionParam
		i611Robot
teachdata	from teachdata import *	Teachdata
i611_extend	from i611_extend import *	Pallet
rbsys	from rbsys import *	RobSys
i611_common	from i611_common import *	Exception
i611_io	from i611_io import *	(None)
i611shm	from i611shm import *	(None)

STEP2 Prepare to use classes and functions

Use methods of class Base, Coordinate, Position, Joint, MotionParam, i611Robot

Classes	Steps
Base	1. Import module .  <pre>from i611_MCS import *</pre>
Coordinate	1. Import Module .  2. Define the dummy class.
Position	<pre>_BASE = Base()</pre>
Joint	1. Import Module. 
MotionParam	1. Import Module.  2. Create an Entity MotionParam <pre>m = MotionParam()</pre> Set robot motion parameters if necessary. <pre>m = MotionParam(jnt_speed=10,lin_speed=70,overlap=30)</pre> (The combed parameters are set to their initial values.)
i611Robot	1. Import Module.  2. Create an Entity i611Robot. <pre>rb = i611Robot()</pre> 3. Connect to the robot you want to run by using the open method (). <pre>rb.open()</pre> For methods (*) related to robot movement, set the movement parameters in the robot's MotionParam..

*) The method that accompanies the robot's movements

disable_mdo()	enable_mdo()	getjnt()	getmotionparam()	getpos()
home()	join()	Joint2Position()	line()	motionparam()
move()	optline()	override()	Position2Joint()	reljntmove()
relline()	set_mdo()	toolmove()		

STEP2

Prepare to use class and function

Use the methods of the Teachdata class



Class	Steps
Teachdata	<div>1. Import module.</div> <div>from teachdata import *</div>
	<div>2. Create the Teachdata entity.</div> <div>td = Teachdata()</div>
	<div>3. Run the open() method on the Teachdata class.</div> <div>td.open(readonly = False)</div>

Use the methods of the Pallet class


Class	Steps
Pallet	<div>1. Import module.</div> <div>from i611_MCS import * from i611_extend import *</div>
	<div>2. Create the i611Robot entity.</div> <div>rb = i611Robot()</div>
	<div>3. Implement the open() method of the i611Robot class.</div> <div>rb.open()</div>
	<div>4. Create an instance of the Pallet class.</div> <div>pal = Pallet()</div>

Prepare to use classes and functions

Use the methods of the RobSys class

Class	Steps
RobSys	1 . Import Module.  <code>from rbsys import *</code>
	2 . Create the RobSys entity. <code>rbs = RobSys()</code>
	3 . Implement the open() method of the RobSys class. <code>rbs.open()</code>
	4 . Import the i611_io module, which has a method (*) that defines the I/O configuration so that the I/O function can be used. (p.14) 
*) I/O setting method <code>assign_din(), assign_dout()</code>	

Use the methods of the Exception class

Class	Steps
Exception	1 . Import Module. (*)  <code>from i611_common import *</code>
	2 . Use a class that inherits the Exception class. For details, see how to use each layer.
*1) Module imported Importing i611_common import * in module i611_MCS. The Exception class is available when importing the i611_MCS module.	

Use functions of module i611_io

Module	Steps
i611_io	1 . Import Module. <code>from i611_io import *</code>
	2 . Initialize I/O . <code>IOinit()</code>
	3 . Create the i611Robot entity. <code>rb=i611Robot()</code>
	4 . Run the method <code>open()</code> of i611Robot. <code>rb.open()</code>
	5 . For methods (*) related to robot movement, set the operating parameters in the robot's MotionParam.

) For methods () related to robot movement, set the operating parameters in the robot's MotionParam (i611Robot class)

<code>disable_mdo()</code>	<code>enable_mdo()</code>	<code>getjnt()</code>	<code>getmotionparam()</code>	<code>getpos()</code>
<code>home()</code>	<code>join()</code>	<code>Joint2Position()</code>	<code>line()</code>	<code>motionparam()</code>
<code>move()</code>	<code>optline()</code>	<code>override()</code>	<code>Position2Joint()</code>	<code>reljntmove()</code>
<code>relline()</code>	<code>set_mdo()</code>	<code>toolmove()</code>		

Use the function of i611_shm module

Module	Step
i611_shm	1 . Import Module. <code>from i611_shm import *</code>

























Python "time" module

"Time" is a library containing information functions related to time.

Conduct a check of the current system time or generate data in time format. The starting time is 00:00:00 on January 1, 1970. You can use it when importing the following modules.

```
import time
```

3. List of methods

	Methods, functions	Functions	Modules, classes	page
A	abort()	Stop the robot program	 i611Robot	50
	adjust()	Accurate cell position on Pallet	 Pallet	94
	adjust_mt()	Fix CC value when converting location type coordinate value to string	 i611Robot	50
	assign_din()	Fix CC value when converting position type coordinate value to string	 RobSys	99
	assign_dout()	Assign functions to physical I/O ports and memory I/O output ports	 RobSys	100
	asyncm()	Set up the prediction part of the robot program	 i611Robot	51
B	b2g()	Convert from base coordinate system to world coordinate system	 Coordinate	25
	Base()	Base class constructor	 Base	23
C	cause_user_error()	User-defined error arises Select tool offset	 i611Robot	52
	changetool()			
	check_format()	Create a formatted version of the teaching data file	 i611Robot	52
	check_ready()	Check whether the robot can drive automatically or not	 Teachdata	84
	clear()	Initialize the world coordinate system instance	 i611Robot	53
			Coordinate	25
	clear()	Initialize the position coordinate value	 Position	29
	clear()	Initialize the Joint coordinate value	 Joint	34
	clear()	Initialize operating parameters	 MotionParam	43
	clear_robtask()	Unsubscribe from the robot program	 RobSys	101
	close()	Disconnect from robot	 i611Robot	54
	close()	End of teaching data file	 Teachdata	85
	close()	Terminate connection with system administrator	 RobSys	101
	cmd_pause()	Action command: Pause	 RobSys	102
	cmd_reset()	Action command: Reset error	 RobSys	102
	cmd_run()	Action command: Run the robot program	 RobSys	103

Inner method () is created function.

Icon module



i611_MCS



teachdata



i611_extend



rbsys



i611_common



i611_io





























i611shm

Methods, functions	Functions	Modules classes	p.
cmd_stop()	Operating command: decelerate to stop	rbsys RobSys	103
confdefault()	Set the initial values of the operating parameters	i611 MCS MotionParam	43
Coordinate()	Constructor of Coordinate class	i611 MCS Coordinate	24
copy()	Copy the world coordinate system object	i611 MCS Coordinate	25
copy()	Copy the Position coordinate value	i611 MCS Position	29
copy()	Copy the Joint coordinate value	i611 MCS Joint	34
copy()	Copy operating parameters	i611 MCS MotionParam	44
din()	Functional I/O input	i611 IO (None)	114
D disable_mdo()	Invalid MDO operation	i611 MCS i611Robot	54
dlyOut()	I/O output after specified time has elapsed	i611 IO (None)	115
dout()	Functional I/O output	i611 IO (None)	115
enable_interrupt()	Set exceptions for deceleration and emergency stops	i611Robot	55
E enable_mdo()	Enable MDO activity	i611Robot	56
exit()	Force quit the robot program	Teach data i611Robot	57
flush()	Export updated teaching data to files	i611 MCS Teachdata	85
F g2b()	Convert from world coordinate system to base coordinate system	i611 MCS Coordinate	26
G get_coordinate()	Check the base offset value of the teaching data	Teach data Teachdata	86
get_hw_info()	Check the model name and serial number	i611 MCS i611Robot	57
get_joint()	Check the Joint coordinate value of the teaching data	Teach data Teachdata	86
get_param()	Check parameters of teaching data	Teach data Teachdata	87
get_pos()	Get cell location	i611 Ext. Pallet	95

Inner method () is created function.

Functions

Methods, functions		Mô-đun Lớp		p.
get_position()	Check the Position coordinate value of the teaching data	 Teachdata		88
get_robtask()	Check the status of the robot program	 RobSys		104
get_system_port()	Check system port status	 i611Robot		58
get_system_status()	Check system status and error ID	 i611Robot		59
get_tool()	Check the tool offset of the teaching data	 Teachdata		89
getjnt()	Check the current position of the controller according to the joint type.	 i611Robot		59
getmotionparam()	Check current operating parameters	 i611Robot		60
getpos()	Check the current location of the Manipulator via Position Type	 i611Robot		60
has_mt()	Check cross counter information	 Position		30
H home()	Move all axes to Joint 0deg coordinates	 i611Robot		60
i611Robot()	Constructor of class i611Robot	 i611Robot		49
I init_3()	Definition of pallet (Lecture 3 points)	 Pallet		96
init_4()	Definition of pallet (Lecture 4 points)	 Pallet		97
inv()	Perform the inverse transformation to create an object of the Coordinate class	 Coordinate		26
IOinit()	Initialize I/O function	 (Không có)		116
is_open()	 Check i611Robot open status	 i611Robot		61
is_open()	Check the open status of teaching data	 Teachdata		8
is_pause()	Check the pause status of the robot program	 i611Robot		60
jnt2dict()	Check Joint coordinate value in dictionary format	 Joint		34
J jnt2list()	Check the Joint coordinate value in list form	 Joint		35
join()	Wait for the predicted robot program operation to complete	 i611Robot		63
Joint()	Constructor of Joint class	 Joint		33
L Joint2Position()	Converts joint coordinate values to position coordinate values	 i611Robot		63
M line()	Perform linear interpolation	 i611Robot		64
MCS_version()	Check the version of the robot library	 i611Robot		65

Icon module



i611_MCS



teachdata



i611_extend



rbsys



i611_common



i611_io



























i611_shm

Methods, functions	Functions	Modules Classes	p.
MotionParam()	Constructor of MotionParam class	i611 MCS MotionParam	42
motionparam()	Set operating parameters	i611 MCS MotionParam	45
motionparam()	Set operating parameters	i611 MCS i611Robot	65
move()	Carry out PTP activities	i611 MCS i611Robot	66
mp2dict()	Get operating parameters in dictionary format	i611 MCS MotionParam	46
mp2list()	Enter operating parameters in list format	i611 MCS MotionParam	46
offset()	Add offset coordinate value to Position coordinate value (create new object while maintaining itself)	i611 MCS Position	30
offset()	Add offset coordinates to joint coordinates (create a new object while maintaining itself)	i611 MCS Joint	35
open()	Start connecting to the robot (initialization)	i611 MCS i611Robot	67
open()	Open the teaching data file	Teach data Teachdata	90
open()	Initiate communication with the system administrator	rbsys RobSys	104
optline()	Perform linear interpolation motion while shifting gears at optimal speed	i611 MCS i611Robot	68
override()	Perform override(*)	i611 MCS i611Robot	69
Pallet()	Constructor of Pallet class	i611 Ext. Pallet	93
pause()	Pause the robot's movements	i611 MCS i611Robot	69
pos2dict()	Enter the Position coordinate value in dictionary format	i611 MCS Position	31
pos2list()	Enter the Position coordinate value in list format	i611 MCS Position	31
Position()	Constructor of the Position class	i611 MCS Position	28
position()	Convert the Position coordinate value to the parent coordinate system and import it in list format	i611 MCS Position	31
Position2Joint()	Convert from Position coordinates to Joint coordinates	i611 MCS i611Robot	70
release_stopevent()	Reset the exception event that is occurring	i611 MCS i611Robot	70
reljntmove()	Relative motion in the joint coordinate system	i611 MCS i611Robot	71
relline()	Perform relative linear interpolations in Cartesian coordinates	i611 MCS i611Robot	72

Inner method() is created function.

*) override covers the speed setting.


Methods, functions	Function	Modules Classes	p.
replace()	Replace the world coordinate system object (self-updating)	 Coordinate	27
replace()	Replace Position coordinate value (self-updating)	 Position	32
replace()	Replace Joint coordinate values (self-updating)	 Joint	36
req_mcmd()	Check system status and operate command status	 RobSys	105
restart()	Generate restart signal from pause	 i611Robot	73
RobSys()	Function of RobSys class	 RobSys	98
S set_behavior()	Set pause action (action)	 i611Robot	74
set_joint()	Update coordinate values to match teaching data	 Teachdata	90
set_mdo()	MDO operation settings (*)	 i611Robot	75
set_param()	Update parameters of teaching data	 Teachdata	91
set_position()	Update coordinate values of teaching data	 Teachdata	92
set_robtask()	Registration for the robot program	 RobSys	106
settool()	Set tool offset	 i611Robot	76
shift()	Move objects in world coordinate system (self-updating)	 Coordinate	27
shift()	Move Position coordinate value (self-updating)	 Position	32
shift()	Move joint coordinate values (self-updating)	 Joint	36
shm_read()	 Read shared memory	 (None)	119
shm_write()	 Write to shared memory	 (None)	120
shotOut()	 I/O output at the specified time	 (None)	117
sleep()	Pause processing for a certain period of time	 i611Robot	77
stop()	Decelerate the robot to stop	 i611Robot	78

*) MDO operation: Is a function that changes I/O output under specified conditions during operation..


Icon module

 i611_MCS

 teachdata












 i611_extend

 rbsys

 i611_common

 i611_io

 i611shm

	Methods, functions	Function	Modules Classes	p.
	svoff()	Set servo to OFF	 i611Robot	78
	svstat()	Check servo status	 i611Robot	79
T	 Teachdata()	Constructor of class Teachdata	 Teachdata	84
	toolmove()	Perform relative movement in the tool coordinate system	 i611Robot	79
U	use_mt()	Set cross counter on/off	 i611Robot	80
	user_hook()	Pause the robot program	 i611Robot	80
V	version()	Check the system version	 i611Robot	81
	version()	Check the version of System Manager	 RobSys	107
W	wait()	 Wait until the specified I/O input pattern is reached	 (None)	118

The inner method () is the constructor



When ending the program or shutting down the controller, make sure to execute the close() method of all the classes you are using.



The robot program divides between “uppercase” and “lowercase” letters.



Regarding “Exception” (Exception)

In case the robot program is created incorrectly, an "exception" will occur. If an exception occurs, check the error code and take appropriate action.



Check the results of program execution

Record usage examples provided for each method. You can check the results of the method's execution using the print statement.

Usage
example

```
# Load teaching data
data=Teachdata( './teach_data' )
# Key: Joint1, index number: Taking in data 0.
jnt_0=data.get_Joint( 'Joint1', 0 ) print
jnt_0.jnt2list()
```

Performance result (This example shows Match Type data)

```
# Check the performance result
[0.744, -37.724, -83.660, 45.270, -47.308, 10.110]
```

(In the following explanation, 「print…」 is omitted, only the performance result is displayed.)

point



How to view the robots library

Overview and class names

Name and function

Lớp		
MotionParam		
Handle robot motion parameterst		
Variable number of members		Page
lin_speed	Speed (linear interpolation operation)	P.38
...
ik_solver_option	rotation direction	P.41
Method		
clear()	Initialize motion parameters.	P.43
...
mp2list()	Get the operation parameters in list format.	P.46

Icon module

Is the Module that must be inserted to use this method.

Classification and name

Argument (entire)

Indicates the order of the list in case of multiple arguments (*)

Detailed argument description

Cannot be omitted with this argument.

Unit

Variable Icon

return value (Total)
Indicates the retrieval order in case there are multiple return values

Mission	Get the Joint coordinate value of the teaching data	Teach data
[key, index, comment] :		
key	Joint coordinate key name	
[-]	Installation scope : 'Joint1'-'Joint20' Joint coordinate index	
integer	Pinstallation range : 0 - 9 Receiving comments	
bool	True: Get; False: Uncollectable	
[-]		
[{ Joint }]		
[{ Joint }]		
[-]		
float	Joint Coordinate value	
[deg]		
string		
comment	Comment	
[-]	(Maximum 32 characters, if none, " ")	
#Key = joint1.index Get Joint Coordinate value and comment number = 1		

Data Icon

If multiple symbols are entered, they correspond to each type of data.

Program and example

Usage example

```
jnt, comment = td.get_joint( 'joint1', 1, True )
print jnt.jnt2list()
```

Performance result

[0.744, -37.724, -83.660, 45.270, -47.308, 10.110]

[Position] [Joint] [MotionParam] Result

Here is an example after implementing this method. Can be tested using print statements.

*)

Major Icon

• : Unomittable arguments

Can be listed. Please refer to the data type for details	
Icon of data type	Icon of variable type
• List	• float : Long
• Dict	• bool : String
• Vari. No	• Integer
• Dictionary	• float
• Variable argument	• bool
• Key words	

P.3)

Unit

• [mm]
• [deg]
• [s]
• [-] (No units)

[Position]

Icon of data type

• [Joint] : Type of position

[x, y, z, rz, ry, rx, parent, posture, multiturn]

[MotionParam]

: Match type
[j1, j2, j3, j4, j5, j6,]
• : MotionParam type

[lin_speed, jnt_speed, acctime, dactime, posture, passin, overlap, zone, pose_speed, ik_solver_option]

1. Module: i611_MCS

Class	
<u>Base</u>	
Determine the world coordinate system.(*)	
Variable of members	
—	—
Method	
—	—

(*) This is a pseudo class used in the Position class and the Coordinate class.

Created functions	Base() i611 MCS
Function	Create instances of the pseudo-class for use in the Position and Coordinate classes of the world coordinate system.
Argument	None
Return value	Self Reference (Base Class Object)
Usage example	<code>_BASE=Base()</code>



Classes



Coordinate

Handles world coordinate system objects.

Variable for members	
x, y, z	Position (absolute coordinates)
rz, ry, rx	Pose (Z-Y-X Euler angle)
parent	Set to use world coordinate system.
Method	
b2g()	Converted from base coordinate system to world coordinate system. P.25
clear()	Initialize the world coordinate system object. P.25
copy()	Copy world coordinate system. P.25
g2b()	Converted from world coordinate system to base coordinate system. P.26
inv()	Create an object of the Coordinate class to perform the inverse transformation. P.26
replace()	Replace the world coordinate system object. (self-updated) P.27
shift()	Moves objects in world coordinates. (self-updated) P.27

Created functions	Coordinate() i611 MCS
	Creates an instance of the Coordinate class defined in the world coordinate system.
Argument	[x, y, z, rz, ry, rx, parent] : List Keyword
Return value	<p>If numbers are omitted, the base value will be set..</p> <p>Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, _BASE]</p> <p>Self-referencing (Coordinate Object)</p>
Usage examples	<div> <div> # Example 1: Omit arguments. (Original value setting) </div> <div> CO1=Coordinate() </div> <div> [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, <... >] </div> </div> <div> <div> # Example 2 : Keywords (All) </div> <div> CO2=Coordinate(x=1, y=2, z=3, rz=1, ry=2, rx=3, parent=_BASE) </div> <div> [1.0, 2.0, 3.0, 1.0, 2.0, 3.0, <... >] </div> </div> <div> <div> # Example 3 : Keywords (6 words) </div> <div> CO3=Coordinate(x=1, y=2, z=3, rz=1, ry=2, rx=3) </div> <div> [1.0, 2.0, 3.0, 1.0, 2.0, 3.0, <... >] </div> </div> <div> <div> # Example 4 : Keyword (1 word), Unknown value will become the original value. </div> <div> CO4=Coordinate(x=10) </div> <div> [10.0, 0.0, 0.0, 0.0, 0.0, 0.0, <... >] </div> </div>

Method	b2g() i611 MCS
Function	Convert from base coordinate system to world coordinate system.  .
Argument	[x, y, z, rx, ry, rz] : List (All arguments are needed to change coordinates.)
Return value	<div> <div>x, y, z</div> <div>Need [mm] float</div> </div> <div>Unit (default coordinate system)</div>
	<div> <div>rx, ry, rz</div> <div>Need [deg] float</div> </div> <div>Pose (Euler angles are based on Z-Y-X)</div>
	[X, Y, Z, RX, RY, RZ] : List
Usage examples	<div>X, Y,Z</div> <div>[mm] float</div> <div>Unit (default coordinate system)</div>
	<div>RX, RY,RZ</div> <div>[deg] float</div> <div>Pose (Euler angles are based on Z-Y-X)</div>
	# Specify all arguments in a list. CO1=Coordinate() CO1.b2g(1, 2, 3, 4, 5, 6)  [1.0,2.0, 3.0, 4.0,5.0, 6.0]

Method	clear() i611 MCS
Function	Initializes the object in the world coordinate system. Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, _BASE]
Argument	None
Return value	None
Usage example	# Initial the world coordinate system. CO1=Coordinate(1, 2, 3, 4, 5, 6, _BASE) CO1.clear()  Performance result  [0.0,0.0,0.0,0.0,0.0,0.0,<...>]

Method	copy() i611 MCS
Function	Copy of the world coordinate system.
Argument	None
Return value	New copied coordinate system object (Coordinate object)
Usage example	#Copy of the coordinate system object Random coordinates CO1. # Declare CO1. CO1=Coordinate(x=1, y=2, z=3, rz=4, ry=5, rx=6, parent=_BASE) # Copy CO1 to the new Coordinate object CO1C. CO1C=CO1.copy() <div> <div>Result</div> <div> CO1 : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, <...>] ↓ copy() ↓ New point object : CO1C CO1C : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, <...>] </div> </div>

Method	g2b()		i611 MCS
Function	Convert from world coordinate system to base coordinate system.		
Argument	[X, Y, Z, RZ, RY, RX] : List (All arguments are needed to change coordinates.)		
	X, Y, Z Cân [mm] float	Unit (World coordinate system)	
	RZ, RY, RX Cân [deg] float	Pose (Euler angle based on Z-Y-X)	
Return value	[x, y, z, rz, ry, rx] : List		
	x, y, z [mm] float	Unit (default coordinate system)	
	rz, ry, rx [deg] float	Pose (Euler angle based on Z-Y-X)	
Usage value	# Specify all arguments in a list. CO1=Coordinate() CO1.g2b(1, 2, 3, 4, 5, 6)		

[1.0,2.0, 3.0, 4.0, 5.0, 6.0]

Method	inv()		i611 MCS
Function	Create an object of the Coordinate class to perform the inverse transformation.		
Argument	None		
Return value	A new Coordinate object is created		
Usage value	# The teaching point in an arbitrary coordinate system must be available in advance. # Declare CO1.		
	CO1=Coordinate()	[0.0,0.0,0.0,0.0,0.0,0.0,<...>]	Perform. result
	CO1.replace(1,2, 3, 4, 5, 6)	[1.0,2.0, 3.0, 4.0, 5.0, 6.0, <...>]	
	CO2 = CO1.inv()		

Method	replace()	i611 MCS
Function	Replace the world coordinate system object. (self-updated)	
Argument	[x, y, z, rz, ry, rx, parent] :	List Keyword
	x, y, z	Unit [mm] (World coordinate system)
	rz, ry, rx	Pose [deg] (Euler angle based on Z-Y-X)
	parent	Install for world coordinate system usage [-] float
Return value	If the argument is omitted, the default value will be set. Initial value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, _BASE]	
	Self-reference (Coordinate object)	
Usage examples	# Example 1: List (2 items) Any undefined value will become the original value. CO2=Coordinate() CO2.replace(7, 8)	
	<div> <div></div> <div>Result</div> <div>[7.0, 8.0, 0.0, 0.0, 0.0, 0.0, < ... >]</div> </div>	
Usage examples	# Example 2: Key words (2 words) Any undefined value will become the original value. CO3=Coordinate() CO3.replace(x=1, rx=6)	
	<div> <div></div> <div>Result</div> <div>[1.0, 0.0, 0.0, 0.0, 0.0, 6.0, < ... >]</div> </div>	

Method	shift()	i611 MCS
Function	Move objects in world coordinates. (self-updated)	
Argument	[dx, dy, dz, drz, dry, drx] :	List Keyword
	dx, dy, dz	Unit [mm] float (World coordinate system)
	drz, dry, drx	Pose [deg] float (Euler angle based on Z-Y-X)
	If the argument is omitted, it will not move.	
Return value	Self-reference (Coordinate object)	
	# Example 1: List (2 items) CO1 = Coordinate() CO1.replace(1,2,3,4,5,6) CO1.shift(80, 70)	
Usage examples	<div> <div></div> <div>Result</div> <div>[1.0,2.0,3.0,4.0,5.0,6.0]</div> </div>	
	<div> <div></div> <div>Result</div> <div>[81.0, 72.0, 3.0, 4.0, 5.0, 6.0]</div> </div>	
Usage examples	# Example 2 : Key word (1word) CO2 = Coordinate() CO2.replace(1,2,3,4,5,6) CO2.shift(dx=80)	
	<div> <div></div> <div>Result</div> <div>[1.0, 2.0, 3.0, 4.0, 5.0, 6.0]</div> </div>	
Usage examples	<div> <div></div> <div>Result</div> <div>[81.0, 2.0, 3.0, 4.0, 5.0, 6.0]</div> </div>	

Classes

Position

Handle coordinate values Position (*) of the world coordinate system.

Membership variable

—	—
Method	
clear()	Initialize the Position coordinate value. P.29
copy()	Copy the Position coordinate value. P.29
has_mt()	Check cross counter information. P.30
offset()	Add the offset coordinate value to the Position coordinate value. (create new object while maintaining itself.) P.30
pos2dict()	Get Position coordinate value in dictionary format. P.31
pos2list()	Enter Position coordinate values in list format. P.31
position()	Convert the Position coordinate value to the original coordinate system and import in list format. P.31
replace()	Replace Position coordinate values. (self-updated) P.32
shift()	Moving Position of the coordinate value. (self-updated) P.32

*) These are the coordinates that will be processed in the robot program.
We can handle not only taught coordinates but also untaught coordinates.

Created function	Position()	i611 MCS
Function	Create a version that defines teaching points in world coordinates .	
Argument	[Position] [x, y, z, rz, ry, rx, parent, posture, multiturn] : List Keyword	
Usage examples	<p>If the argument is omitted, the default value will be set.</p> <p>Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, _BASE, -1, 0xFF000000]</p> <ul style="list-style-type: none"> When creating a second or subsequent version, the most recent value will be applied Call clear() to reset the recent value and return to the original value. <p># Example 1: Ignore the argument. (Setting original value)</p> <p>P1=Position() → [0.0,0.0,0.0,0.0,0.0,0.0, <...>,-1,0xFF000000] Result</p> <p># Example 2: Key words</p> <p>P2=Position(x=1, y=2, z=3, rz=1, ry=2, rx=3, parent=_BASE, posture=1) → [1.0, 2.0, 3.0, 1.0, 2.0, 3.0, <...>, 1, 0xFF000000]</p> <p># Example 3: The value with no keyword (1 word) specified becomes the original value.</p> <p>P3=Position(rx=103) → [0.0,0.0,0.0,0.0,0.0,103.0,<...>,-1,0xFF000000]</p>	

[Position] For more information, see MotionParam Class (Page 37).

Method	clear()	i611 MCS
Function	Initialize the Position coordinate value. Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, _BASE,-1, 0xFF000000]	
Argument	None	
Return value	None	
Usage example	<pre># Initialize the Random Position object P1 # P1 Declaration. P1=Position(1,2,3,4,5,6) # Initialize P1. P1.clear()</pre> <div> <div>Result</div> <div> P1 : [1.0,2.0, 3.0,4.0,5.0,6.0, <...>,-1,0xFF000000] ↓ clear() ↓ P1 : [0.0,0.0,0.0,0.0,0.0,0.0, <...>,-1,0xFF000000] </div> </div>	



Original value of the posture parameter

posture is a 3-bit value. The original value is “-1”. Any new input will be overwritten. If not specified, the previous setting value is inherited.

Method	copy()	i611 MCS
Function	Copy the Position coordinate value.	
Argument	None	
Return value	Copy new teaching point object (Position Object)	
Usage examples	<pre># Copy any P1 Position object. # P1 Declaration. P1=Position(x=1, y=2, z=3, rz=4, ry=5, rx=6, 0xFF000000) # Copy P1 to new Position object PIC. PIC=P1.copy()</pre> <div> <div>Result</div> <div> P1 : [1.0,2.0,3.0,4.0,5.0,6.0,<...>,-1,0xFF000000] ↓ copy() ↓ New point object : PIC PIC : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, <...>, -1, 0xFF000000] </div> </div>	

Method	has_mt()		i611 MCS
Function	Check cross counter information .		
Argument	None		
Return value	res0	Presence or absence of cross counter information True : Yes False : No	
Usage example	[-] bool		

If class Position is created in the program as a parameter with cross counter information omitted, data of type Position without cross counter information will be created

Method	offset()		i611 MCS
Function	Add the offset coordinate value to the Position coordinate value. (create a new object while maintaining the object itself.)		
Argument	[dx, dy, dz, drz, dry, drx] : <div>ListKeyword</div>		
	dx, dy, dz	[mm] <div>float</div>	Offset quantity of Position (Descartes Coordinates)
	drz, dry, drx	<div>float</div> [deg]	Amount of posture offset (Euler angle series Z-Y-X)
	If the argument is omitted, Offset is not set.		
Return value	Refer to the maintained Offset value. (Position object) # Add offset coordinates to the P1 Random Position object.		
Usage examples	<div>.# P1 Declaration. P1=Position(x=1, y=2, z=3, rz=4, ry=5, rx=6) # Create a new Position object P1ofs offset from P1. P1ofs=P1.offset(dx=100, drz=-10)</div>		
	<div># In case you specify only the values you want to Offset on the list in P1, create a new Position object P1ofs.P1ofs=P1.offset(100, 0, 0, -10)</div>		

Result

P1 : [1.0,2.0,3.0,4.0,5.0,6.0,...]

↓

offset()

↓

Original Offset:P1

P1 : [1.0,2.0,3.0,4.0,5.0,6.0,...]

New point object : P1ofs

P1ofs : [101.0,2.0,3.0,-6.0,5.0,6.0,...]

New point object : P1ofs

P1ofs : [101.0,2.0,3.0,-6.0,5.0,6.0,...]

Result

P1 : [1.0,2.0,3.0,4.0,5.0,6.0,...]

↓

offset()

↓

Original Offset:P1

P1 : [1.0,2.0,3.0,4.0,5.0,6.0,...]

New point object : P1ofs

P1ofs : [101.0, 2.0, 3.0, -6.0, 5.0, 6.0, ...]

New point object : P1ofs

P1ofs : [101.0, 2.0, 3.0, -6.0, 5.0, 6.0, ...]

Method	pos2dict()	i611 MCS
Function	Enter the Position coordinate value in dictionary format. ^(*1)	
Argument	None	
Return value	[Position] : Dict	
Usage examples	<pre># Render an arbitrary P1 Position object in dictionary format ^(*2) # P1 Declaration. P1=Position(1, 2, 3, 4, 5, 6) # Export P1 in dictionary format. P1.pos2dict()</pre> <div>Result</div> <pre>{'parent':<...>,'rx':6.0,'ry':5.0,'rz':4.0,'y':2.0,'x':1.0,'z':3.0,'posture':-1,'multiturn':0xFF000000}</pre>	

Method	pos2list()	i611 MCS
Function	Enter the Position coordinate value in list format. ^(*1)	
Argument	None	
Return value	[Position] : List	
Usage examples	<pre># Render an arbitrary P1 Position object in list format.^(*2) # P1 Declaration. P1=Position(1, 2, 3, 4, 5, 6) # P1 outputs in list format. P1.pos2list()</pre> <div>Result</div> <pre>[1.0,2.0,3.0,4.0,5.0,6.0,< ... >,-1,0xFF000000]</pre>	

Method	position()	i611 MCS
Function	Convert the Position coordinate value to the original coordinate system and import in list format. ^(*1)	
Argument	None	
Return value	[Position] : List	
Usage examples	<pre># Render an arbitrary P1 Position object in list format.^(*2) # P1 Declaration. P1=Position(1, 2, 3, 4, 5, 6) # P1 outputs in list format. P1.position()</pre> <div>Result</div> <pre>[1.0,2.0,3.0,4.0,5.0,6.0,< ... >,-1,0xFF000000]</pre>	

* 1) When setting i611Robot.use_mt (True), the multiturn entry will be added to the return value.

* If i611Robot.use_mt (False) (original value) will not be added.

* 2) This example does not have cross counter information.

Method	replace()		i611 MCS								
Function	Replace the Position coordinate value. ^(*1) (self-updated)										
Argument	<div>[Position] : List Keyword</div> <div>If the argument is omitted, the value will not be updated.</div>										
Return value	Self-reference (Position object)										
Usage examples	<div># Replace arbitrary Position objects P1, P2, and P3.^(*2) # Declaration P1, P2, P3. P1=Position() P2=Position() P3=Position() # Example 1: When specifying as a list P1.replace(1, 2, 3, 4, 5, 6) # Example 2: When specifying two variable arguments P2.replace(7, 8) # Example 3: When specified with two keywords P3.replace(x=1, rx=6)</div> <div><table><tr><th></th><th>Result</th></tr><tr><td>P1 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()</td><td>P1 : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, < ... >, -1, 0xFF000000]</td></tr><tr><td>P2 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()</td><td>P2 : [7.0, 8.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000]</td></tr><tr><td>P3 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()</td><td>P3 : [1.0, 0.0, 0.0, 0.0, 0.0, 6.0, < ... >, -1, 0xFF000000]</td></tr></table></div>				Result	P1 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()	P1 : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, < ... >, -1, 0xFF000000]	P2 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()	P2 : [7.0, 8.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000]	P3 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()	P3 : [1.0, 0.0, 0.0, 0.0, 0.0, 6.0, < ... >, -1, 0xFF000000]
	Result										
P1 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()	P1 : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, < ... >, -1, 0xFF000000]										
P2 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()	P2 : [7.0, 8.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000]										
P3 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >, -1, 0xFF000000] ↓ replace()	P3 : [1.0, 0.0, 0.0, 0.0, 0.0, 6.0, < ... >, -1, 0xFF000000]										

Method	shift() <div>i611 MCS</div>	
Function	Move the Position coordinate value. ^(*1) (Self-updated)	
Argument	[dx, dy, dz, drz, dry, drx] : <div>ListKeyword</div>	
	dx, dy, dz [mm] <div>float</div>	Amount of movement in position (Descartes Coordinates)
	drz, dry, drx [deg] <div>float</div>	amount of movement in the pose (Euler angles based on Z-Y-X)
	Do not move if arguments are omitted	
Return value	Self-reference (Position object)	
Usage examples	<div># Move Random position P1 object.^(*2)</div> <div># P1 declaration.</div> <div>P1=Position(1, 2, 3, 4, 5, 6)</div> <div># Update P1 to the moved location.</div> <div>P1.shift(dx=80)</div>	<div>Result</div> <div>P1 : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0, < ... >, -1, 0xFF000000]</div> <div>↓</div> <div><div>shift()</div></div> <div>↓</div> <div>First object:P1</div> <div>P1 : [81.0, 2.0, 3.0, 4.0, 5.0, 6.0, < ... >, -1, 0xFF000000]</div>

* 1) When setting i611Robot.use_mt (True), the multiturn entry will be added to the return value.

* If i611Robot.use_mt (False) (initial value) will not be added.

* 2) This example does not have cross counter information.

Class

Joint

Process the angle data of joint coordinate values in the joint coordinate system (*)

Member variable		
j1, j2, j3, j4, j5, j6	Joint angle	
Method		
clear()	Initialize the joint coordinate value .	P.34
copy()	Copy the joint coordinate value.	P.34
jnt2dict()	Enter the joint coordinate value in dictionary format.	P.34
jnt2list()	Enter the joint coordinate value in list format.	P.35
offset()	Add the offset coordinate value to the joint coordinate value. (create a new object while maintaining the object itself.)	P.35
replace()	Replace joint coordinate values. (self-updated.)	P.36
shift()	Move joint coordinate values. (self-updated.)	P.36

*) Joint coordinate value

These are the coordinates processed by the program.

It is possible to handle only taught coordinates but also untaught coordinates.

Created function	Joint()
Function	Create an entity that defines the teaching point of the Joint coordinate system.
Argument	<div>[Joint] [j1, j2, j3, j4, j5, j6] :</div>
Return value	<p>If the argument is omitted, the default value will be set. Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]</p> <p>Self-referrence (Joint object)</p>
Usage examples	<p># Example 1: Ignore the argument. (Set original value.)</p> <div> <div>J1=Joint()</div> <div>Result quá</div> <div>[0.0, 0.0, 0.0, 0.0, 0.0, 0.0]</div> </div> <p># Example 2: List</p> <div> <div>J2=Joint(1, 1, 1, 1, 1, 1)</div> <div>[1.0, 1.0, 1.0, 1.0, 1.0, 1.0]</div> </div> <p># Example 3: Key words (6)</p> <div> <div>J3=Joint(j1=1, j2=2, j3=3, j4=4, j5=5, j6=6)</div> <div>[1.0, 2.0, 3.0, 4.0, 5.0, 6.0]</div> </div> <p># Example 4: Key words (1). Any undefined value will become the original value.</p> <div> <div>J4=Joint(j6 = 6)</div> <div>[0.0, 0.0, 0.0, 0.0, 0.0, 6.0]</div> </div>

Method	clear()	i611 MCS
Function	Initialize the joint coordinate value. Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]	
Argument	None	
Return value	None	
Usage example	<pre># Initialize random Joint object J1. # J1 declaration. J1=Joint(1,2,3,4,5,6) # Initialize J1. J1.clear()</pre> <div> <div>Result</div> <pre>J1 : [1.0,2.0,3.0,4.0,5.0,6.0] ↓ clear() ↓ J1 : [0.0,0.0,0.0,0.0,0.0,0.0]</pre> </div>	

Method	copy()	i611 MCS
Function	Copy the joint coordinate value.	
Argument	None	
Return value	Copy the new Joint coordinate object (Joint object)	
Usage examples	<pre>#Copy any Joint J1 object. # J1 declaration. J1=Joint(j1=1, j2=2, j3=3, j4=4, j5=5, j6=6) # Copy J1 to new common object J1C. J1C=J1.copy()</pre> <div> <div>Result</div> <pre>J1 : [1.0,2.0,3.0,4.0,5.0,6.0] ↓ copy() ↓ new point object : J1C J1C : [1.0,2.0,3.0,4.0,5.0,6.0]</pre> </div>	

Method	jnt2dict()	i611 MCS
Function	Enter the joint coordinate value in dictionary format.	
Argument	None	
Return value	[Joint] : Dict	
Usage examples	<pre># Export an arbitrary Joint object J1 in dictionary format.. # J1 declaration. J1=Joint(1, 2, 3, 4, 5, 6) # Export J1 in dictionary format. J1.jnt2dict()</pre> <div> <div>Result</div> <pre>{'j4': 4.0, 'j5': 5.0, 'j6': 6.0, 'j1': 1.0, 'j2': 2.0, 'j3': 3.0}</pre> </div>	

Method	jnt2list()	i611 MCS
Function	Enter the joint coordinate value in list format.	
Argument	None	
Return value	[Joint] : List	
Usage examples	<pre># Export arbitrary Joint object J1 in list format # J1 declaration. J1=Joint(1, 2, 3, 4, 5, 6) # Export J1 in list format. J1.jnt2list()</pre> <div>Result: [1.0,2.0,3.0,4.0,5.0,6.0]</div>	

Method	offset()	i611 MCS
Function	Add offset coordinates to joint coordinates. (Create a new object while maintaining the object itself.)	
Argument	[dj1, dj2, dj3, dj4, dj5, dj6] : List Keyword Joint angle compensation amount dj1, dj2, dj3, dj4, dj5, dj6 [deg] If the argument is omitted then the offset is not set. New angle object for each axis (Joint object)	
Return value		
Usage examples	<pre># Add J1 offset coordinates to the random Joint object.. # J1 declaration. J1=Joint(1, 2, 3, 4, 5, 6) # Create a new joint object J1ofs offset from J1. J1ofs=J1.offset(dj1=80, dj6=-30) # In case of only specifying a number as the value you want to Offset at J1 # How to set dj1, dj2 in list form J2ofs=J1.offset(80, -30)</pre> <div>Result: <pre>J1 : [1.0,2.0,3.0,4.0,5.0,6.0] ↓ offset() ↓ First object:J1 J1 : [1.0,2.0,3.0,4.0,5.0,6.0] New point object : J1ofs J1ofs : [81.0, 2.0, 3.0, 4.0, 5.0, -24.0] New point object : J2ofs J2ofs : [81.0, - 28.0, 3.0, 4.0, 5.0, 6.0]</pre> </div>	

Method	replace()	i611 MCS
Function	Replace the joint coordinate value. (self-updated)	
Argument	[Joint] : List Keyword	
Return value	If the argument is omitted, the value will not be updated.	
Usage examples	<p>Self-reference (Joint objects)</p> <pre># Replace arbitrary Joint objects J1, J2, J3. # Declaration for J1, J2, J3. J1=Joint() J2=Joint() J3=Joint()</pre> <div> <div> <p># Example 1: When specified in the list</p> <p>J1.replace(1,2,3,4,5,6)</p> </div> <div> <p>Result</p> <p>J1 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]</p> <p>↓ replace()</p> <p>J1 : [1.0, 2.0, 3.0, 4.0, 5.0, 6.0]</p> </div> </div> <div> <div> <p># Example 2: When specifying two variable arguments</p> <p>J2.replace(7,8)</p> </div> <div> <p>J2 : [0.0,0.0,0.0,0.0,0.0,0.0]</p> <p>↓ replace()</p> <p>J2 : [7.0,8.0,0.0,0.0,0.0,0.0]</p> </div> </div> <div> <div> <p># Example 3: When specified with two keywords</p> <p>J3.replace(j1=1,j6=6)</p> </div> <div> <p>J3 : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]</p> <p>↓ replace()</p> <p>J3 : [1.0, 0.0, 0.0, 0.0, 0.0, 6.0]</p> </div> </div>	

Method	shift()	i611 MCS
Function	Move joint coordinate values (Self-updated)	
Argument	[dj1, dj2, dj3, dj4, dj5, dj6] : List Keyword	
Return value	<p>dj1, dj2, dj3, dj4, dj5, dj6</p> <p>[deg]</p> <p>float</p> <p>Degree of movement of the joint angle</p> <p>Original value : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]</p> <p>If the argument is omitted, the amount of movement will not be set.</p>	
Usage examples	<p>Self-reference (Joint objects)</p> <pre>#Randomly move common object J1. # J1 declaration. J1.replace(1, 2, 3, 4, 5, 6) # Move J1 to update itself. J1.shift(dj1=80)</pre> <div> <div> <p>Result</p> <p>J1 : [1.0,2.0, 3.0, 4.0,5.0, 6.0]</p> <p>↓</p> <p>shift()</p> <p>↓</p> <p>First object: J1</p> <p>J1 : [81.0, 2.0, 3.0, 4.0, 5.0, 6.0]</p> </div> </div>	

Class

MotionParam

Handle robot motion parameters.

Membership variable		
lin_speed	Speed (Line operation (linear interpolation operation))	P.38
jnt_speed	Speed (PTP operation, joint operation, optimal linear interpolation operation)	P.38
acctime	Acceleration time	P.38
dacctime	Deceleration time	P.39
posture	Posture	P.39
passm	Operate Pass	P.39
overlap	Gaps overlap	P.40
zone	Complete range of positioning	P.40
pose_speed	Speed (pose interpolated motion)(*)	P.41
ik_solver_option	Direction of rotation	P.41
Method		
clear()	Initialize motion parameters.	P.43
confdefault()	Set the initial value of the operating parameter.	P.43
copy()	Copy operating parameters.	P.44
motionparam()	Set operating parameters	P.45
mp2dict()	Enter action parameters in dictionary format.	P.46
mp2list()	Enter action parameters in list format.	P.46


*) The Manipulator head changes direction and operates, then sets the upper limit of the machine head's Euler angular motion speed.





Setting acceleration/deceleration too fast may cause the robot to vibrate.
Initial parameter adjustment must be done by gentle acceleration and deceleration to ensure no vibration occurs in the robot.



Member variable of type MotionParam

Member variable	lin_speed		
Function	Speed (Line operation (linear interpolation operation))	Unit/Type Original value	5.0 [mm/s] <input type="text" value="float"/>
Supplement	<p>Is the act of moving at a constant speed so that the trajectory to the destination is a straight line while simultaneously controlling the X-Y-Z axes synchronously.</p> 		

Member variable	jnt_speed		
Function	Speed (PTP operation, joint operation, optimal linear interpolation operation)	Unit/type Original value	5.0 [%] <input type="text" value=""/>
Supplement	<p>All joints move at a constant speed and angle toward the target coordinates. Motion moves in a smooth curve. The optimal linear interpolation motion also sets the speed according to jnt_speed. Set to % of maximum speed for numeric change.</p> <p>PTP operation, Joint operation</p>  <p>Optimal linear interpolation operation</p> 		

Member variable	acctime		
Function	Acceleration time	Unit/Type Original value	0.4 [s] <input type="text" value="float"/>
Supplement	<p>Set the time to reach the set speed in lin_speed, jnt_speed.</p> <p>Movement speed Overwritten part (override()) It is possible to limit the operating speed using overrides.</p> <p>Setting jnt_speed, lin_speed Sudden acceleration</p> <p>Short (= Sudden acceleration) Long</p> <p>Time</p>		


Member variable	dacctime		
Function	Deceleration time	Unit/Type Original value	0.4 [s] <code>float</code>
Supplement	Time from speed set in lin_speed, jnt_speed to deceleration and stopping at target coordinates. 		


Member variable	posture		
Function	Posture	Unit/Type Original value	2 [-] <code>integer</code>
Supplement	Installation range : 0 -7 The position of the manipulator is defined as: ① Arm unit ② Joint angle Example: Original value 「 2 」		

For more information about posture, please refer to the book “Coordinate Systems and posture”.


Member variable	passm		
Function	Pass activity	Unit/Type Original value	2 [-] <code>integer</code>
Supplement	Installation value : 1=ON , 2=OFF By enabling the passm operation parameter, you can bypass the waiting time between operations and shorten the overall operation time. 		

If asyncm(1) overlap (predictive read) is used, it will always operate in the ON state regardless of the passm parameter setting.

Member variable	overlap		
Function	Overlapping distance	Unit/Type g Original value	0.0 [mm] <input type="text" value="float"/>
Supplement	<p>As soon as the target point (B) is approached, the next overlapping movement will begin..</p> <p>The robot can be moved smoothly without stopping motion at the prepared transition point (B) to perform obstacle avoidance actions.</p> <div data-bbox="979 539 1372 840">  <p>Example: Overlap = 30mm</p> </div>		

Member variable	zone		
Function	Complete range of positioning	Unit/Type g Original value	100 [pulse] <input type="text" value="integer"/>
Supplement	<p>Set the encoder pulse range so that the end of the robot arm approaches the target point and determine whether positioning is complete or not</p> <div data-bbox="916 1151 1396 1429">  </div>		

Member variable	pose_speed		
Function	Speed (Postural interpolation motion)	Unit/Type Original value	20 [%] float
Supplement	<p>Installation value : 100% = 45deg/s</p> <p>When the manipulator head operates and changes direction, set the upper limit of the movement speed of the final Euler angle .</p>		

Member variable	ik_solver_option		
Function	Rotation direction	Unit/Type Original value	0x11111111 [-] long
Supplement	<p>Specify the direction of rotation of each axis when moving to the coordinates specified in the Position type or converting from the Position type to the Joint type.</p> <p>0 x <u>1 1 1 1 1 1 1</u> (Rsv.) J6 J5 J4 J3 J2 J1</p> <p>Setting J1 -J6 0 : This is a rotation that does not use information from shortcuts. 1 : Use information from the multiturn parameter. 2 : Rotate toward direction +. 3 : Rotate toward direction -. Refer to the figure on the right for the +, direction -</p> 		

Created function	MotionParam()	i611 MCS
Function	Create an instance of the robot's motion parameters	
Argument	<p><code>[MotionParam]</code></p> <p><code>[lin_speed,jnt_speed,acctime,dacctime,posture,passm,overlap,zone,pose_speed,ik_solver_option]</code></p> <p> List Keyword </p> <p>.</p> <p>If the argument is omitted, the default value will be set.</p> <p>Original value : <code>[5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20, 0x11111111]</code></p>	
Return value	Self-reference (MotionParam object)	
Usage examples	<p>#Example 1: Ignore the argument. (Set initial value)</p> <p><code>m=MotionParam()</code></p> <div> <p>Result</p> <p>Original value : <code>[5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</code></p> <p>↓</p> <p>MotionParam</p> <p>↓</p> <p>Operating argument</p> <p>m : <code>[5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</code></p> </div> <p># Example 2: Set the action parameter specified in the argument.</p> <p><code>m=MotionParam(lin_speed=70, jnt_speed=10, overlap=30)</code></p> <div> <p>Original value : <code>[5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</code></p> <p>↓</p> <p>MotionParam</p> <p>Specify argument</p> <p>↓</p> <p>Operating argument</p> <p>m : <code>[70.0, 10.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]</code></p> <p>lin speed jnt speed overlap</p> </div>	

Method	clear()		i611 MCS
Function			
Argument	None		
Return value	None		
Usage examples	#Initialize a random MotionParam object m.		
	# Declaration m.		
	m=MotionParam(lin_speed=70, jnt_speed=10, overlap=30)		
			Result
		m : [70.0, 1.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]	
		↓	
	m.clear()	clear()	
		↓	
		m : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]	i611 MCS

Method	confdefault()
Function	Change the original value of the operating parameter.
Argument	[MotionParam] : Keyword
Return value	None
Usage examples	<div><div><div>m.clear()</div><div>m.confdefault(lin_speed=70,overlap=30)</div></div><div><div>Original value before change : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</div><div>Original value after change : [70.0, 5.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]</div></div></div> <div><div>lin_speed</div><div>overlap</div></div> <div><div>confdefault</div></div> <div>Kết quả</div>



Original value setting time of operating parameters

The initial value change setting in the confdefault() method will be reflected the next time when a version of the MotionParam class is created, copied, or deleted.

Method	copy()	i611 MCS
Function	Copy operating parameters.	
Argument	[MotionParam] List Keyword	
Return value	<p>If specified the argument will change the currently set operating parameter for copying. If the argument is omitted, the current setting operation parameter value will be copied.</p> <p>Copied new motion parameters (MotionParam object)</p>	
Usage examples	<p># Motion parameters must be preset in MotionParam.</p> <pre>m=MotionParam(jnt_speed=10, lin_speed=70, overlap=30)</pre> <p># Example 1: Ignore the argument. (The operating parameters are currently set)</p> <pre>mcopy = m.copy()</pre> <div> <p>Result</p> <p>Value : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</p> <p>↓</p> <p>MotionParam</p> <p>↓</p> <p>Operating parameters</p> <p>m : [70.0, 10.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]</p> <p>↓</p> <p>copy (Argument omitted)</p> <p>↓</p> <p>Copy operation parameters</p> <p>mcopy : [70.0, 10.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]</p> </div> <p># Example 2 : Change and copy action parameters specified in arguments.</p> <pre>mconv = m.conv(int speed=15)</pre> <div> <p>Operating parameters</p> <p>m : [70.0, 10.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]</p> <p>↓</p> <p>copy</p> <p>Specify arguments</p> <p>↓</p> <p>Copied action parameters</p> <p>mconv : [70.0, 15.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111]</p> </div>	

Method	motionparam() i611 MCS
Function	Set operating parameters.
Argument	<p>[MotionParam] : List Keyword</p> <p>If the argument is omitted, the default value will be set. Original value : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</p>
Return value	Self-reference (MotionParam object)
Usage examples	<p># Motion parameters must be preset in MotionParam. m=MotionParam()</p> <p># Example 1: Ignore the argument. (Set initial value)</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: right;">Result</p> <pre> m : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111] ↓ motionparam (Argument is omitted) ↓ mm : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111]</pre> </div> <p># Example 2: Change operating parameters. mm=m.motionparam(lin_speed=70, jnt_speed=10, overlap=30)</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> m : [5.0, 5.0, 0.4, 0.4, 2, 2, 0.0, 100, 20.0, 0x11111111] ↓ motionparam Set argument ↓ mm : [70.0, 10.0, 0.4, 0.4, 2, 2, 30.0, 100, 20.0, 0x11111111] lin_speed jnt_speed overlap</pre> </div>

Method	mp2dict()	i611 MCS
Function	Get action parameters in dictionary format.	
Argument	None	
Return value	[MotionParam] : Dict	
Usage examples	<p># Example: Preset motion parameters in MotionParam.</p> <pre>m=MotionParam(lin_speed=70, jnt_speed=10, overlap=30) modict = m.mp2dict()</pre> <p>Result: {'lin_speed': 70.0, 'zone': 100, 'acctime': 0.400, 'pose_speed': 20.0, 'dactime': 0.400, 'overlap': 30.0, 'passm': 2, 'jnt_speed': 10.0, 'posture': 2}</p> <p># Get the value directly.</p> <pre>lin_speed = m.mp2dict()['lin_speed']</pre> <p>Result: lin_speed=70.0</p>	
Method	mp2list()	i611 MCS
Function	Get operation parameters in list format.	
Argument	None	
Return value	[MotionParam] : List	
Usage examples	<p># Example: Preset motion parameters in MotionParam.</p> <pre>m=MotionParam(lin_speed=70, jnt_speed=10, overlap=30) molist=m.mp2list()</pre> <p>Result: [70.0,10.0,0.400,0.400, 2, 2, 30.0,100,20.0]</p> <p># Only receive the specified quantity.</p> <pre>molist=m.mp2list()[0:2]</pre> <p>print molist [70.0,10.0]</p> <p># Get value directly.</p> <pre>lin_speed=m.mp2list()[0]</pre> <p>print lin_speed lin_speed=70.0</p>	

Class		
i611Robot		
Handling robot movements.		
Member variable		
-	-	P.38
Method		
abort()	Stop the robot program.	P.50
adjust_mt()	Fix CC value when converting position type coordinates to string.	P.50
asyncm()	Set up the predicted motion part of the robot program.	P.51
cause_user_error()	A user-defined error arises.	P.52
changetool()	Select Tool Offset.	P.52
check_ready()	Check if the robot can drive itself or not.	P.53
close()	Disconnect from the robot.	P.54
disable_mdo()	Disable MDO action.	P.54
enable_interrupt()	Make exceptions for deceleration stops and emergency stops.	P.55
enable_mdo()	Enable MDO behavior.	P.56
exit()	Force to quit the robot program.	P.57
get_hw_info()	Get the model name and serial number.	P.57
get_system_port()	Get the status of system ports.	P.58
get_system_status()	Get system status and error ID.	P.59
getjnt()	Get the current position of the manipulator in Joint form.	P.59
getmotionparam()	Get current operating parameters.	P.60
getpos()	Get the operator's current position in the Location type.	P.60
home()	Move all axes to joint coordinates 0 degrees .	P.60
is_open()	Check the open status of i611Robot.	P.61
is_pause()	Check the pause status of the robot program.	P.61
join()	Wait for the predicted robot program operation to complete.	P.63
Joint2Position()	Convert joint coordinate values to position coordinate values.	P.63
line()	Perform linear interpolation motion.	P.64
MCS_version()	Download the robot library version.	P.65
motionparam()	Set operating parameters.	P.65
move()	Carry out PTP activities.	P.66
open()	Start connecting to the robot. (reinstall)	P.67
optline()	Linear interpolated motion is performed while shifting gears at optimal speed..	P.68
override()	Override	P.69
pause()	Pause the robot's movements.	P.69
Position2Joint()	Convert from Position coordinates to Joint coordinates.	P.70

(i611Robot method)

Method		
release_stopevent()	Reset an exception event that is occurring.	P.70
reljntmove()	Relative movement is performed in the joint coordinate system.	P.71
relline()	The relative linear interpolation operation is performed in the Descartes coordinate system.	P.72
restart	Emit a continue signal after a pause.	P.73
set_behavior()	Set the operation (action) when paused.	P.74
set_mdo()	Set up MDO behavior.	P.75
settool()	Set up Tool offset.	P.76
sleep()	Pause for a certain period of time.	P.77
stop()	Decelerate the robot to stop.	P.78
svoff()	Set servo to OFF.	P.78
svstat()	Get servo status.	P.79
toolmove()	Relative operation in the Tool coordinate system.	P.79
use_mt()	Set cross counter on/off.	P.80
user_hook()	Pause the robot program.	P.80
version()	Get system version.	P.81

Created function	i611Robot()		i611 MCS
Function	Create an instance of class i611.		
Argument	[host, port] : List Keyword		
	host	Destination IP address Initial value : '127.0.0.1'	
	port	Number of connection ports Initial value : 12345	
Return value	If you omit the argument, the default value will be set.		
	Return to that class main object.		
Usage examples	# Example 1: Omit argument (Set initial value.) rb=i611Robot()		
	# Example 2: List rb=i611Robot('127.0.0.1', 12345)		
	# Example 3: Keyword arguments (specify all) rb= i611Robot(host='127.1.1.1', port=10000)		
	# Example 4: Keyword arguments (identify the server only) rb= i611Robot(host='127.1.1.1')		
	# Example 5: Keyword arguments (specify port only) rb= i611Robot(port=3000)		




Restrict the i611Robot class

The i611Robot class cannot be used in the servo OFF state. (Including status at start-up, emergency stop, main power OFF and system error)
The servo ON state is also indicated by the LED (SVO) on the controller















The i611Robot entity can only be created once in a program.

When looping within a program, create an instance of class i611Robot before the loop.



Method	abort()	i611 MCS
Function	Stop the robot program.(*)	
Argument	None	
Return value	None	
Usage example	rb.abort()	

*) Only activated when the robot is moving.

Method	adjust_mt()	i611 MCS
Function	Fix cross counter value when converting position type coordinates to string.	
Argument	The string is converted to Position coordinates used as the origin [pos, str_x, str_y, str_z, str_rz, str_ry, str_rx] : 	
	pos	: Position coordinates are used as the origin
	 [-]	 x coordinate string
	 [-] 	y coordinate string
	 [-] 	z coordinate string
	 [-] 	rz coordinate string
	 [-] 	ry coordinate string
	 [-] 	rz coordinate string
Return value	 Cross-counting is corrected	
Usage examples	<pre> rb=i611Robot() rb.open() pos = rb.getpos() pos_value = pos.position() pos_str = [str(round(x,2)) for x in pos_value[0:6]] new_mt = rb.adjust_mt(pos, pos_str[0], pos_str[1], pos_str[2], pos_str[3], pos_str[4], pos_str[5]) pos_str += [str(pos_value[7]), "0x%06X" % new_mt] print "Position String:%s" % pos_str </pre>	



Method	asyncm()		i611 MCS
Function	Set up the predicted motion part of the robot program.		
Argument	SW [-]	1 : Program prediction operation is ON 2 : Program prediction operation OFF (default value)	
Return value	If successful : True <small>integer</small> If it fails: An exception arises <small>pool</small> .		
Usage examples	<pre> rb.line(p10) #Perform linear interpolation motion at teaching point p10.. rb.asyncm(sw=1) # Program prediction operation ON (also available in rb.asyncm (1)) rb.line(p20,p21) #Move to teaching points p20 and p21 in the order of performing linear interpolation.. rb.join() # Wait for completion of the robot program's predicted actions. rb.asyncm(sw=2) #Program prediction operation OFF (also possible in rb.asyncm (2)) ... rb.close() </pre>		

Method	cause_user_error()		i611 MCS
Function	A user-defined error arises.		
Argument	[code, critical] : <div>List</div> <div>Keyword</div>		
	code		Error ID
	<div>Can</div> [-] <div>integer</div>		Installation range : 1 -99
	critical		True : A user-defined error arises
Return value		[-] <div>bool</div>	False : A user-defined error occurred (default value)
	None		
Usage value	# When a user-defined error occurs (Error ID: 19) rb.cause_user_error(19, False) # User-defined error - When a fatal error occurs (Error ID: 01) rb.cause_user_error(01, True)		



About user-defined errors

If you use the error ID (which cannot be optionally omitted) to execute the cause_user_error() method, the Robot program will end when an error occurs..

User-defined error	Error reset method	7-segment LED light
Serious	Reconnect the power source	
Error	' Error reset signal '	

Method	changetool()		i611 MCS
Function	Select Tool Offset.		
Argument	tid	Tool number	
	<div>integer</div> <div>Need [-]</div>	0 : Tool offset OFF. 1 -8 : Select Tool offset.	
Return value	Successful : True [-]		
	Unsuccessful : An exception occurred.		
Usage value	<pre># 1 . Preset Tool Offset. rb.settool(1, 0.0, 0.0, 200.0, 0.0, 0.0, 0.0) # Set Tool No.1. # 2 . Select Tool Offset. # Example 1: Specify value rb.changetool(1) # Select Tool No.1 # Example 2: Key word rb.changetool(tid=1) # Select Tool No.1</pre>		

Method	check_ready()			i611 MCS
Function	Check whether the robot can work automatically or not.			
Argument	None			
Return value	res	[-]	integer	Can drive automatically. 0 : Run the robot program
				Cannot drive automatically. can run programs that do not involve robot movements. 1 : Emergency stop in progress. 2 : servo is OFF. 3 : Not in automatic mode. (JOG bar is connected) 4 : Permission to operate is not granted. 5 : Other errors are occurring.
Usage example	res = i611Robot.check_ready() if res != 0: ... #Displays messages and notifications of external output			




How to use check_ready method ()

Is a method that confirms whether the open() method of the i611Robot class is implemented in the dictionary

If the return price is not '0', the robot will not work.

An exception occurred when executing open() or the constructor of class i611Robot. By checking the state in this Method, it is possible to prevent exceptions from occurring.

Example) If running the automatic operation program with the JOG bar connected to the controller...



Method	close()		i611 MCS
Function	Disconnect from the robot.		
Argument	None		
Return value	Successful : True [-] (Only return when successful.)		
Usage value	rb.close()		







Go to exit () and close ()




Exit() processing is also implemented with close() processing.

Method	disable_mdo	
Function	Turn off MDO behavior.	
Argument	bitfield [-] integer	MDO management number (*1) Set the bit corresponding to the disabled MOD management number. Installation range : 0 -255
Return value	Successful : True [-] bool	
Usage examples	Failed : An exception occurred.	
	<pre># Preset MDO operation settings (*2) rb.set_mdo(1, 23, 0, 1, 30) rb.set_mdo(8, 23, 1, 2, 10) rb.enable_mdo(129) # Activate MDO management No. 1 and 8 # Turn off MDO behavior # Example 1: Specify value rb.disable_mdo(129) # Disable MDO management No. 1 and 8 # Example 2: Key words rb.disable_mdo(bitfield=129) # Management MDO disabled No. 1 and 8</pre>	

* 1) For bit field settings, please refer to "Setting MDO management numbers using bit fields" on page 56.

* 2) See page 75 for more information about set_mdo() and page 56 for Enable_mdo().

Method	enable_interrupt()		i611 MCS
Function	Set the exception occurrence for emergency stop and deceleration stop.		
Argument	[eid, enable] : 		
	eid	[-] 	<p>Event code</p> <p>0 : An exception occurred when entering the deceleration stop command during operation</p> <p>1 : An exception occurs when an emergency stop signal occurs during operation</p> <p>2 : An exception occurs when entering the deceleration stop command during a pause</p> <p>3 : An exception occurs when entering the emergency stop state during a pause</p> <p>In case an exception is turned off, the Robot program ends normally.</p>
	enable	[-] 	<p>An exception arises</p> <p>True : activated</p> <p>False : OFF</p>
	res0	[-] 	<p>True : Successful</p> <p>False : Unsuccessful</p>
Return value			
Usage examples	<pre># Example 1: An exception is allowed when entering the deceleration stop command during operation. rb.enable_interrupt(0, True) # Example 2: Allow creating exceptions when an emergency stop command is entered during operation. rb.enable_interrupt(1, True) # Example 3: Disable the possibility of an exception when entering a deceleration stop command during a pause. rb.enable_interrupt(2, False) # Example 4: Disables the feature of an emergency stop exception occurring during a pause. rb.enable_interrupt(3, False)</pre>		

Method	enable_mdo()		i611 MCS
Function	Enable MDO activity (*1).		
Argument	bitfield  [-] 	MDO management number (*2) Set the bit corresponding to the active MOD management number. Installation range : 0 -255	
Return value	Successful : True [-] 		
Usage examples	Unsucessful : An exception occurred.		
	<pre># Preset MDO operation settings (*3) rb.set_mdo(1, 23, 0, 1, 30) rb.set_mdo(8, 23, 1, 2, 10) # Enable MDO behavior # Example 1: Specify a value rb.enable_mdo(129) # Activate MDO management No.1 and 8 . # Example 2: Key words rb.enable_mdo(bitfield=129) # MDO 관리 번호 1, 8 을 활성화합니다 .</pre>		

* 1) MDO operation is a function that shorts or opens an I/O output under conditions specified in operation.

* 2) For bit field settings, refer to "Setting MDO management numbers using bit fields" on page 56.

* 3) See page 75 for more details about set_mdo().



Set the MDO management number according to the bit field

Enable_mdo() can turn ON/OFF each mdo operation at the same time.

Example) Activate management No.8 and 1.

```
rb.enable_mdo(bitfield=129)
```

Number
symbol

8

Number
symbol

1

1000 0001

Activate management No.1.

Activate management No. 8.



Numbers can be set at the same time with Enable_mdo()

There are a total of 4 MDOs that can be enabled in the enable_mdo() method. Selection in MDO settings in set_mdo() method.

Even if you run allow_mdo() multiple times, it cannot be enabled more than 5 times at the same time..

Method	exit()		i611 MCS
Function	Force to quit the robot program.		
Argument	res [-]	0 : Normal ending 0 khác : Unusual ending	
Return value	Noneinteger		
Usage examples	rb.exit(0)		



Regarding exit() method

If the robotics program is successfully completed, this Method will not be needed.

- Exit() processing is also implemented with close() processing.
- The exit() method is equivalent to sys.exit() in the standard Python library sys module.

When the robot program is terminated by specifying a non-zero argument

The controller generates a system-determined error and the robot program terminates abnormally. In this error, the 'reset' signal is injected into the recovery I/O.

For port allocation, please refer to “3 Memory Maps”.

Method	get_hw_info()		i611 MCS
Function	Get the model name and serial number.		
Argument	None		
Return value	[model name, serial number] : List		
	model name [-] string Model name		
	serial number [-] string Serial number		
Usage example	model, serial = i611Robt.get_hw_info()		

This method is a static method. This method can be called without specifying an instance of the i611Robot class.

get_system_port()

Function	Get the status of system ports		i611 MCS
Argument	None		
Return value	[running, svon, emo, hw_error, sw_error, abs_lost, in_pause, error, (rsv.)] :		
Return value	running	[-]	Robot program status 1 : Running (Displayed on the controller LED (STS))
	svon	[-]	0 : Stopping
	emo	[-]	servo status
	hw_error	[-] <small>integer</small>	1 : Turn on the servo 0 : Turn off the servo
	sw_error	[-] <small>integer</small>	Emergency stop condition 1 : Emergency stop in progress
	abs_lost	[-]	0 : None
	in_pause	[-] <small>integer</small>	System-determined error condition (critical) 1 : An error occurred
	error	[-] <small>integer</small>	0 : None The error state is determined by the system 1 : An error is occurring
		[-] <small>integer</small>	0 : None Loss of ABS 1 : Loss of ABS
			0 : None
			pause status 1 : Pause 0 : No
			system error condition (*) 1 : A system error occurred 0 : No
	(rsv.)	[-] <small>integer</small>	(Expected)
# Check the status of each system.			

Usage examples

```
running = rb.get_system_port()[0]      # robot program status
svon = rb.get_system_port()[1]         # servo status
emo = rb.get_system_port()[2]          # emergency stop condition
hw_error = rb.get_system_port()[3]     # Error condition determined by the system (serious)
sw_error = rb.get_system_port()[4]     # Error condition determined by the system
abs_lost = rb.get_system_port()[5]     # Loss of ABS
in_pause = rb.get_system_port()[6]     # pause state
error = rb.get_system_port()[7]        # system error condition
```

Method	get_system_status()	i611 MCS
Function	Get system status and error ID.	
Argument	None [status, err_id] :	
Return value	<div> <div>List</div> <div>System status [Controller symbol]</div> </div>	
	<div> <div>status</div> <div> <div>[-] integer</div> <div> <div>1 : Start up [</div> <div>2 : standby state</div> <div>3 : Loss of ABS</div> <div>4 : Teaching []</div> <div>6 : The robot program is running</div> <div>10: A specified system error is occurring</div> <div>11. System error is occurring (serious)</div> <div>12. An error is occurring</div> <div>13. An error is occurring (serious)</div> </div> </div> </div> <div> <div>(88 :ID error)</div> </div>	
err_id	<div>ID error</div> <div>Error ID is the value displayed on the 7-segment LED display when an error occurs.</div>	
	<div>[-] List (usually 0)</div>	
Usage examples	<div># Call by static method</div> <div>status, err_id = i611Robot.get_system_status()</div>	

This method is a static method. This method can be called without specifying an instance of the i611Robot class.

Method	getjnt()	i611 MCS
Function	Get the current position of the manipulator in Joint form.	
Argument	None	
Return value	<div>Successful : <div>[Joint]</div> : <div>List</div></div>	
	Unsuccessful : An exception occurred.	
Usage examples	<div>rb.home()</div> <div>pos01=rb.getjnt()</div>	

Method	getmotionparam()	i611 MCS
Function	Get current operating parameters.	
Argument	None	
Return value	Successful : <code>[MotionParam]</code> : Can reference an element set by the MotionParam class.	
	Unsuccessful : An exception occurred.	
Usage example	<pre># MotionParam's entity reference. t_lin_speed=rb.getmotionparam().lin_speed t_lin_overlap=rb.getmotionparam().overlap</pre>	

For details about the MotionParam format, please refer to P.37~.

Method	getpos()	i611 MCS
Function	Get the current position of the manipulator as position.	
Argument	None	
Return value	Successful : <code>[Position]</code> : <code>List</code>	
	Unsuccessful : An exception occurred.	
Usage examples	<pre>rb.home() pos01=rb.getpos()</pre>	

Method	home()	i611 MCS
Function	Move so that the joint value of all axes is 0 degrees.	
Argument	None	
Return value	Successful : True [-]	
	Unsuccessful : An exception occurs.	
Usage examples	<pre>rb.home()</pre>	

Method	is_open()		i611 MCS
Function	Check the open status of i611 Robot.		
Argument	None		
Return value	res0 <div><div></div><div>[-] bool</div></div>	True : Opening False : Not opening	
Usage examples	if not rb.is_open(): ... # Describe the command that will be performed if not opened.		

Method	is_pause()			i611 MCS
Function	Check the pause status of the robot program.			
Argument	None			
Return values	res0	<div><div>[-]</div><div>bool</div></div>	True : Pause False : No pause .	
Usage example (*)	<pre>## Track pause and restart status in separate topic. def thread_fnc(rb): while notthread_end: # check status pause_st = rb.is_pause() print'Thisstatusis{ }.'.format(pause_st) print "th:waitstop",din(DIN_STOP) if din(DIN_STOP) == "1": rb.stop() if din(DIN_PAUSE) == "1": rb.pause() if din(DIN_RESTART) == "1": rb.restart() # Example) Robot program sample try: while True: # Description of operating programs such as line(), move() . . # Pause by using user hook rb.user_hook() # . . Description of operating programs such as line(), move() . . exceptRobot_emo: # The event handler presses the emergency stop switch # exceptRobot_stop: # The event handler detects the deceleration stop input # finally: rb.close()</pre>			



Supplement

Supplement of example using `is_pause` method ()
Prepare to use the `is_pause()` method

- Create a separate Threads entity.

Example : `threadTest=threading.Thread(target=thread_fnc,args=[rb])`

- Setup Daemon in separate thread.

Example : `threadTest.setDaemon(True)`

- Start separate thread.

Example : `threadTest.start()`

- Set pause operation. (The pause position changes depending on the value of the `no_pause` flag in `set_behavior()` .)

Example : `rb.set_behavior(only_hook=False,servo_off=False,restore_position=True,no_pause=False)`

- Set the exception interrupt handling for deceleration and emergency stops during operation..

(The default value is all off (False).)

Example : `rb.enable_interrupt(0,True)` #Activate an exception when entering a deceleration stop order during operation

`rb.enable_interrupt(1,True)` # Enable exception generation when there is an emergency stop input during operation

- Set operating parameters.

Example : `Cnt0 = MotionParam(lin_speed=70,jnt_speed=10,acctime=0.4,dacctime=0.4,overlap=100.0)`
`rb.motionparam(Cnt0)`

- Define I/O.

Example : `DIN_STOP = 7` # Stop deceleration

`DIN_PAUSE = 8` # Temporary stop

`DIN_RESTART = 9` # Restart.

Method	join()	i611 MCS
Function	Wait for the expected robot program operation to complete.	
Argument	None	
Return value	In case of failure: An exception is set out (occurs only if there is an error.)	
Usage example	<pre> rb.line(P10) #Linear interpolated motion with teaching point P10 rb.asyncm(sw=1) #Program prediction operation ON (start) # Perform linear interpolation movements using teaching points rb.line(P20) # Perform linear interpolation motion to the teaching point P20. #Wait for the Prediction Robot program to complete. rb.line(P21) P21. rb.join() rb.asyncm(sw=2) # Program prediction activity OFF (exit) ... rb.close() </pre>	



포인트

How to use asyncm () and join() methods

Before implementing asyncm (sw=2), wait until completion of performing the operation command in anticipation of performing the join() method.

Method	Joint2Position()	i611 MCS
Function	Convert a Joint coordinate value to a Position coordinate value.	
Argument	<div>[Joint]</div> <div>:</div> <div></div> <div>(Arguments cannot be omitted.)</div>	
Return value	Successful : <div>List</div> ; Unsuccessful : An exception arises.	
Usage examples	<pre> # Joint coordinate value j10=Joint(0, 30, 60, 0, 90, 90) # Convert location coordinate values (j10 → Convert → p10) p10=rb.Joint2Position(j10) </pre> <div>Result</div> <pre> J10 : [0, 30, 60, 0, 90, 90] ↓ Joint2Position() P10 : [125.0, -717.5, 434.70181275976404, 3.508354649267438e-15, 4.296495291499103e-31, 180.0, < ... >, 7] </pre>	

Method	line() i611 MCS
Function	Perform linear interpolation.
Argument	<code>[Position] [Joint] [MotionParam] : List</code> Takes one or more motion parameters of type Position, type Joint, and type MotionParam as arguments. If the MotionParam type is taken as an argument, subsequent actions will be executed with the changed motion parameters.
Return value	Successful : True [-] <code>bool</code> Unsuccessful : An exception arises .
Usage example	<pre># Example 1 # Linear interpolated motion is performed by using position coordinate p10. # Operating conditions are subject to those given by MotionParam. rb.line(p10) #Example 2 # After arriving at the coordinate position p10, perform a linear interpolation movement to p20. # Operating conditions depend on MotionParam settings. rb.line(p10, p20) # Example 3 # The operating conditions change MotionParam and move to coordinate position p10. # Then perform a linear interpolation motion with p20. mt=m.MotionParam(posture=1, passm=1, overlap=4.8, zone=20, pose_speed=5.0) rb.line(mt, p10, p20)</pre>



Regarding line() and move()

Pre-define the position coordinates of Position type or Joint type.

Example : `p1=Position(-50, -250, 350, 90, 0, 180)`

```
# Change the motion parameters set using the motionparam() method, and move from p1 to p5
```

```
#####
```

```
rb.line(p1, p2) ----- Move from p1 to p2 with action parameter m
```


```
m1=m.motionparam( lin_speed=6,jnt_speed=20 ) ----- Move from p1 to p2 with action parameter m
```



```
rb.line(p3, p4) ----- Move the action from p2 to p4 through p3 with action parameter m1
```

```
m2=m.motionparam( lin_speed=7,jnt_speed=40 ) ----- Change the parameter from m1 to m2
```

```
rb.line(p5) # move() ----- Move from p4 to p5 with action parameter m2
```




Kết quả
 [0, 3, 2, 4]

Method	motionparam() i611 MCS
Function	Set operating parameters.
Argument	[MotionParam] : Keyword 
	If the argument is omitted, it will be set to the default value.
Return value	Successful : True [-] 
	Unsuccessful : An exception arises .
Usage examples	<pre># Example 1: Set as entity of type MotionParam m=MotionParam() rb.motionparam(m) # Example 2: Set as keyword of member variable of type MotionParam rb.motionparam(posture=1, passm=1, overlap=4.8, zone=20, pose_speed=5.0)</pre>

For a detailed explanation of the MotionParam type, please refer to Page 37~.

Method	move() i611 MCS
Function	Moving PTP
Argument	[Position] or [Joint] or [MotionParam] List Take on 1 position coordinate of type Position and type Joint and motion parameters of type MotionParam as arguments. If the MotionParam type is taken as an argument, subsequent actions will be executed with the changed motion parameters.
Return value	Successful : True [-] bool Unsuccessful : An exception arises .
Usage examples	<pre> #Example 1 # PTP moves to the position of p10 coordinate # Operating conditions are subject to those given by MotionParam. rb.move(p10) # Example 2 # Move to coordinate position p10, then PTP moves to p20. # Operating conditions are subject to those given by MotionParam. rb.move(p10, p20) #Example 3 # Change the operating condition to MotionParam and move to coordinate position p10, # Then, move PTP to p20. mt=m.MotionParam(posture=1,passm=1,overlap=4.8,zone=20,pose_speed=5.0) rb.move(mt, p10, p20) #Example 4 # Use cross counter information rb.use_mt(True) ... rb.move(p10) ... rb.close() </pre>



When using cross counter information

Make sure to call `use_mt(True)` before calling the `move()` method.

If `use_mt(False)` is called or `use_mt()` is not called at all during the operation, that operation will not use the cross counter information.

For more information about cross counter, please refer to P.3, for more information about `use_mt()`, please refer to P. 80. The settings of cross counter ('ik_solver_option') are used in the `move()` method and the `Position2Joint()` method.

Method	open() i611 MCS	
Function	Start connecting to the robot. (Initialization.)	
Argument	permission	The only argument is True. True: Gain permission to operate (default value)
	[-] bool	
Return value	If the argument is omitted, it will be set to the default value.	
	Successful : True [-] bool	
	Unsuccessful : An exception arises .	
Usage example	rb.open(True)	





About operation permissions and open() Method

Only a single process in the entire system can have operating privileges.

In case you do not have the right to operate but still use it, you can create many processes but an exception will arise when implementing the method requesting the right to operate.

The number of times open() is performed is only 1 time in the program. After executing close() once, if you execute open() a second time an exception will occur.

When executing a repeat statement, write open() before the repeat statement.

Method	optline()	i611 MCS
Function	Perform linear interpolation movements at optimal speed.	
Argument	<div>[Position] [Joint] [MotionParam] : List</div> <p>Get on 1 position coordinate of type Position and type Joint and type motion parameters MotionParam as argument. If takes type MotionParam as argument, further actions will be executed with changed motion parameters.</p>	
Return value	<p>Successful : True [-] bool</p> <p>Unsuccessful: An exception arises .</p>	
Usage example	<pre># Example 1 # # Optimal linear interpolation motion is performed by using position coordinates p10. # The operating conditions are subject to the given conditions given in MotionParam. rb.optline(p10) # Example 2 # After moving to coordinate position p10, perform Optimal linear interpolation motion to p20. # The operating conditions follow those given in MotionParam. Rb.optline(p10,p20) # Example 3 # Change of operating conditions to MotionParam and move to coordinate position p10. # Perform the Optimal linear internal with p20. mt=m.MotionParam(posture=1, passm=1, overlap=4.8, zone=20, pose_speed=5.0) rb.optline(mt, p10, p20)</pre>	
	Optline () speed is set equally to <u>int_speed</u> (PTP activity, Joint activity, Optimal linear interpolation motion), not likely to <u>lin_speed</u> (Optimal linear interpolation motion).	

Method	override()		i611 MCS
Function	Run override.		
Argument	<div>OVR</div> <div><div>Need</div> [%] <div>integer</div> or <div>float</div></div>	<div>Adjust the speed by applying a multiplier to the robot's motion speed set in motionparam(). (Cannot be omitted)</div> <div>Installation range : 0 ~ 200</div>	
Return value	Unsuccessful: An exception arises (Return only in case of failure.)		
Usage examples	<div># Set override to 50%.</div> <div>rb.override(50)</div>		

Method	pause()		i611 MCS
Function	Pause the robot's movements. (*)		
Argument	None		
Return value	None		
Usage examples	<pre>## Track the pause state in a separate thread. def thread_fnc(rb): while notthread_end: pause_st = rb.is_pause() print "Thisstatusis{ }.".format(pause_st) print "th:waitstop",din(DIN_STOP) if din(DIN_STOP) == "1": rb.stop() if din(DIN_PAUSE) == "1": #Pause. rb.pause() if din(DIN_RESTART) == "1": rb.restart() # Example) Robot program sample try: while True: # · · · Describe operating programs such as line(), move() · · · # Pause with user hook rb.user_hook() # · · · Describe operating programs such as line(), move() · · · exceptRobot_emo: # The event handler presses SW to stop urgently # · · · · · exceptRobot_stop: # The event handler detects the deceleration stop input # · · · · · finally: rb.close()</pre>		

Method	Position2Joint()	i611 MCS
Function	Change the Position coordinate value to the Joint coordinate value.	
Argument	[Position] : List	
	Need (Arguments cannot be omitted.)	
Return value	Successful : [Joint] : List	
	Unsuccessful : An exception arises .	
Usage examples	<pre># Coordinate value of Position type p10=Position(-50, -250, 350, 90, 0, 180) # Change Joint type coordinates (p10 → change → j10) j10=rb.Position2Joint(p10)</pre> <div> <div>Result</div> <pre>p10 : [-50, -250, 350, 90, 0, 180] ↓ Position2Joint() j10 : [18.049733949948962, -21.510874537939305, 147.44314399114182, -180.0, 125.9322694532025, 161.95026605005106]</pre> </div>	

Method	release_stopevent()	i611 MCS
Function	Resets an occurring exception event.*)	
Argument	None	
Return value	None	
Usage examples	<pre>try: ... # Movement except Robot_stop: rb.release_stopevent() ... # Avoidance action</pre>	

*) • Set up before exception handling.
• The exception occurs continuously until reset.

Method	reljntmove() i611 MCS	
Function	Work relative to the Joint coordinate system	
Argument	[dj1, dj2, dj3, dj4, dj5, dj6] : Keyword	
	dj1 [deg] float	Degree of movement of axis J1
	dj2 [deg] float	Degree of movement of axis J2
	dj3 [deg] float	Degree of movement of axis J3
	dj4 [deg] float	Degree of movement of axis J4
	dj5 [deg] float	Degree of movement of axis J5
	dj6 [deg] float	Degree of movement of axis J6
Return value	None	
Usage examples	<pre> # Prepare Joint type coordinate values. J1 = Joint(45, 45, -45, -45, 90, 0) # Set operating parameters. m=MotionParam(jnt_speed=10, lin_speed=70, overlap=30) rb.motionparam(m) ... rb.move(J1) # Move J1 to a position 35 degrees offset in the joint coordinate system. rb.reljntmove(dj1=35) </pre>	

Method	relline()		i611 MCS
Function	Relative linear interpolation motion is performed in the Cartesian coordinate system		
Argument	[dx, dy, dz, drz, dry, drx] : Keyword		
	dx	[mm] float	Offset amount in axial direction X
	dy	[mm] float	Offset amount in axial direction Y
	dz	[mm] float	Offset amount in axial direction X
	drz	[deg] float	Offset amount around axis Rz
	dry	[deg] float	Offset amount around axis Ry
	drx	[deg] float	Offset amount around axis Rz
Return value	Không có		
Usage example	<pre> # Prepare coordinate values of type Position.(*) P10 = Position(95, -280, 240, 154, 80, -114) # Set operating parameters. m=MotionParam(jint_speed=10, lin_speed=70, overlap=30) rb.motionparam(m) ... rb.move(P10) # Move to an offset position of 15 mm in the X-axis direction in the Cartesian coordinate system.. rb.relline(dx=15) </pre>		

*) The teaching point in the example has been simplified. Please use teaching data obtained through actual teaching.

Method	restart()	i611 MCS
Function	Send a restart signal from the paused state.	
Argument	None	
Return value	None Processing returns before restarting according to the actual status. Call from a separate thread apart from the main thread.	
Usage examples	<pre> ## Restart in a separate thread. def thread_fnc(rb): while not thread_end: pause_st = rb.is_pause() print"Thisstatusis { }.".format(pause_st) print"th:waitstop",din(DIN_STOP) if din(DIN_STOP) == "1": rb.stop() if din(DIN_PAUSE) == "1": rb.pause() if din(DIN_RESTART) == "1": # Restart rb.restart() # Eaxmple) Robot program sample try: while True: # · · · Describe action plans such as line(), move() # Pause by using user hook rb.user_hook() # · · · Describe action programs such as line(), move() · · · except Robot_emo: # The event handler by pressing SW to stop the emergency # · · · · except Robot_stop: # The event handler detects deceleration stop input · finally: rb.close() </pre>	

Method	set_behavior()		i611 MCS
Function	Set pause method.		
Argument	[only_hook, servo_off, restore_position, no_pause] : List Keyword		
	only_hook [-] bool	Only pauses are allowed with user_hook(). True : Activate False : OFF (default)	
	servo_off [-] bool	Switch servo to OFF when paused. True : Activate False : OFF (default)	
	restore_position [-] bool	When restarting after a pause (*1), the position will return to before the pause. (2) True : Activate False : OFF (default)	
	no_pause [-]	Only make temporary stops according to the activity classification (*3) True : Activate (Compatible with system version R0.5.0) False : OFF *4) (default)	
	If the argument is omitted, it will be set to the default value.		
Return value	None bool		
Usage example	# When restarting after a pause, it will return to the position it was before the pause. rb.set_behavior(only_hook=False, servo_off=False, restore_position=True, no_pause=True)		

*1) To continue operation, turn the servo on and then run (run).

*2) Even if the servo is turned on again after a pause and the position is moved, you can continue operation by returning to the position before the pause. If paused during operation, return to the original position and restart.

*3) Action division is immediately after action completion when calling the i611Robot class method.

If you want to pause, periodically call the method associated with the action or insert a user_hook() method.

*4) Distinguish between actions or pauses during actions.

Method	set_mdo()		i611 MCS
Function	Set up MDO behavior.		
Argument	[mdoid, portno, value, kind, distance] :		
	mdoid [-]	MDO management No. Setting range : 1 ~ 8	
	portno [-]	integer	Number of output ports Setting range : 0 ~ 12,287
	value [-]	integer	Output I/O 0 : LOW 1 : HIGH
	kind [-]	integer	Conditions 1 : certain distance from the starting point 2 : Reach within a certain range from the endpoint
Return value	distance [mm]	integer	Distance Setting range : 0.0 ~
	Thành công : True [bool] Unsuccessful : An exception arises .		
Usage example	<p># Example 1: Specify a numeric value</p> <pre>rb.set_mdo(1, 23, 0, 1, 30) #Set to MDO management number 1 rb.set_mdo(8, 23, 1, 2, 10) #Set to MDO management number 8</pre> <p># Example 2: Key words</p> <pre>rb.set_mdo(mdoid=1, portno=23, value=0, kind=1, distance=30) #Set to MDO management number 1 rb.set_mdo(mdoid=8, portno=23, value=1, kind=2, distance=10) #Set to MDO management number 8</pre>		



MDO operations

MDO : Middle Digital Out

A function that switches I/O output to LOW/HIGH under specified conditions during operation.

Example) Set output at LOW level.
value=0
kind=1

Example) Set output to HIGH.
value=1 kind=2




Method	settool()		i611 MCS
Function	Install Tool Offset.		
Argument	[id, offx, offy, offz, offrz, offry, offrx] : <div>List</div> <div>Keyword</div>		
	id <div></div> [-] <div>integer</div>	Tool No.: 0 : Turn off Tool Offset. 1 - 8 : Choose Tool Offset.	
	offx <div></div> [mm] <div>float</div>	Tool Offset amount on the X axis in the Tool coordinate system	
	offy <div></div> [mm] <div>float</div>	Tool Offset amount on the Y axis in the Tool coordinate system	
	offz <div></div> [mm] <div>float</div>	Tool Offset amount on the Z axis in the Tool coordinate system	
	offrz <div></div> [deg] <div>float</div>	The Tool Offset amount is rotated around the Rz axis in the Tool coordinate system	
	offry <div></div> [deg] <div>float</div>	The Tool Offset amount is rotated around the Ry axis in the Tool coordinate system	
	offrx <div></div> [deg] <div>float</div>	The Tool Offset amount is rotated around the Rx axis in the Tool coordinate system	
	Original value : [0, 0.0, 0.0, 0.0, 0.0, 0.0, 0.0]		
Return value	Successful : True [-]		
	Unsuccessful : Exception occurs .		
Usage example	# 1 . Set Tool Offset (Tool No.1). # Example 1: Specify a numeric value rb.settool(1, 0.0, 0.0, 200.0, 0.0, 0.0, 0.0) # Example 2: Keywords rb.settool(id=1, offx=0.0, offy=0.0, offz=200.0, offrz=0.0, offry=0.0, offrx=0.0)		
	# 2 . Choose Tool No.1 from Tool Offset. # Example 1: Specify a numeric value rb.changetool(1) # Example 2: Keywords rb.changetool(tid=1)		

The Tool argument name is used differently in Changetool() Method and settool() Method. ().

Method	Argument name of tool
changetool()	tid
settool()	id

Method	sleep()		i611 MCS
Function	Pause processing. Set pause time as argument.		
Argument	sec	Pause time	
Return value	integer		
Usage example	<pre> # When an Exception is detected, terminate normally try. # Pause processing for 5 seconds. rb.sleep(sec=5) ... except Robot_emo #Event handler presses SW to stops urgently (cannot recover) # Describe the required error handling [e.g., termination handling]. </pre>		

*) To enable the Robot_emo() class, describe enable_interrupt() first..

( enable_interrupt(...P. 55, Robot_emo(...P. 109)

예) enable_interrupt(1,True) ## Activate an exception when an emergency stop command is entered during an operation



Sleep function of sleep() method and Python

Python's sleep function cannot cause an emergency stop exception even if the emergency stop switch is pressed during pause. By using the robot library's sleep() function, robot-related exceptions can be thrown even during sleep.

Method	stop()	i611 MCS
Function	Decelerate the Robot to stop. ^(*)	
Argument	None	
Return value	None	
Usage example	<pre>## Command to stop deceleration in a separate topic. def thread_fnc(rb): while notthread_end: pause_st = rb.is_pause() print "Thisstatusis{ },'.format(pause_st) print 'th:waitstop',din(DIN_STOP) # Command to stop deceleration in a separate topic if din(DIN_STOP) == "1": rb.stop() if din(DIN_PAUSE) == "1": rb.pause() if din(DIN_RESTART) == "1": rb.restart() # Example) Robot program sample try: while True: # Describe action programs such as line(), move() # Pause using user hook rb.user_hook() # Describe action programs such as line(), move() except Robot_emo: # Event handler presses SW to stops urgently # except Robot_stop: # Event handler detects input Deceleration stop input detection # # finally: rb.close()</pre>	

*) In states other than automatic operation, use the following method to stop. The method : abort() can only stop when the robot is operating, and not in other cases. (Go to the next program execution section.))

Related method

Restart Confirmation Method : is_pause ()

Method: Set stop position : set_behavior()

Method	svoff()	i611 MCS
Function	Set servo to OFF.	
Argument	None	
Return value	Successful : True [-] bool	
Usage example	Unsuccessful : Exception occurs . rb.svoff()	

Method	svstat()		i611 MCS
Function	Obtain servo status.		
Argument	None		
Return value	state [-] integer	Only worth returning when successful. 1 : ON servo 0 : OFF servo -1 : Emergency stop in progress	
Usage example	if rb.svstat() == 1: # ON servo ... elif rb.svstat() == 0: # OFF servo ... elif rb.svstat() == -1: # Emergency stop in progress		

Method	toolmove()		i611 MCS
Function	Relative movement is performed based on the Tool coordinate system.		
Argument	[dx, dy, dz, drz, dry, drx] :		
	dx [mm]	The amount of movement in the X axis direction in the Tool coordinate system	
	dy [mm] float	The amount of movement in the Y axis direction in the Tool coordinate system	
	dz [mm] float	The amount of movement in the Z axis direction in the Tool coordinate system	
	[deg] float	The amount of rotation around Rz in the Tool coordinate system	
	dry [deg] float	The amount of rotation around Ry in the Tool coordinate system	
	drx [deg] float	The amount of rotation around Rx in the Tool coordinate system	
	Default : [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]		
Return value	Successful : True [-]		
	Unsuccessful: Exception occurs .		
Usage example	#Example: Define teaching data of type location [dx, dy, dz, drz, dry, drx] as a list. p10=Position(95, -280, 240, 154, 80, -114)		
	# For example: After moving to coordinate position p10, move a distance dx=15mm according to the Tool coordinate system. ... rb.move(p10) rb.toolmove(dx=15) ... rb.close()		

Method	use_mt()		i611 MCS
Function	Set cross counter on/off.		
Argument	mt [-]	True : Activate False : OFF (Default: Compatible with R system version 0.5.0)	
Return value	None	bool	
Usage example	<pre># Use cross counter information. rb.use_mt(True)</pre>		



Cross counter method

If cross counter is enabled, the behavior of the underlying API will change

포인트!

[Created function]

Position()

[Method]

Position class : replace(), pos2list(), pos2dict(), position(), motionparam() Class i611Robot :
getpos(), Joint2Position(), Position2Joint(), move()

Class i611Robot : getpos(), Joint2Position(), Position2Joint(), move()

Method	user_hook()		i611 MCS
Function	Pause the robot program.		
Argument	None		
Return value	None		
Usage example	<pre>... rb.user_hook() # Pause the program at this position. ...</pre>		



User hook() method

Place this Method at the location where you want to pause processing outside of the robot control commands of the Robsys class .

When pausing only a specific part of the robot program, place user_hook() at the location where you want to pause the robot program, in the disabled state "Enable pause only when user_hook" is disabled in set_behavior().

Method	version()	i611 MCS
Function	Get system version.	
Argument	None	
Return value	[res0,major,minor,patch,build,date,option]: res0 List	
	None	True :Successful
	[-] bool	False: Unsuccessful
	major [-] integer	Major Version
	minor [-] integer	Minor Version
	patch [-] integer	Patch Version
	build [-] List	Build Version
	date [-] string	Built date
	option [-] string	Option
Usage example	rb.version() [True, 0, 6, 9, 7, u'04:37:07 Nov 28 2017', u'SIM No-spiio ']	

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal blue lines across its entire width. The paper is otherwise completely empty, with no margins, text, or other markings.

2. Module: teachdata

Lóp

Teachdata

Teaching data administration

Member variable

—	—
Method	
check_format()	Get a formatted version of the teaching data file. P.84
close()	Close the teaching data file. P.85
flush()	Export updated teaching data to a file. P.85
get_coordinate()	Enter the Base Offset of the teaching data. P.86
get_joint()	Get the Joint coordinate value of the teaching data. P.86
get_param()	Get teaching data parameters. P.87
get_position()	Get the Position coordinate value of the teaching data. P.88
get_tool()	Get the Tool offset of the teaching data. P.89
is_open()	Check the open status of the teaching data file. P.89
open()	Open the teaching data file. P.90
set_joint()	Update the matching coordinate value of the teaching data. P.90
set_param()	Update parameters of teaching data. P.91
set_position()	Update the Position coordinate value of the teaching data.. P.92

Created functions	Teachdata()		Teach data
Function	Create an instance of the Teachdata class by loading the teaching data.		
Argument	fname [-] string	Name of the teaching data file Original value : '/home/i611usr/teach_data'	
Return value	Self-reference (Teachdata class object)		
Usage examples	<pre># When a teaching data file is specified td=Teachdata(fname = '/home/i611usr/teach_data') # If argument is omitted td = Teachdata()</pre>		



「Key」and「Index」

Correspond to what is displayed on the teaching, key and folder screens.

「Key」and「Index」

Correspond to what is displayed on the teaching, key and folder screens.

Key value

file:teach_data

```
pos1[0]
pos1[1]
pos1[2]
pos1[3]
pos1[4]
pos1[5]
pos1[6]
```

Index name

Method	check_format()		Teach data
Function	Import a formatted version of the teaching data file.		
Argument	fname <div>Needstring</div>	Full path to the teaching data file	
Return value	ver <div>[-]string</div>	" Version string "	
Usage example	ver = Teachdata.check_format("/home/i611usr/ <u>teach_data</u> ") <div>_____ File name _____</div>		

An instance of the Teachdata class is not required for the Static Method.

Method	close()	Teach data
Function	Close the teaching data file.	
Argument	None	
Return value	None	
Usage example	<pre># End of teaching data file. td.close()</pre>	



Please implement the close() method at the end of the program.

When opening teaching data in Read/Write mode, export the updated data to a real file and then disable exclusive (exclusive) processing...

Method	flush()	Teach data
Function	Export updated teaching data to a file.	
Argument	None	
Return value	None	
Usage example	<pre># Update teaching data files. .. td.flush() ... td.close()</pre>	

- In case of updating data, when close () will also be when running that data. This should be done when a certain amount of updates have been accumulated, not every update.
- If you are updating data, it will also run internally when you close it ().

Method	get_coordinate()		Teach data
Function	Enter the Base offset of the teaching data.		
Argument	index [-] <input type="text"/> integer	Base ID Installation range : 0 - 3 0 : Returns the base version 1 -3 : Returns a Coordinates instance of the Base coordinate system.	
Return value	baseoffset	Base offset example The corresponding entity is returned according to the ID specified in the argument. index=0 : Base index=1, 2, 3 : Coordinate entity of the corresponding Offset Base	
Usage example	# Index number: 1, offset value of base coordinates taken from the teaching data file. <pre>baseoffset = td.get_coordinate(1)</pre> <div> <div></div> <div>[0.0, 0.0, 0.0, 0.0, 0.0, 0.0, < ... >]</div> <div>Result</div> </div>		

Method	get_joint()		Teach Teach
Function	Get the matching coordinate value of the teaching data.		
Argument	[key, index, comment] : <input type="text"/> List		
Argument	key [-] <input type="text"/> Need	Joint Coordinate key value Installation range : 'Joint1' -'Joint20'	
	index [-] <input type="text"/> integer	Joint Coordinate index Installation range : 0 -9	
	comment [-] <input type="text"/> bool	flag receives Comment True : Received False : Not received .	
	[<input type="text"/> Joint] , comment] : <input type="text"/> List		
Return value	<input type="text"/> Joint [deg] <input type="text"/> float	Joint Coordinate value	
	comment [-] <input type="text"/>	Comment (Maximum 32 characters)	
Usage example	#key = joint1, index 번호 = Get the Joint coordinate value and Comment of 1. <pre>jnt, comment = td.get_joint('joint1', 1, True) printjnt.jnt2list()</pre> <div> <div></div> <div>[0.744, -37.724, -83.660, 45.270, -47.308, 10.110]</div> <div>Result</div> </div>		






An exception (Robot_error) occurs when data for the specified key and index does not exist.

Method	get_param()		Teach data
Function	Get teaching data parameters.		
Argument	[key, index, axis, comment] :		
	key [-]	the key value of the parameter Installation range : 'param1' - 'param4'	
	index [-]	string	parameter index Installation range : 0 - 9
	axis [-]	integer	Axis number in parameter Installation range : 1 - 8
Return value	comment [-]	integer bool	Gets the parameter's Comment flag True : Received False : Not received . (Original value)
	param [-]	string	parameter string (Maximum 32 characters/values can be entered on the teaching screen.)
Usage example	<pre>#key : "param2", index number : Get the 1st and 2nd teaching data files param = td.get_param("param2", 1, 2)</pre>		


An exception occurs if data for the specified key, index, and axis does not exist.

Method	get_position()			Teach data
Function	Get the Position coordinate value of the teaching data.			
Argument	[key, index, tool, base, comment] : <div>List</div>			
	key	[-] <div>Need</div>	Key value of Position coordinates Installation range : 'pos1' -'pos20'	
	index	[-] <div>Need</div> <div>integer</div>	Position coordinate index Installation range : 0 -9	
	tool	[-] <div></div>	Tool ID collection flag True : Received False : Not received . (Original value)	
	base	[-] <div></div>	Facility ID collection flag True : Received False : Not received . (Original value)	
	comment	[-] <div>bool</div>	Comment collection flag True : Received False : Not received . (Original value)	
Return value	[pos, toolid, baseid, comment] : <div>List</div>			
	pos	[mm] <div>float</div>	Position coordinate valuef (<div>object</div>) <div>[Position]</div>	
	toolid	[-] <div>integer</div>	Tool ID Return value : 0 - 8 (0 without tool)	
	baseid	[-] <div>integer</div>	Base ID Return value : 0 - 3 (0 without tool)	
	comment	[-] <div></div>	Comment (Maximum 32 characters, if there isn't ' ')	
Usage examples	# Get data of key = pos1, index number = 1.。 #(Get Tool ID(True), Base ID(True), Comment (True).) pos, toolid, baseid, comment = td.get_position('pos1', 1, True, True, True)			
				<div>Result</div> <div>pos : [21.0, 459.94, 120.61, 53.890, 4.720, -142.88, < ... >, 6] toolid : [3] baseid : [0] comment : [test]</div>

An exception occurs when data for the specified key and index does not exist.

Method	get_tool()		Teach data
Function	Get the Tool offset of the teaching data.		
Argument	index  [-] 	Tool ID Installation range : 0 -8 (If set to 0, the return value will be [0, 0, 0, 0, 0, 0].)	
	[dx, dy, dz, drz, dry, drx] 		
Return value	dx, dy, dz [mm] 	Tool Offset value position (world coordinate system)	
	drz, dry, drx [deg] 	Tool Offset value angle (angle Z-Y-X Euler)	
Usage example	# Index number: 1, Tool Offset value is taken from the teaching data file.		
	tooloffset=td.get_tool(1) ...	<div>Result</div> <div>[1, u'0.00', u'0.00', u'0.00', u'0.00', u'0.00', u'0.00']</div>	

An exception (Robot_error) occurs when data for the specified key and index does not exist.

Method	is_open()		Teach data
Function	Check the open status of teaching data.		
Argument	None		
Return value	res [-] 	0 : Not open 1 : ReadOnly mode (read only) 2 : Read/Write mode (Read/Write)	
Usage examples	<p># Check the open status of the teaching data file.</p> <pre> td = Teachdata() td.open(readonly=False) if td.is_open() == 2: return False ... </pre>		

Method	open()		i611 IO	Teach data
Function	Open the teaching data file.			
Argument	readonly	True : Open in ReadOnly mode (default) False : Open in Read/Write mode (read/write)		
Return value	Không có			
Usage example	<pre># Open in read-only mode. td = Teachdata() td.open(readonly=Ture) # Open in Read/Write mode. td = Teachdata() td.open(readonly=False)</pre>			

- Cannot be opened when the operating mode is "Teaching"..
 - If you open in Read/Write mode, other processes cannot open in Read/Write mode.
 - If the version of the teaching data file is an unsigned version (R1.0.0 or later), an exception will occur..
 - Older versions of the teaching data file can be read, but an error message will appear.
- (It is recommended to convert teaching data files.)

Method	set_joint()			i611 IO	Teach data
Function	Update the Joint coordinate value of the teaching data.				
Argument	[key, index, jnt, comment] :				List
	key	[-]	Key		
	Need		Joint name : joint1 -joint20		
	index	[-]	Index		
	Need	integer	Installation range : 0 -9		
jnt	[-]	Updated Joint coordinate value (] Object)			
	Need	float			
	comment	[-]	Comment string (Maximum 32 characters)		
		string			
Return value	None				
Usage examples	# Key value of type Joint : "joint1",index number : 2, Joint type coordinates: jnt, Comment : "home" is updated . jnt = Joint(0, 0, 0, 0, 0, 0) td.set_joint("joint1",2,jnt,"home")				

- Can only be used on data that already exists.
- If there is no specific key or index, an exception will occur.
- An exception occurs if not in Read/Write mode.
- If you run the Flush() command after calling this Method, the file will be updated.

Method	set_param()		Teach data
Function	Update parameters of teaching data.		
Argument	[key, index, axis, paramstr comment] :		
	key [-]	Key Param name : param1 ~ param4	List
	index [-]	Index Installation range : 0 -9	
	axis [-]	Axis Installation range : 1 -8	
	paramstr [-]	Parameter string (Maximum 32 characters)	
	comment [-]	Comment string (Maximum 32 characters)	
Return value	None		
Usage examples	<pre># key : param2, index No. : 3, number of axis : 1, parameter "1.00" updated td.set_param("param2", 3, 1, "1.00")</pre>		

- Can only be used on data that already exists.
- If there is no specific key or index, an exception will occur.
- An exception occurs if not in Read/Write mode.
- If you run the Flush() command after calling this Method, the file will be updated.

Method	set_position()		Teach data
Function	Update the Position coordinate value of the teaching data.		
Argument	[key, index, pos, tooloffset, baseoffset, comment] : <div>List</div>		
	key <div>Cần</div> <div>[-] string</div>	Key Position name : pos1 ~ pos20	
	index <div>Cần</div> <div>[-] integer</div>	Index Installation range : 0 - 9	
	pos <div>Cần</div> <div>[-] float</div>	Update Location coordinate <div>[value]</div> (Object)	
	tooloffset <div>[-] integer</div>	The Tool Offset ID is used to determine this Position coordinate value Installation range : 0 - 8 Original value: 0 (Do not use Base Offset).)	
	baseoffset <div>[-] integer</div>	The Base Offset ID is used when determining this Position coordinate value Installation range : 0 - 3 Original value: 0 (Do not use Base Offset.)	
	comment <div>[-] string</div>	Comment string (Maximum 32 characters)	
Return value	None		
Usage example	# Value type Position : pos2, Index number : 2, Tool ID : 1, Base Offset : Not used, Comment "work" updated pos = Position(95, -280, 425, -120, 84, -28) td.set_position("pos2", 2, pos, 1, 0, "work")		

- Can only be used on data that already exists.
- If there is no specific key or index, an exception will occur.
- An exception occurs if not in Read/Write mode.
- If you run the Flush() command after calling this Method, the file will be updated.

3. Module: i611_extend

Class

Pallet

Performs the function of pallets.

Member variable

-

-

Method

adjust()	Fix cell position.	P.94
get_pos()	Enter the position of the cell.	P.95
init_3()	Definition of pallet (Lecture 3 points)	P.96
init_4()	Definition of pallet (Lecture 4 points)	P.97

Created functions	Pallet() i611 Ext.	
Function	Pallet function: creates a Pallet class entity.	
Argument	None	
Return value	Back to the private class object	



For practical operations, use the points taught to determine the coordinates of each Pallet.

Method	adjust()		11
Function	Fix cell position.		
Argument	[i, j, di, dj] : List		
	i [-] integer	Index determines the cell's position in the Pallet (i direction)	
	j [-] integer	Index determines the cell's position in the Pallet (j direction)	
	di [mm] integer	The offset value of the cell position in direction i	
	dj [mm] integer	The offset value of the cell position in direction j	
Return value	None		
Usage example	<pre># For example: Determine the coordinates of the 4 corners of the Pallet and identify the Pallet.. (*) pos_0=Position(-250, -250, 400) pos_1=Position(-170,-250,400) pos_2=Position(-250, -180,400) pos_3=Position(-170,-180,400) pal.init_4(pos_0, pos_1, pos_2, pos_3, 8, 7) # Set the Pallet offset value. pal.adjust(4, 4, 10, 10) rb.close()</pre>		

*) For practical operations, use the points taught to determine the coordinates of each Pallet.

Method	get_pos()		i611 MCS	i611 Ext
Function	Get the cell's position.			
Argument	[i, j, dk] <div>List</div>			
	i	<div>Can</div> [-] integer	Index determines the cell's position in the Pallet (direction i)	
	j	<div>Can</div> [-] integer	Index determines the cell's position in the Pallet (direction j)	
	dk		Offset value in vertical direction	
		[mm] integer	Original value : 0	
	If an offset value is set, the offset coordinates will be taken from the Pallet coordinates in the k direction of the cell. If the dk argument is omitted, the original value is set.			
Return value	<div>[Position]</div> Coordinates of the cell at position (i, j) in the Pallet			
Usage example	<pre># Example: Determine the Pallet and the coordinates of the 4 corners of the Pallet. (*) pos_0=Position(-250, -250, 400) pos_1=Position(-170,-250,400) pos_2=Position(-250,-180,400) pos_3=Position(-170,-180,400) pal.init_4(pos_0,pos_1,pos_2,pos_3,8,7) pal.adjust(4, 4, 10, 10) # Gets the coordinates of the specified index in the Pallet, including offset. p00=pal.get_pos(0, 0, 10) # Go to the coordinates obtained from get_pos (). rb.move(p00) rb.close()</pre>			

*) For practical operations, use the points taught to determine the coordinates of each Pallet..






Vertical direction of pallets

The positive sign direction of the vertical direction of the pallet (k direction) changes depending on the position of the teaching point..


Example ① $\vec{i} \times \vec{j}$: Vector \vec{z} + perpendicular to the plane (Pallet plane).

Example ② $\vec{j} \times \vec{i}$: \vec{z} - opposite to the example①.



Method	init_3()		i611 MCS	i611 Ext
Function	Identify Pallets (3-point guide)			
Argument	[pos_0, pos_i, pos_j, ni, nj] : <div>List</div>			
	pos_0	<div>need</div>	<div>[-] float</div>	<div>[Position]</div> Pallet teaching point (original)
	pos_i	<div>need</div>	<div>[-] float</div>	<div>[Position]</div> Pallet teaching point (direction i)
	pos_j	<div>need</div>	<div>[-] float</div>	<div>[Position]</div> Pallet teaching point (direction j)
	ni	<div>need</div>	<div>[-] integer</div>	Number of cells arranged in direction i of the Pallet
	nj	<div>need</div>	<div>[-] integer</div>	Number of cells arranged in direction j of the Pallet
Return value	res	<div>True : Successful</div>		
Usage example	<pre># Example: Determine the coordinates of the three vertices of the Pallet (*) pos_0=Position(-250, -250, 400) pos_1=Position(-170, -250, 400) pos_2=Position(-250, -180, 400) # Identify Pallets using 3-point guidance data. pal.init_3(pos_0, pos_1, pos_2, 8, 7) rb.close()</pre>			
	<div></div> <div>P(i,j) : Pallet Position</div>			

*) For practical operations, use the points taught to determine the coordinates of each Pallet.

Method	init_4()			i611 MCS	i611 Ext.
Function	Xác định Pallet (hướng dẫn 4 điểm)				
Argument	[pos_0, pos_i, pos_j, pos_ij, ni, nj] :				
	List				
	pos_0	[-] float	[Position]	Pallet teaching point (original)	
	pos_i	[-] float	[Position]	Pallet teaching point (direction i)	
	pos_j	[-] float	[Position]	Pallet teaching point (direction j)	
	pos_ij	[-] float	[Position]	Pallet teaching point	
	ni	[-] integer	Number of cells arranged in direction i of the Pallet		
Return value	nj	[-] integer	Number of cells arranged in direction j of the Pallet		
	res	[-] bool	Only return when successful True : Successful		
Example	<pre># Example: Determine the coordinates of the 4 vertices of the Pallet (*) pos_0=Position(-250, -250, 400) pos_1=Position(-170, -250, 400) pos_2=Position(-250, -180, 400) pos_3=Position(-170, -180, 400) # Identify Pallets using guidance data 4 point pal.init_4(pos_0, pos_1, pos_2, pos_3, 8, 7) rb.close()</pre>  <p style="text-align: center;">P(i,j) : Pallet Position</p>				

*) For practical operations, use the points taught to determine the coordinates of each Pallet.

4. Module : rbsys

Class

RobSys

System administrator control

Member variable

-

-

Method

assign_din()	Allocate functions to input ports of physical I/O and memory I/O.	P.99
assign_dout()	Assign functions to the output ports of physical I/O and memory I/O.	P.100
clear_robtask()	Unsubscribe from the robot program.	P.101
close()	Terminate the connection with the system manager.	P.101
cmd_pause()	Action command: pause	P.102
cmd_reset()	Action command: reset error	P.102
cmd_run()	Action command: Run the robot program	P.103
cmd_stop()	Action command: stop deceleration	P.103
get_robtask()	Get the status of the robot program.	P.104
open()	Initiate communication with the system administrator.	P.104
req_mcmd()	Get system status and command status.	P.105
set_robtask()	Register for the robot program.	P.106
version()	Get version information of System Manager.	P.107



The RobSys class is an administrative program interface for I/O control and task management in configuration scripts. (init.py).
In the robot program, use the Method of the i611Robot class and do not use the RobSys class.

Constructor	RobSys()		rbsys
Function	Create robot system instances.		
Argument	host	Specify the IP address of the connection destination	
	[-] string	Original value : '127.0.0.1'	
	If the argument is omitted, it will be set to the default value.		
Return value	Return to the class object itself		
Usage examples	# Example 1: Omit argument (set to initial value)		
	rbs = RobSys()		
	# Example 2: Keywords		
	rbs = RobSys(host='127.1.1.1')		

Method	assign_din()		i611 IO	rbsys
Function	Assign functions to input ports of physical I/O and memory I/O.			
Argument	[run, stop, err_reset, pause] :		Keyword	
	run		Run the robot program	
	[-]	integer	Original value : -1	
	stop		Reduce speed to stop	
	[-]	integer	Original value : -1	
	err_reset		Reset errors	
	[-]	integer	Original value : -1	
	pause		Pause	
	[-]	integer	Original value : -1	
Argument	Installation range : <ul style="list-style-type: none">• Physical I/O : 0 - 15• Memory I/O : 32 - 12287• If no value is assigned, specify -1.• If the argument is omitted, it is set to Initial Value.• Duplicate assignments cannot be made to the same I/O.• Please refer to “3 Memory Maps” for assigned physical I/O.• Setting range 0 - 15 corresponds to IN1 to IN16 (CN3: I/O connector 1) of the input port signal name.• Low— Hi input detection input signal			
Return value	Successful : True [-] bool			
	Unsuccessful : Exception occurs			
Usage example	# Specify in init.py: (recommended settings below) rbs.assign_din(run=0, stop=1, err_reset=2, pause=3)			

Method	assign_dout()		11	rbsys
Function	Assign functions to output ports of physical I/O and memory I/O.			
Return value	[running, svon, emo, hw_error, sw_error, abs_lost, in_pause, error] Keyword			
	running [-] integer	robot program status Original value : -1		
	svon [-] integer	Servo status Original value : -1		
	emo [-] integer integer	emergency stop condition Original value : -1		
	hw_error [-] integer	System-determined error condition (critical) Original value : -1		
	sw_error [-] integer	The error state is determined by the system Original value : -1		
	abs_lost [-] integer	Status of ABS loss Original value : -1		
	in_pause [-] integer	Pause status Original value : -1		
	error [-]	system error condition (*) Original value : -1		
	Examples	Installation range : <ul style="list-style-type: none">Physical I/O : 16 - 31Memory I/O : 32 - 12287 <div></div> <ul style="list-style-type: none">If no value is assigned, specify -1.If the argument is omitted, it is set to Initial Value.Duplicate assignments cannot be made to the same I/O.Please refer to “3 Memory Maps” for assigned physical I/O.Setting range 16 - 31 corresponds to signal names O1 to O16 (CN4: I/O connector 2, CN5: I/O connector 3)When the output is ON, the corresponding output port becomes Hi <div>bool</div>		
Successful : True [-]				
Unsuccessful: Exception occurs				

*) A system-determined error status (non-fatal or fatal) occurs. Used to test 2 error states on one control line.



If the robot program is started without using the system manager, (*)the running output is not displayed. If running outputs, please reboot through system manager.

*) For example, the case of starting with terminal software.

Method	clear_robtask()		rbsys
Function	Unsubscribe from the robot program.		
Argument	None		
Return value	res0 [-]	True : Successful False : Unsuccessful	
Usage examples	<pre># Successful if rbs.clear_robtask()[0] == True: # Unsuccessful if rbs.clear_robtask()[0] == False:</pre>		



The clear_robtask() method does not stop the Robot program while it is running.

Method	close()		rbsys
Function	Terminate the connection with the system manager.		
Argument	None		
Return value	None		
Usage example	rbs.close()		

Method	cmd_pause()		rbsys
Function	Action command: pause		
Argument	None		
Return value	res0 [-]	True : Successful False : Unsuccessful	
Usage example	rbs.cmd_pause()		



Usage time md_pause()





Pausing can be done if cmd_pause() is executed in an action command or at the time of executing the user_hook() Method.

To continue working, execute with cmd_run ().

Method		
Function	Action command: reset error	
Argument	None	
Return value	res0 [-]	True : Successful False : Unsuccessful
Usage example	rbs.cmd_reset()	



Errors can be reset by cmd_reset()

Type of errors	Is it possible to cancel via cmd_reset()?
 E** system-determined error	○
 C** system-determined error Critical	×
 U** user-determined error	○
 r** user-determined error Critical	×

Method	cmd_run()		rbsys
Function	Action command: Run the robot program (If paused, the program will be reconnected.)		
Argument	fname [-]	Framework name	
	If the argument is omitted, the robot program specified with set_robtask() will be executed.		
Return value	None		
Usage example	# Example 1: When executing the robot program specified with set_robtask(), the argument will be ignored. rbs.set_robtask('sample.py') rbs.cmd_run()		
	# Example 2: When specifying a filename as an argument rbs.cmd_run('sample.py')		

Method	cmd_stop()		rbsys
Function	Motion command: stop deceleration		
Argument	res0 [-] <input type="checkbox"/> bool	True : Successful False : Unsuccessful	
Return value	None		
Usage example	rbs.cmd_stop()		



Relationship between cmd_stop() and allow_interrupt() in class i611Robot

The behavior of the robot program after deceleration to stop varies depending on the Enable_interrupt() (deceleration interrupt setting) of the i611Robot class.

Interrupt speed deceleration enable_interrupt(eid, enable)	Robot program after stopping deceleration
Valid enable_interrupt(0, True)	Exception occurred
Disable enable_interrupt(0, False)	Normal interrupt

In case the validity expires, the Robot program will end abnormally.

Method	get_robtask()	rbsys
Function	Get the status of the robot program.	
Argument	None	
Return value	[res0, res1, res2] : List	
	res0	True : Robot program in progress [-] bool False : Stop
	res1	Process ID of the currently running robot program or last run [-] integer
	res2	File name of the registered robot program [-] string
Examples	<pre># Get the execution status of the robot program rb.get_robtask()[0] # Get the process ID of the robot program that is running or last executed rb.get_robtask()[1] # Get the file name of the registered robot program rb.get_robtask()[2]</pre>	
Method	open()	rbsys
Function	Initiate communication with the system administrator.	
Argument	None	
Return value	None	
Usage example	rbs.open()	

Method	req_mcmd()		rbsys
Function	Get system status and command status.		
Argument	None		
Return value	[running, svon, emo, hw_error, sw_error, abs_lost, in_pause, error] :		
	running	[-]	the robot program status 1 : Displayed on the controller LED (STS) is running)
	svon	emo	0 : Stopping
	hw_error	[integer]	servo status 1 : 서보 ON
	sw_error	[-]	0 : 서보 OFF
		[integer]	emergency stop condition
		[-]	1 : Emergency stop in progress
	abs_lost	[integer]	0 : None
	in_pause	[-]	System-determined error condition (critical) 1 : An error is occurring
	error	[integer]	0 : None
Usage examples		[-]	System-determined error condition
		[integer]	1 : An error is occurring
		[integer]	0 : None
		[integer]	Status of Loss of ABS 1 : Loss of ABS
		[integer]	0 : None
		[integer]	Stopping status
		[integer]	1 : Stopping
		[integer]	0 : None
		[integer]	system error condition (*)
		[integer]	1 : A system error occurred
Usage examples		[integer]	0 : None
	# Check your system status individually		
	running = rbs.req_mcmd()[0]	# robot program status	
	svon = rbs.req_mcmd()[1]	# servo status	
	emo = rbs.req_mcmd()[2]	# emergency stop condition	
	hw_error = rbs.req_mcmd()[3]	# System-determined error condition (critical)	
	sw_error = rbs.req_mcmd()[4]	# System-determined error condition	
	abs_lost = rbs.req_mcmd()[5]	# Status of ABS loss	
	in_pause = rbs.req_mcmd()[6]	# pause status	
	error = rbs.req_mcmd()[7]	# system error condition	

Method	set_robtask()		rbsys
Function	Register for the robot		
Argument	fname	Program file name	
Return value	[-]		
	res0	string	True : Successful False : Unsuccessful (The specified file does not exist)
Usage example	rbs.set_robtask('sample01.py')		



Robot programs can only be registered using the set_robtask() method. Cannot be used when starting the robot program.



Relationship between I/O allocation and Python ports

Function	Related method	Number of Python ports	
		Physical I/O (*2)	System I/O
Run the robot program	cmd_run()	0	4288
Reduce speed to stop	cmd_stop()	1	4289
Reset errors	cmd_reset()	2	4290
Pause	cmd_pause()	3	4291

Function	Related method	Number of Python ports	
		Physical I/O (*2)	System I/O
The state of the robot program	req_mcmd()[0]	16	4160
Servo state	req_mcmd()[1]	17	4096
The state of emergency stop	req_mcmd()[2]	18	4097
The state of error according to what the system determined (critical)	req_mcmd()[3]	19	4098
The state of error according to what the system determined	req_mcmd()[4]	20	4161
The state of losing ABS	req_mcmd()[5]	21	4099
The state of pause	req_mcmd()[6]	22	4162
The state of system error (*1)	req_mcmd()[7]	23	4163

*1) A system-determined error status (non-fatal or fatal) occurs. Used to test 2 error states on one control line.

*2) We recommend assigning this I/O. For details on memory I/O, please refer to "3 Memory Maps".

Method	version()	rbsys
Function	Get the system manager version information.	
Argument	None	
Value	[res0, major, minor, patch, build] : List	
	major	[-] bool True : Successful False : Unsuccessful
	minor	[-] integer Principal version
	patch	[-] integer Principal version
	build	[-] integer patched version
		[-] integer built version
Examples	<pre>version=rbs.version() print version</pre>	

5. Module : i611_common

Class

Exception

Exception handling of Method of class i611Robot.

The class inherits the Exception class

Robot_emo	Exception occurs during emergency stop (cannot be recovered)	P.109
Robot_error	The exception arose due to an error	P.110
Robot_fatalerror	Exceptions arise in case of fatal (irrecoverable) errors)	P.110
Robot_poweroff	Exception occurred when power off (irrecoverable)	P.111
Robot_stop	Exception occurs when decelerating to stop	P.112

The Exception class can be used simply by importing the i611_MCS module. Load from i611_common import in the i611_MCS module.

Class	Robot_emo()	i611 COM.	i611 MCS
Function	Exception occurs during emergency stop (cannot be recovered)		
Argument	Event handling during emergency stop.		
Value	None		
Examples	<pre> Preparation - ## 1 . Initial setup ① Import the module ##### from i611_MCS import * ## 2 . Initial settings ②: Set operating conditions ##### # Robot constructor i611 rb = i611Robot() # Determine the world coordinate system _BASE = Base() # Start connecting to the robot, initialize rb.open(True) # Exception triggered due to emergency stop input during operation rb.enable_interrupt(1, True) ... # Exception handling..... # Example 1: Exception detection and normal termination try: ... except Robot_emo: # Exceptions are made for emergency stops # Required error handling (termination handling) technique # Example 2: Exception detected, termination of error try: ... </pre>		



except Robot_emo: # Exceptions arise during emergency stops

Added description of Robot_emo class

Operate the robot program while pressing the emergency stop switch

Code try: ... except: in action program • • •

• Case not included :

The program ends with an error condition. Display controller •  .

Case included :

The program ends normally.^(*)

^(*) Write a program so that the robot program ends within 5 seconds when the emergency stop switch is pressed.
If it exceeds 5 seconds, it will end in an error condition. display 7seg:



Class	Robot_error()	i6 COM.	11
Function	The exception arose due to an error This is the event handler when an error occurs..		
Argument	None		
Return value	None		
Usage examples	<pre> # Preparation..... ## 1 . Initial setup ① Import the module ##### from i611_MCS import * ## 2 . Initial settings②: Set operating conditions ##### # Robot i611 constructor rb = i611Robot() # Determine the world coordinate system _BASE = Base() # Start connecting to the robot, initialize rb.open(True) ... # Exception handling..... # Exception detection and normal termination try: ... except Robot_error: # Exception raised due to error # Error handling technique (termination handling) required </pre>		

Class	Robot_fatalerror()	i611 COM.	11 i6 MCS
Function	Exceptions occur when a fatal (unrecoverable) error occurs) This is the event handler for when a fatal error occurs.		
Argument	None		
Return value	None		
Usage examples	<pre> # Preparation..... ## 1 . Initial setup ① Import the module ##### from i611_MCS import * ## 2 . Initial settings②: Set operating conditions ##### # Robot i611 constructor rb = i611Robot() # Determine the world coordinate system _BASE = Base() # Start connecting to the robot, initialize rb.open(True) ... # Exception handling..... # Exception detection and normal termination try: ... except Robot_fatalerror: # Exceptions arise when there is a fatal error # Required error handling (termination handling) technique </pre>		

Class	Robot_poweroff()	i611 MCS
Function	Exception occurs when power is turned off (cannot be recovered) This is the power-off event handler.(*)	
Argument	None	
Return value	None	
Usage examples	<pre> # Preparation ## 1 . Initial setup ① Import the module ##### from i611_MCS import * ## 2 . Initial settings②: Set operating conditions ##### # Robot i611 constructor rb = i611Robot() # Determine the world coordinate system _BASE = Base() # Start connecting to the robot, initialize rb.open(True) ... # Exception handling # Exception detection and normal termination try: ... except Robot_poweroff: # Exception raised on power off # Error handling technique (termination handling) required </pre>	

*) Occurs when the controller is visible **PoF** .

If you want to turn off the power, please complete the process until then.

Class	Robot_stop()	i611 MCS
Function	Exception occurs when decelerating to stop This is the event handler for deceleration to stop.	
Argument	None	
Return value	None	
Usage examples	<pre> # Preparation ## 1 . Initial setup ① Import the module ##### from i611_MCS import * ## 2 . Initial settings②: Set operating conditions ##### # Robot i611 constructor rb = i611Robot() # Determine the world coordinate system _BASE = Base() # Start connecting to the robot, initialize rb.open(True) # Enable an exception to be raised when entering "Deceleration Stop" during operation rb.enable_interrupt(0, True) ... # Exception handling # Example 1: Exception detection and normal termination try: ... except Robot_stop: # Event handler checks "Stop deceleration" # Required error handling (termination handling) technique # Example 2: Detect exceptions and terminate errors try: ... except Robot_emo: # Event handler checks "Stop deceleration" rb.exit(1) # At the end there is errors occur </pre>	

Occuring . (Refer to P. 57)




Add description of Robot_stop class

Action program behavior when deceleration stop occurs

Try code: ... except: in the action program • •

- If not described :

The program ended with an error. Display controller  .

- If described :

The program ends normally.

6. Module : i611_io

Class

(None)

I/O Control

Member variable

—

—

Functions

din()	I/O input	P.114
dlyOut()	I/O output after specified time has elapsed	P.115
dout()	I/O output	P.115
IOinit()	Initialize I/O	P.116
shotOut()	I/O output during specified time	P.117
wait()	Wait until the specified I/O input pattern is reached	P.118

Function	din() 1611 IO	
Function	I/O input	
Argument	[*adr] : List	
	<div> <div>*adr</div> <div>@.: [-] string</div> <div>[-]</div> </div>	Input port <ul style="list-style-type: none"> • When specifying an input port adr : input port number • When specifying multiple port ranges adr[0] : Input port number (start) adr[1] : Input port number (end)
Return value	[*port] :	
	<div>*port</div> <div>[-]</div>	Return execution result of input port to '0' or '1' If multiple input ports are specified, will be received as list.
Usage example	<pre> # Example 1: Specify port number 15 if din (15) == '1': # Example 2: Specify port 8 to 10 if din (8, 10)[0] == '1': # When specifying port number 10 ... elif din(8, 10)[1] == '1': # When specifying port number 9 ... elif din(8, 10)[2] == '1': # When specifying port number 8 </pre>	




ATTENTION



Do not use preset ports in init.py



(Incident)

Function	dlyOut()			i611 IO
Function	I/O output after specified time has elapsed			
Argument	[num, dat, tim]: <div>List</div> <div>Keyword</div>			
	num <div></div> [-] <div>integer</div>		Delay output port number	
	dat <div></div> [-] <div>string</div>		Output data from I/O Set as bit field in string ( See “Setting ports in bit fields” on page 116) '1' = ON '0' = OFF (Orignal value) '*' = Without change	
	tim <div></div> [s] <div>integer</div>	Delay time		
Return value	None			
Usage examples	<div># Example 1: List (output port: 8, data output: ON, delay time: 10 seconds)</div> <div>dlyOut(8, '1', 10)</div> <div># Example 2: Keyword (output port: 1, data output: OFF, delay time: 10 seconds)</div> <div>dlyOut(num=1 ,dat='0', tim=10)</div>			

Function	dout()		i611 IO
Function	I/O output		
Argument	[adr, data] : <div>List</div> <div>Keyword</div>		
	adr <div><div></div></div> [-] <div>integer</div>	Output port start number Installation range : 16 ~ 31	
	data <div><div></div></div> [-] <div>string</div>	Output data from I/O Set as bit field in string (<div><div></div></div> See “Setting ports in bit fields” on page 116) '1' = ON '0' = OFF (Original value) '*' = Without change	
	Return value		
None			
Usage examples	# Specify ON/OFF start address and output data (ports 20, 19, 18, 17, 16 ON) dout(16, '11111')		

Function	IOinit()		i611 IO
Function	Initialize I/O (*)		
Argument	[IPAddress, port] : <div>List</div>		
	IPAddress [-] string	IP Address Original value : '127.0.0.1'	
	port [-] integer	Number of port Original value : 12345	
	If the argument is omitted, it will be set to default		
Return value	None		
Usage examples	# Example 1: If argument is omitted (set to Initial Value) IOinit()		
	# Example 2: List (all) IOinit('127.0.0.1', 12345)		


*) IOinit() does not affect what is stored.
Initializes the interface to access memory I/O.




Set the port in the bit field

The data part of the doubt(), layout(), shootOut(), wait() methods is a string in bitfield format

Example) Output port settings 16 - 31



Function	shotOut() i611 IO	
Function	I/O output during specified time (When the time set in tm elapses, it will return to the previous I/O output)	
Argument	[adr, data, tm]: List Keyword	
	adr Cần [-] integer	Output port address number
	data Cần [-] string	Output data from I/O Set as bit field in string ( See "Setting ports in bit fields" on p 116) '1' = ON '0' = OFF (Original value) '*' = Without change
	tm Cần [s] integer	Output time
Return value	None	
Usage examples	<p>None</p> <p># Example 1: List (output port: 8, data output: ON, output time: 10 seconds) shotOut(8, '1', 10)</p> <p># Example 2: Keywords (output port: 1, data output: OFF, output time: 10 seconds)) shotOut(adr=1, data='0', tm=10)</p>	

Function	wait()		i611 IO
Function	Wait until the specified I/O input pattern is reached		
Argument	[adr, data, tm] : <div>List</div> <div>Keyword</div>		
	adr <div>0</div> [-] <div>integer</div>	Input port address number	
	data <div>0</div> [-] <div>string</div>	Specify the data waiting for input '1' = ON '0' = OFF (Original value : 0)	
	tm <div>0</div> [s] <div>float</div> <div>integer</div>	End time	
Return value	[res0, res1, res2] : <div>List</div>		
	res0 [-] <div>integer</div>	Result 1 : Matches input values 0 : Time out -1: Other errors	
	res1 [-] <div>string</div>	Input value	
	res2 [s] <div>float</div> <div>integer</div>	Time passes until the condition is established	
Usage examples	# Example 1: List if wait(8, '1', 10)[0] == 1: if wait(9, '1', 10)[1] == '1': if wait(9, '1', 10)[2] > 10:		
	# Example 2: Keywords if wait(adr=1, data='1', tm=10) == 1:		

7. Module : i611shm

Class

(Not available)

Access shared memory.

Member variable

-

-

Functions

shm_read()

Read shared memory.

P.119

shm_write()

Write to shared memory.

P.120

Function	shm_read()		i611shm
Function	Read shared memory.		
Argument	[index, num] : List		
	index	[-] integer	Readable shared memory address Installation range : 0x0100 -0x3800 Please refer to "Memory Map"
	num	[-] integer	Number of variables read continuously Original value : 1
	If the num argument is omitted, it will set the default value		
Return value	res	[-] string	The string is separated by commas Return the value of the number specified with num as a comma-separated string
Usage examples	<pre># Current command value of J1 (Joint coordinates) val_list = shm_read(0x3050, 6).split(',') joint0 = float(val_list[0])</pre>		



About comma separation

Use a comma separator (,) as the argument to .split(). This allows you to separate values.

```
val_list = shm_read( 0x3050, 6 ).split( ',' )
```

Function	shm_write() i611 shm	
Function	Write to shared memory	
Argument	[<u>index</u> , <u>num</u>] : List	
	<u>index</u> [-] integer	Writable shared memory address Installation range : 0x1800- 0x23F8 Please refer to “3 Memory Maps”
	<u>num</u> [-] integer	List or set of values to read consecutively
Return value	None	
Usage example	shm_write(0x1800, 10) shm_write(0x1C00, (3.5, 4.3))	



Writable memory and shares

Memory address	Type of table	Quantity
0x1800 -0x1BFC	integer (4byte)	256 bytes
0x1C00 -0x23F8	float (8byte)	256 bytes



D Software

3

Memory map



1. Start.....	2
2. Share memory	3
1. Share memory structure	3
2. Memory map (share memory).....	4
Title block.....	4
Memory I/O block	4
System management block	5
User block.....	5
Control management block.....	6
3. Memory I/O	8
1. Memory map (Physical I/O)	8
2. Memory map (System I/O)	9

1. Start



Share memory and I/O memory are RAM (Variable memory) .

All memory contents will be deleted when power off. After starting the system, all values are initialized to 0.

When starting the system, everything except for the user block in the share memory is updated with the current new information.



Save memory content

Recommendations to save memory content to a file.

When saved, call Flush () or Close () after writing. (Flush () : Forced to delete the file buffer)

2. Share memory

1. Share memory structure

Data block	Offset	byte	Content
Title	+0x0000	256	Title in share memory
Memory I/O	+0x0100	1024	Contents like Memory I/O
(Reserve)	+0x0500	768	—
System administration	+0x0800	4096	System administration area
User	+0x1800	4096	User area (4 -byte integer and float type)
Manager controls	+0x2800	4096	Default processing area



Access to share memory

Access to the share memory, use the robot library SHM_READ (), SHM_WRITE ().

Shm_write (), can only be used with the user block. Other areas are only reading areas.

2. Memory map (share memory)

Title block

R : Only read | R/W : Both Read and Write

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x0000	(Reserve)	-	-	-	-	-	-
+0x0008	Update counter	4	unsigned short	update_counter	"1" : Original update	1ms	R
+0x000C	The flag is updating	2	unsigned short	now Updating	Become 1 in the original update process.	1ms	R
+0x000E	(Reserve)	-	-	-	-	-	-

Memory I/O block

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x0100	Digital In/Out	4	unsigned int	dio_io	I/O X16 input, X16 output	1ms	R
+0x0104	Hand Digital In/Out	4	unsigned int	dio_handio	I/O input (ARM) X8, X4 output	1ms	R
+0x0108	Reserve)	-	-	-	-	-	-
+0x0300	System SI (Input) 0	4	unsigned int	mio_si0	Servo status, emergency stop	1ms	R
+0x0304	Reserve)	-	-	-	-	-	-
+0x0308	System SI (Input) 2	4	unsigned int	mio_si2	The operating status of the user program	1ms	R
+0x030C	Reserve)	-	-	-	-	-	-
+0x0318	System SL (Output) 2	4	unsigned int	mio_sl2	Input implementation	1ms	R
+0x031C	Reserve)	-	-	-	-	-	-
+0x0320	User In/Out (output input)	480	unsigned int	mio_pi0[120]	User area	Frequent	R

System management block

R : Only read | R/W : Both Read and Write

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x0800	robtask name	32	char (string)	robtask_name[32]	"Name of the user program registered in set_robtask"	When updated	R
+0x0820	running program name	32	char (string)	running_name[32]	Run the user program name	When updated	R
+0x0840	running program pid	4	unsigned int	running_pid	"pid of the user program is running"	When updated	R
+0x0844	assign_din(run)	2	short	assign_port[0]	Input gate (run) or -1	When updated	R
+0x0846	assign_din(stop)	2	short	assign_port[1]	Enter the designated port (stop) or -1	When updated	R
+0x0848	assing_din(err_reset)	2	short	assign_port[2]	Input allocation port (err_reset) or -1	When updated	R
+0x084A	assign_din(pause)	2	short	assign_port[3]	Enter the designated port (pause) or -1	When updated	R
+0x084C	assign_out(running)	2	short	assign_port[4]	Running or -1 output gate	When updated	R
+0x084E	assign_out(svon)	2	short	assign_port[5]	Output allocation port (svon) or -1	When updated	R
+0x0850	assign_out(emo)	2	short	assign_port[6]	Output assignment port (emo) or -1	When updated	R
+0x0852	assign_out(hw_error)	2	short	assign_port[7]	The output allocation port (hw_error) or -1	When updated	R
+0x0854	assign_out(sw_error)	2	short	assign_port[8]	The output allocation port (sw_error) or -1	When updated	R
+0x0856	assign_out(abs_lost)	2	short	assign_port[9]	The output allocation port (abs_lost) or -1	When updated	R
+0x0858	assign_out(in_pause)	2	short	assign_port[10]	The output allocation port (in_pause) or -1	When updated	R
+0x085A	assign_out(error)	2	short	assign_port[11]	Running or -1 output gate	When updated	R
+0x085C	(Reserve)	-	-	-	-	-	-

User block

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x1800	intval0	4	integer	intval0	User variable (integer)	Not following the cycle	R/W
+0x1804	intval1	4	integer	intval1	User variable (integer)	Not following the cycle	R/W
+0x1808	intval2 - intval255	1016	integer	intval(n)	User variable (integer)	Not following the cycle	R/W
+0x1C00	floatval0	8	double	floatval0	User variable (dynamic commas)	Not following the cycle	R/W
+0x1C08	floatval1	8	double	floatval1	User variable (dynamic commas)	Not following the cycle	R/W
+0x1C10	floatval2 - floatval255	2032	double	floatval(n)	User variable (dynamic commas)	Not following the cycle	R/W
+0x2400	(Reserve)	-	-	-	-	-	-



Share memory and number of user blocks can be recorded

Memory address	Type of variable	Quantity

*) That is 4 bytes.

Control management block

Control status (csts)

R : Only read | R/W : Both Read and Write

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x2800	errcode	2	unsigned short	errcode	Số lỗi nghiêm trọng	When arising	R
+0x2802	bTeachMode	2	unsigned short	bTeachMode	Cờ trong giờ giảng dạy	When updated	R
+0x2804	bSPILargeFrame	2	unsigned short	bSPILargeFrame	Cờ giao tiếp SPI cho khung lớn	When updated	R

Operation information

(rbcfg)

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x2C00	manip_type	36	char (string)	manip_type	Operation information	No update	R
+0x2C24	manip_serial	36	char (string)	manip_serial	Continuing operation	No update	R
+0x2C48	format_version(major)	4	unsigned int	format_version[0]	Data structure version	No update	R
+0x2C4C	format_version(minor)	4	unsigned int	format_version[1]	Data structure version	No update	R
+0x2C50	format_version(patch)	4	unsigned int	format_version[2]	Data structure version	No update	R
+0x2C54	parameter_version(major)	4	unsigned int	parameter_version[0]	Data structure version	No update	R
+0x2C58	parameter_version(minor)	4	unsigned int	parameter_version[1]	Data structure version	No update	R
+0x2C5C	parameter_version(patch)	4	unsigned int	parameter_version[2]	Data structure version	No update	R
+0x2C60	(Reserve)	-	-	-	-	-	-

Robot status (rbsts)

R : Only read | R/W : Both Read and Write

Offset	Data	byte	Data type	Name of variable	Content	Update cycle	Users access
+0x3000	Command value (Descartes coordinates)	8	double	cmdx	Current command value	1ms	R
+0x3008	Command value (Descartes coordinates) Y [mm]	8	double	cmdy	Current command value	1ms	R
+0x3010	Command value (Descartes coordinates) Z [mm]	8	double	cmdz	Current command value	1ms	R
+0x3018	Command value (Descartes coordinates) Rz [deg]	8	double	cmdrz	Current command value	1ms	R
+0x3020	Command value (Descartes coordinates) Ry [deg]	8	double	cmdry	Current command value	1ms	R
+0x3028	Command value (Descartes coordinates) Rx [deg]	8	double	cmdrx	Current command value	1ms	R
+0x3030	(Reserve)	-	-	-	-	-	-
+0x3040	Arm posture (rescue flag)	4	unsigned int	posture	Posture (0 ~ 7)	1ms	R
+0x3044	(Reserve)	-	-	-	-	-	-
+0x3048	Specific score information	4	unsigned int	singular	Is there a special feature in the current position?	1ms	R
+0x304C	Multi -rotation information	4	unsigned int	multiturn	Multiple rotation information on each axis	1ms	R
+0x3050	Command value (Joint) J1[deg]	8	double	joint[0]	Current command value	1ms	R
+0x3058	Command value (Joint) J2[deg]	8	double	joint[1]	Current command value	1ms	R
+0x3060	Command value (Joint) J3[deg]	8	double	joint[2]	Current command value	1ms	R
+0x3068	Command value (Joint) J4[deg]	8	double	joint[3]	Current command value	1ms	R
+0x3070	Command value (Joint) J5[deg]	8	double	joint[4]	Current command value	1ms	R
+0x3078	Command value (Joint) J6[deg]	8	double	joint[5]	Current command value	1ms	R
+0x3080	(Reserve)	-	-	-	-	-	-
+0x3090	Speed	8	double	velocity	Current command value	1ms	R
+0x3098	Abnormal speed	4	unsigned int	vel_error_axes	The shaft has a speed error	When arising	R
+0x309C	Soft limit	4	unsigned int	softlimit	Is there near the limit of each axis	1ms	R
+0x30A0	Location right before TURNING OFF servo J1 [Rad]	8	double	joint_svon_to_swoff[0]	Location right before TURNING OFF	When arising	R
+0x30A8	Location right before TURNING OFF servo J2[rad]	8	double	joint_svon_to_swoff[1]	Location right before TURNING OFF	When arising	R
+0x30B0	Location right before TURNING OFF servo J3[rad]	8	double	joint_svon_to_swoff[2]	Location right before TURNING OFF	When arising	R
+0x30B8	Location right before TURNING OFF servo J4[rad]	8	double	joint_svon_to_swoff[3]	Location right before TURNING OFF	When arising	R
+0x30C0	Location right before TURNING OFF servo J5[rad]	8	double	joint_svon_to_swoff[4]	Location right before TURNING OFF	When arising	R
+0x30C8	Location right before TURNING OFF servo J6[rad]	8	double	joint_svon_to_swoff[5]	Location right before TURNING OFF	When arising	R
+0x30D0	(Reserve)	-	-	-	-	-	-
+0x30E0	Location storage flag right before TURNING OFF the servo	4	unsigned int	b_saved	Is the location right before TURNING OFF valid?	When arising	R
+0x30E4	(Reserve)	-	-	-	-	-	-
+0x37E8	(Reserve)	-	-	-	-	-	-
+0x37F0	(Reserve)	-	-	-	-	-	-
+0x37F8	(Reserve)	-	-	-	-	-	-

3. Memory I/O

1. Memory map (Physical I/O)

R : Only read | R/W : Both Read and Write

Type	Ad dre ss	Cont ent	Connected terminal (Signal name)	Python port number	Users access	
Physical Dido of 4 -byte controller (I/O connector)	0L	Digital input CN3: I/O 1 connector (input)	2A (IN1)	0	0x0000	R
			2B (IN2)	1	0x0001	R
			3A (IN3)	2	0x0002	R
			3B (IN4)	3	0x0003	R
			4A (IN5)	4	0x0004	R
			4B (IN6)	5	0x0005	R
			5A (IN7)	6	0x0006	R
			5B (IN8)	7	0x0007	R
			6A (IN9)	8	0x0008	R
			6B (IN10)	9	0x0009	R
			7A (IN11)	10	0x000A	R
			7B (IN12)	11	0x000B	R
			8A (IN13)	12	0x000C	R
			8B (IN14)	13	0x000D	R
			9A (IN15)	14	0x000E	R
			9B (IN16)	15	0x000F	R
	0H	Digital output CN4: I/O 2 connector (output)	2A (O1P), 2B (O1N)	16	0x0010	R/W
			3A (O2P), 3B (O2N)	17	0x0011	R/W
			4A (O3P), 4B (O3N)	18	0x0012	R/W
			5A (O4P), 5B (O4N)	19	0x0013	R/W
			6A (O5P), 6B (O5N)	20	0x0014	R/W
			7A (O6P), 7B (O6N)	21	0x0015	R/W
			8A (O7P), 8B (O7N)	22	0x0016	R/W
			9A (O8P), 9A (O8N)	23	0x0017	R/W
		Digital output CN5: I/O 3 connector (output)	2A (O9P), 2B (O9N)	24	0x0018	R/W
			3A (O10P), 3B (O10N)	25	0x0019	R/W
			4A (O11P), 4B (O11N)	26	0x001A	R/W
			5A (O12P), 5B (O12N)	27	0x001B	R/W
			6A (O13P), 6B (O13N)	28	0x001C	R/W
			7A (O14P), 7B (O14N)	29	0x001D	R/W
			8A (O15P), 8B (O15N)	30	0x001E	R/W
			9A (O16P), 9A (O16N)	31	0x001F	R/W
ArmDIDO 8 byte (I/O connector arm)	1L	Digital input	6A (I1)	32	0x0020	R
			6B (I2)	33	0x0021	R
			5A (I3)	34	0x0022	R
			5B (I4)	35	0x0023	R
		(Reserve)	-	36 - 47	0x0024 -0x002F	-
	1H	Digital output	3A (O1)	48	0x0030	R/W
			3B (O2)	49	0x0031	R/W
		(Reserve)	-	50 - 63	0x0032 -0x003F	-
	2	(Reserve)	-	64 - 95	0x0040 -0x005F	-
(Reserve)	3 - 127	-	-	96 -4095	0x0060 -0x0FFF	-

2. Memory map (System I/O)

R : Only read | R/W : Both Read and Write

Type	Address	Content	Python port number access		Users
System SI 16 bytes	128	Servo status	4096	0x1000	R
		emergency stop	4097	0x1001	R
		Error caused by the system (serious)	4098	0x1002	R
		ABS loss	4099	0x1003	R
		(Reserve)	4100 -4103	0x1004 -0x1007	-
		(Reserve)	4104 -4111	0x1008 -0x100F	-
		(Reserve)	4112 -4127	0x1010 -0x101F	-
	129	(Reserve)	4128 -4159	0x1020 -0x103F	-
	130	Robot program status	4160	0x1040	R/W
		Error status determined by the system	4161	0x1041	R/W
		Pause status	4162	0x1042	R/W
		System error status (*)	4163	0x1043	R/W
		System status	4164 -4167	0x1044 -0x1047	R/W
		error code	4168 -4175	0x1048 -0x104F	R/W
		(Reserve)	4176 -4183	0x1050 -0x1057	-
		(Reserve)	4184 -4187	0x1058 -0x105B	-
		(Reserve)	4188	0x105C	-
		(Reserve)	4189 -4191	0x105D -0x105F	-
System SL 16 bytes	131	(Reserve)	4192 -4223	0x1060 -0x107F	-
	132	(Reserve)	4224 -4255	0x1080 -0x109F	-
	133	(Reserve)	4256 -4287	0x10A0 -0x10BF	-
	134	Run the robot program	4288	0x10C0	R/W
		Decelerate to stop	4289	0x10C1	R/W
		reset the error	4290	0x10C2	R/W
		Pause	4291	0x10C3	R/W
		(Reserve)	4292 -4319	0x10C4 -0x10DF	-
User Input/Output 480 bytes	135	(Reserve)	4320 -4351	0x10E0 -0x10FF	-
	136-255	For users (*)	4352 -8191	0x1100 -0x1FFF	R/W

*) Error has been defined by the system (not serious or serious).

**About I/O Memory**

Physical I/O and System I/O are collectively referred to as I/O memory.

IEO () function only creates the interface to access I/O memory. Does not affect memory content.



The relationship between I/O allocation and Python port

Input

Functions	Related methods	Python port number	
		Physical I/O (*2)	Digital I/O

In

Functions	Related methods	Số cổng Python	
		Physical I/O (*2)	Digital I/O

*1) Error status caused by the system determined (not serious or serious).

Used to check 2 errors with 1 control line.

*2) This is recommended settings.



D Software

4

Steps to implement the program



1. The whole process	2
1. How to start robot program.....	2
2. How to implement	4



The whole process

1. How to start robot program

Step 1 Prepare teaching points.



Prepare teaching points in advance.

Also, please refer to the guidebook "Teaching ".)

Step 2 Write robot program



Create a robot program in the text editor on PC.

Establish prepared teaching points for step 1 for the robot program.

(Please refer to "programming guide" and "2 robot libraries".)

Step 3 Transfer robot program to controller.



File transmission between PC and controller with FTP client software.

(Please refer to the user manual "guide c" to know the connection method.)

Step 4 Run the robot program.

There are two methods to start.

Method 1 When starting from "I/O input"

Run the robot program from I/O input (hardware signal).

Set the port I/O 5 init.py.

Mainly used in automatic operation at production facilities.

(Please refer to "1 programming guide" and "2 robot libraries".)



Or

(Init.py is prepared in the controller.)

Step 2 When starting from "terminal software"






Use terminal software to connect with the controller and run the transferred robot program.

tttermpro.exe

Mainly used for testing and removing holes.

(Please refer to the user manual "guide c" to know the connection method)



 ATTENTION		
	Do not write a robot program in Init.py to start operating automatically as soon as the power is turned on.	
	When combining or sharing robots with a machine that can damage the robot, we recommend that you test all functional programs and motion individually, outside the working area of another machine.	

포인트!

The relationship between the promoting method of the robot program and the log output

The different diary data export method depends on the implementation method of the robot program. 「When starting from "I/O input"

Standard output, error output is stored in a file.

▪ Robot program



Output information	Save location	File name
Standard output	/opt/i611/log	userporg_out◇log
Error output		userporg_err◇log

Output information	Save location	File name
Standard output	/opt/i611/log	sys_out◇log
Error output		sys_err◇log

「When starting from "terminal software"

▪ init.py

Not stored in log files.

All output data, including error information, is displayed on the screen of the section



▪ Robot program (xxx.py)

Users can freely create robot movements with a robot library. Users can freely name the file. (xxx.py)

▪ System program (init.py)

Set description for control on I/O input by using Robsys layers in the robot library. Do not change the file name.



When starting from "I/O input"


Please refer 「1 Programming guide」, 「2 Robot library」.




When starting from "terminal software"

Start communicating with the controller.

(For example, the screen is Windows 8.1)



Run the program and start control.



The notes when using the Print () statement


Do not use too many print () statements when executed via I/O. If the error exceeds the controller capacity (C06) occurs due to this error, delete the log file and delete the print () statement. If you need to log in a large capacity, the log file should be written by using Rotatingfilehandler, Timedrotatingfilehandler of the log library instead of using print () ..

Related path:

<https://docs.python.org/ko/3/library/logging.handlers.html#logging.handlers.RotatingFileHandler>
<https://docs.python.org/ko/3/library/logging.handlers.html#logging.handlers.TimedRotatingFileHandler>



DOCUMENTS

- 
1. Block diagram
 2. Maintenance
 3. Terminology
 4. Solving problems
-



ZERO

MEMO



Z Data section

1

BLOCK DIAGRAM




1. System block diagram	2
1. System block diagram	2
2. Program list	3
2. Hardware block diagram	4
1. Control block diagram	4














1. System block diagram

1. System block diagram




2. Program list

Program name	Summary
i611:ROBOT PROGRAM 	<u>Created by users or SI.</u> This is a controller control robot program ..
i611:TEACHING DATA 	<u>Created by users or SI.</u> This is the file to save the coordinate information set by teaching.
i611:INITIALIZATION PROGRAM 	<u>Provided by the manufacturer. Can be modified by users or SI.</u> This is the file set to explain the I/O settings and how to run the robot program ..
i611:SYSTEM MANAGER 	<u>Provided by the manufacturer.</u> Make status management, control the status of teaching and handle errors of the robot program
i611:ROBOT LIBRARY 	<u>Provided by the manufacturer.</u> This file contains different modules necessary to program the movement of the robot ..
i611:CONTROL MANAGER 	<u>Provided by the manufacturer.</u> Status management, including booting and stopping the system as well as handling errors. Calculate the relationship between the angle and the posture (the World coordinate system) of each joint of the machine in real time and perform the control/speed control. This is an important part that makes up the movement.
i611:TEACHING MANAGER 	<u>Provided by the manufacturer.</u> Used to locate the controller, the output of the coordinates is stored in a file and allows the use of the output coordinates in the user program
i611:ROBOT CONTROLLER 	<u>Provided by the manufacturer.</u> Control user interface and JOG behavior.
i611:JOG CONTROLLER 	<u>Provided by the manufacturer.</u> Control the JOG bar. Get and process vibration signals, led lights and horns from Robot Controller.
i611:TEACHING UI 	<u>Provided by the manufacturer.</u> This is a browser user interface to establish teaching or operating robots.
i611:Web Browser 	<u>Use Chrome Browser provided by Google</u> JavaScript operation for teaching.

2. Hardware block diagram

ZERO

1. Control block diagram





Z Data section

2

MAINTENANCE



1. Checking.....	2
1. Points to note when checking	2
2. Daily inspection and periodic inspection.....	3
2. Maintenance	6
1. Manipulator	6
2. Controller.....	7
3. JOG stick.....	8
4. Teaching pendant.....	9

1. Checking

1. Points to note when checking



ATTENTION

	To use this product safely and for a long time, perform checks to prevent problems and ensure safety..	
	Do not use petroleum-based products when cleaning plastic parts.	 (Deformation/di scoloration)

Start checking after performing the following preparation steps.

1. Place “check” signs on controls and entrances to secure areas to prevent other workers from working inside while moving.
2. Workers ensure priority control by locking controls before work and carrying the key.
3. Ensure enough space and light for work.
4. The inspection is performed by someone who has completed a special training course on industrial robots.
5. Arrange the person on duty in a position to observe the entire situation and prepare for an immediate emergency stop.
6. Check the method of transmitting signals to each other.
7. Store inspection records for over 3 years.

Based on inspection time and operating time

$$15\text{h/day} \times 20\text{ days / month} \times 3\text{ months} = \text{about } 1,000\text{h}$$

Make sure to perform daily or regular checks to detect any abnormalities.

If there is a problem, it must be repaired immediately or take necessary measures to prevent the problem and ensure safety.

Try to perform outside the range of motion as much as possible, if working within the range of motion is unavoidable then take safety measures before doing it.

It is recommended to perform maintenance and inspection of the entire system according to the system integrated maintenance plan. Do not perform major testing (insulation resistance measurement).

2. Daily inspection and periodic inspection

Daily inspection ; Perform before operation

Before turning on the power (Check the checklist below before turning on the power.)

Test item (content)	Measures when there are abnormalities
1. Is the power cable securely connected?	Be sure to connect.
2. Are operator cables plugged in and locked?	Be sure to connect.
3. Are the I/O connectors and safety connectors securely connected??	Be sure to connect.
4. Are the controller connections loose?	Tighten the bolts securely.
5. Are the upper flange mounting bolts loose?	Tighten the bolts securely.
6. Are there any cracks or chips in the plastic part of the manipulator?	Stop using and contact a service center.
7. Are there any foreign substances such as powder or oil?	Check for any problems, clean and remove.
8. Are there any objects in the area of operation?	Remove objects to avoid interference.
9. Are the controller's intake and exhaust ports clogged with dust?	Please clean and remove.
10. Are there any cracks or chips on the JOG bar (optional product)?	Use products that do not have cracks or chip.
11. Are there any cracks or chips on the teaching pendant (optional product)?	Use products that do not have cracks or chip.
12. Are the main cable of the teaching device and the communication cable securely connected?	Be sure to connect.
13. Is the cable likely to be destroyed or damaged?	Use cables that are not torn or damaged.
14. Is the cable submerged in oil or water?	Keep clean from oil and water.
15. Is the power supply and voltage normal?	Check to see if there are any problems.
16. Is there a strange smell?	Stop using and contact a service center.
17. Is there oil, moisture, dust or foreign matter on the connector on the front of the controller?	Keep clean from oil and water.
18. Are operating temperatures and humidity within the range of usage conditions?	Use within the range of usage environments.
19. Are any devices or equipment connections loose or misaligned?	Check to see if there are any errors.
20. Are there any foreign substances in moving parts such as joints and end devices?	Check to see if there are any errors.

After turning on the power (Turn on the power while paying attention to the robot.)

Checking items (content)	Measures when there are abnormalities
21. Are there any unusual movements, strange sounds, strange smells when the power is turned on?	Be sure to connect.

During control (while running a program)

Checking items (content)	Measures when there are abnormalities
22. Is there an error in the position of the manipulator?	Are the bolts on the base or end-effector loose? Has the position of the fixture changed?
23. Does the controller operate abnormally, vibrate abnormally, or emit strange sounds or smells due to program operations?	Contact the service center.

Periodic inspection; Conduct more detailed inspections than daily inspections once a month_____

Manipulator

Checking items (content)	Measures when there are abnormalities
1. Are the bolts on each part of the manipulator loose?	Tighten the bolts securely.
2. Are the connector fixing bolts or the bolts on the connection terminal block loose?	Tighten the bolts.
3. Are there any strange noises coming from the coupling part (reducer)?	Contact the service center.

Controller


Checking items (content)	Measures when there are abnormalities
1. Are the controller's intake and exhaust filters dirty?	Clean or replace with new parts.

Teaching pendant (Optional)

Checking items (content)	Measures when there are abnormalities
1. Are there strange sounds coming from the Teaching pendant's speakers?	Contact the service center.
2. Is the Teaching pendant filter dirty?	Contact the service center.


1. Manipulator

Checking items	Content
【Before driving 】 external inspection	Check to see if any foreign substances such as powder or oil have seeped into the arm or joint area. Check to see if the bolts are loose. Make sure the encoder cover is not damaged.
【During driving】 Noise, position error	Check for any abnormalities in the steering sound. Make sure no location errors occur.




2. Controller

Checking items	Content
Cooling fan exhaust kit	Check if the exhaust port is blocked by dust or foreign objects. Air vents are located on the left and right sides of the controller.
Cooling fan extract kit	Check that the air intake port is not blocked by dust or foreign objects. If blockage or filter damage is observed, replace the filter.
Connection	Check if it is securely attached as shown in the picture below. Make sure there is no dust or foreign objects.




3. JOG bar

Checking items	Content
External inspection	Make sure there are no cracks or crevices.



4. Teaching pendant

Checking items	Content
External inspection	Make sure there are no cracks
	Check that the air intake and exhaust ports are not blocked by dust or foreign substances. If blockage or filter damage is observed, contact a service center.
Connection	Make sure they are securely fastened. Make sure there is no dust or foreign objects.



MEMO



Z Data section

3

TERMINOLOGY

1. Terminology.....	2
---------------------	---



3. Terminology

1. Terminology

A		
ABS Encoder	Absolute (absolute) encoder. The detector can output angle data to the outside. Location information is not lost even after power off	
ABS Loss	The encoder of the joint part loses absolute position information. This mainly happens when the brake is released while the controller is turned off. ABS Need to go back to the roots.	
ABS Zero Return	Active recovery from ABS loss. Reset the encoder of the joint to its original position with the control set to zero and regenerate the angle data. .	
API	Abbreviation for Application Programming Interface. software interface.	
Arm	The aluminum box between the joints. Length varies for each model.	
Asynchronous System	A system that allows simultaneous processing of other tasks during the exercise movement process. Predicts the target point and allows switching to the target point during movement.	
B		
Base coordinate System	The coordinate system is located on the robot's base floor Basically, when the offset is 0, it matches the world coordinate system.	
C		
C.CODE	This code combines controller and controller. Assign to each object. Abbreviation for Connection Code.	
CN1 Connector	Connector on the controller side for connecting the operation cable.	
CN2 Connector	Connector on controller side for connecting JOG stick or dummy connector.	
Command queue	Function that specifies the order of multiple commands, such as file transfers, command line processing, or session end commands	
Controller	A device that comprehensively controls the complex movements of the manipulator	
Control Manager	State management includes starting and stopping the system, error handling, calculations to determine the relationship between the angles of each joint of the robot and the position and posture of the robot's fingertips (WORLD coordinate system) and acceleration/deceleration control.	
Crossover counter	Settings to convert position type position data to unique joint type angle data. Set in the multidimensional parameter of the Position Type data. The value is updated when the angle of each joint exceeds $\pm 180^\circ$.	
E		
Euler angles	Represents the position relationship of two orthogonal coordinate systems.	

F		
FTP	Is a communication protocol for transferring files over the network (short for File Transfer Protocol).	
Factory default settings	Factory reset state.	
First Arm	Middle arm J2 - J3 .	
H		
Home Position	Position where all joints of the manipulator are at 0 degrees.	
Home Position	Position 0deg on each axis in the joint coordinate system (0, 0, 0, 0, 0, 0).	
Hold	Slow down to a stop, stop and wait. A state in which a robot program can be reused without termination.	
I		
I/O Start	Operation to start a robot program with a command entered into physical I/O or memory I/O.	
Initialization Program	Initial setup program (init.py)	
Initial Value	Initial default settings	
J		
Jog Stick	The device allows manual operation of the robot. Use during teaching.	
Joint	Moving parts of manipulator. Integrated structure of motor and encoder.	
Jumper Connector	Connector for automatic mode. Accessory.	
Joint coordinate System	The coordinate system is set by the joint axis. This is the coordinate system used to determine the position and posture according to the angles of the J1 axis to the J6 axis of the robot.	

L		
Linear Interpolation	While synchronously controlling the X-Y-Z axes, the composite trajectory will move so that it becomes a straight line. Similar to Line's operation.	
Line Motion	While synchronously controlling the X-Y-Z axes, the composite trajectory will move so that it becomes a straight line. Similar to linear interpolation.	
M		
Manipulator	Among the parts of the robot, the part that performs physical movements. Includes multiple arms and joints.	
Manipulator Cable	Controller and controller cable connection.	
Mechanical Home Position	Posture when all joints of the operator are aligned with the 0 mark. Posture when returning to ABS power	
Memory I/O	Generic term for controller physical I/O and system I/O.	
MDO Middle Digital Out	Function to switch I/O output to LOW/HIGH under specified conditions during operation..	
Multiturn	Cross counter information	
O		
Orthogonal coordinate system	X-Y-Z axis coordinate system. WORLD coordinate system. Base coordinate system. Generic term for all Cartesian coordinate systems, including user coordinate systems.	
Override	Override the setting value by multiplying the speed setting value by the ratio (%).	
P		
Parent Coordinate System	The information is used to establish guide points in the Cartesian coordinate system relative to the WORLD coordinate system. Used in Location class and Coordinate class.	
Physical I/O	The controller connects to the Tip I/O port	
Point To Point Motion	Action in which all joints move in a smooth curve at a constant speed toward a target coordinate	
Position	Location information	

Posture	The operator's posture information is represented by numbers 1 to 8.	
R		
Resume	Stop condition. Restart the activity in the hold state.	
Robot	The general term includes manipulator and controller.	
Robot Library	The file contains many modules needed to program the robot's movements..	
Robot Position	Controller end coordinates (Position type).	
S		
Safety Connector	An interface connector connects to a separate external protection device to cut off the robot's drive power and stop the manipulator operation in case of abnormal phenomena.	
Safety Plug	Similar to interlock plugs. The plug may block the steering control circuit for safety	
Second Arm	Middle arm J4 - J5	
Servo communication	Communication between 6 joints of manipulator and controller. Send and receive operating commands and status monitoring data.	
Slow down to Stop	Stop when decelerating by servo control.	
Step stop	Define a motor movement command as a single execution step, stopping each time the movement is completed.	
Synchronous System	A system that makes other tasks wait until the target point is reached during locomotor movement	
System I/O	System and program ports	
System Manager	Implement user robot program status management system control, teaching status control and error handling..	

T		
Task coordinate System	The coordinate system is determined by the task	
Teaching	The real task is to move the controller to remember the operations of the control program. Set the necessary information for operation using the JOG bar and PC.	
Teaching Data	Teaching point data file	
Teaching Manager	Teaching task control work (i611_teach.py).	
Teaching Parameter	Teaching point information. Includes coordinates and posture values.	
Teaching Pendant Tablet	Tablet computers have the ability to change many settings for teaching	
Teaching Point	The operator's coordinates are set by the instructor. Postures are included.	
Tool Coordinate System	The coordinate system is established based on the tool, the last part of the manipulator	
Tool Flange	The top flange of the mechanical interface with the tool contact surface is flat, as is the distal (end) flange.	
Tool I/O	The instrument's electrical interface is mounted at the top of the controller	
Top Flange	The top flange of the mechanical interface with the flat tool contact surface. Similar to the tool flange..	
U		
User Robot Program	User-generated robot motion program. (= robot program)	
W		
Work	Products and parts are being processed.	
World coordinate System	Coordinate system located on the ground or work floor Since the initial offset is 0, it matches the base coordinate system.	



Z Data section

4

Solving problems



1. Error Log.....	2
1. Configure Error Log	2
2. How to receive error log	2
2. Solving problems	3
1. Type of errors	3
2. List of system-defined errors	4
3. List of system-defined errors (Serious).....	5
4. How to handle errors	7

1. Configure error Log



The robot saves error log when detecting abnormalities.
If an error occurs, download the error log to your PC and contact the service center.

The Error Log file is a compressed file in .tgz format. Log compression error

Error Log folder : /opt/i611/log

ndstatus	Status log
userprog_out.log	User robot program output (print output)
userprog_err.log	User robot program output (exception output)
sys_out.log	System administrator output (print output)
sys_err.log	System administrator output (exception output)

(If the error log file size exceeds 200kB, it will be divided and saved..)

2. How to receive error Log

Step 1 Connect to PC.

Please refer teaching




Step 2 Select location to save error log

When not using USB memory

Download to computer.
(The error log is stored in the controller.)

When using USB memory

Download USB memory
Insert the USB memory into the controller



Step 3 Start a terminal program and connect to Telnet.

Run get_log.sh in /opt/i611/tools



Step 4 Receive error log

When not using USB memory

Transfer the error log generated in the /tmp controller from the FTP client to the PC. .



When using USB








Error log is created in USB memory..

Example of error log file : Log_SN16110017A_20170123_102914.tgz

1. Type of error

Errors are classified into four types.

Check the error type or code. Please refer to the troubleshooting guide. Errors are displayed on a 7-segment LED on the front of the controller.
























Error system diagram		
Error	System-defined error	 (Can be reset)
		 Serious (cannot be reset)
		 (can be reset)
	User-defined error (*)	 Serious (cannot be reset)
Type of error	Robot will not operate until an error is resolved	
System-defined error	User program	An exception arises.
	How to reset	Eliminate the cause of the error and enter the error reset command (cmd_reset()) or I/O (it will enter standby state after reset.)
System-defined error 	User program	Forced exit.
	How to reset	Remove the cause of the error and turn the power back on.
User-defined error (*) 	User program	An exception occurred.
	How to reset	Eliminate the cause of the error and enter the error reset command (cmd_reset()) or I/O (enter standby state after reset.)
System-defined error  (*)	User program	An exception occurred.
	How to reset	Remove the cause of the error and turn the power back on.

*) The two-digit number of the user-defined error code. Write appropriately for the application you use.

2. Danh sách lỗi do hệ thống xác định

Error code	Meaning
E01	E01 init.py not found.
E02	E02 An error occurred in init.py.
E03	E03 The robot program is not running.
E04	E04 The robot program has not been established yet.
E05	E05 Mode in which the robot program cannot be executed..
E06	E06 The robot motion API was used before open() of the i611Robot class was executed.
E07	E07 The robot program is executed when the ABS origin is lost.
E08	E08 The robot program terminated abnormally.
E09	E09 The Robot program executes open() in class i611Robot during an emergency stop.
E10	E10 The Robot program executes open() in i611Robot class while the servo is OFF.
E11	E11 The robot program has not been authorized to operate.
E12	E12 The robot program cannot communicate with the system administrator.
E13	E13 There are no exceptions for emergency stops.
E14	E14 Abnormal termination of the Robot program's exit() method.
E15	E15 The robot program ended with an exception.
E16	E16 There are no exceptions to stopping deceleration.
E17	E17 System termination process not completed
E18	E18 Unable to access memory I/O.
E19	E19 Instances of the i611Robot class are created multiple times in a single process.
E20	E20 open() in class i611Robot was opened multiple times in one process.
E21	E21 The inconsistent API call occurred in another thread.
E40	E40 The teaching process ended abnormally..
E53	E53 Usage of home directory (/home/i611usr) has exceeded the limit..
E99	E99 Another error occurred.

3. List of system-defined errors (Serious)



Error code	Meaning
	c01 System Manager failed to start.
	c02 System administrator terminated abnormally.
	c03 The system administrator cannot communicate with the controlling administrator.
	c04 An error occurred in JOG operating mode.
	c05 Control Manager terminated abnormally.
	c06 There is no more storage space left on the controller.
	c10 (Matching) circuit is broken.
	c11 (Matching) overcurrent arises.
	c12 (Matching) A brake error has occurred. (When servo OFF → ON)
	c13 (Matching) Excessive torque detected..
	c14 (Matching) overload (heat) occurs.
	c15 (Matching) Drive voltage has decreased..
	c16 (Matching) An AC power abnormality has occurred.
	c17 (Matching) A servo communication error has occurred.
	c18 (Matching) Servo 1 ON indicator error has occurred. (does not operate normally.)
	c19 (Matching) Servo 2 ON indicator error has occurred. (Z, not detected.)
	c20 (Matching) ABS loss: Absolute encoder value cannot be detected.
	c21 (Match) ABS loss: An error occurred in the absolute encoder value..
	c22 (Match) ABS loss: Unable to detect the incremental encoder value..
	c23 (Matching) ABS loss: Progressive encoder is broken
	c24 (Matching) ABS loss: The battery voltage of the progressive encoder has decreased.
	c25 (Matching) An error occurred during the state change condition.
	c26 Abnormalities arise at Tip I/O.
	c28 An error occurred during internal screen processing.
	c29 The cooling fan has stopped.





4.Solving problems
2. Solving problems

System-defined error (Serious)

Error code	Meaning
c30	Regenerative resistor 1 error has occurred.
c31	Main circuit relay is broken.
c32	Wiring error detected in "emergency stop circuit".
c33	Wiring error detected in "mode circuit".
c34	An error has occurred in the control power supply.
c35	Detects thermal anomalies in resistors to prevent intrusion.
c36	Regenerative resistor 2 error has occurred.
c37	A secondary regenerative resistor error has occurred.
c39	The robot's communication has been cut off.
c40	A backup signal mismatch has occurred in the "gate circuit".
c41	There has been a mismatch in the duplex signal in the "mode circuit".
c42	An error occurred depending on the state transition time.
c43	A communication error occurred due to an interruption.
c44	Overspeed slave error occurred.
c58	Error occurred in the SPI circuit.
c59	An error was detected in the robots definition file.
c60	An operation error has occurred.
c89	(Match) An error occurred in the EtherCAT communication packet..
c91	(Match) Abnormal detection of abnormal position and speed deviations.
c92	(Match) Match parameter error detected.
c93	(Match) An encoder communication error has occurred..
c94	(Joint) The control panel is too hot.
c95	(Match) A synchronization error occurred in EtherCAT communication.
c96	(Match) An error occurred during control synchronization.
c98	Power supply is cut off.
c99	Another error occurred.






4. How to handle errors

Type of error		Error handling instructions
System-defined error 		The robot will not operate until the error is resolved. Please refer to the following troubleshooting solutions.
	User program	An exception occurred.
	How to reset	Eliminate the cause of the error and issue an error reset command (cmd_reset()) or I/O input (go to wait state after reset.)
System-defined error 		The robot will not operate until power is restored. Since the internal operation of the controller continues, data cannot be imported from the outside. If you do not see improvement, contact a service center.
	User program	Forced exit.
	How to reset	Remove the cause of the error and turn the power back on

	init.py not found.	
	Reason	init.py is missing from controller /home/i611usr/.
	Measure	Copy init.py from /opt/i611/tools/ to /home/i611usr/.
	An error occurred in init.py.	
	Reason	There is an error in the init.py code.
	Measure	Check init.py.
	The robot program is not running.	
	Reason	The robot program is not specified properly.
	Measure	Checks the specified file name. Example) rbs = RobSys() rbs.open() rbs.set_robtask ('filename.py')
	The robot program has not been established yet.	
	Reason	Missing specified by rbs.set_robtask('filename.py') or specified a file that does not exist..
	Measure	Check the filename specified in rbs.set_robtask('filename.py').

- 4.Solving problems
2. Solving problems

E05	Become a mode that the Robot program cannot perform.	
	Reason	The jumper connector (accessory) is not connected to CN2 on the controller.
	Measure	Make sure the jumper connector is connected to CN2. The robot program cannot be run if the JOG bar is connected to CN2 or if nothing is connected.
E06	The robot motion API was used before open() of the i611Robot class was executed.	
	Reason	There is no description of the i611Robot class in the robot program. or the i611_MCS module cannot be imported.
	Measure	Robot program rb=i611Robot() rb.open() Check to see if it has been described above
E07	Execute the Robot program while losing the ABS base point.	
	Reason	Return of ABS origin does not take place, or the robot chassis emergency stop switch is turned off.
	Nguyên nhân	Ngoại lệ không mong đợi đã xảy ra trong chương trình robot. Proceed to adjust the operating origin of ABS. "Recovering ABS base point for operation" in the procedure book
	Biện pháp	Arm Module User Guide [Teaching C] Kiểm tra chi tiết lỗi trong chương trình robot và sửa lỗi.
E09	The robot program executed open() of class i611Robot during an emergency stop..	
	Reason	The robot program starts by pressing the emergency stop switch.
	Measure	Release the emergency stop switch.
E10	The robot program executed open() of the i611Robot class while the servo was OFF.	
	Reason	When the servo was turned off, open() of the i611Robot class was executed.
	Measure	Please turn on the servo.

	The robot program is not allowed to operate yet..	
	Reason	Duplicate calls or open() with rb=i611Robot() rb.open(permission=False) in class i611Robot.
	Measure	Check if rb=i611Robot() rb.open(permission=True) (← rb.open()) is included in the Robot program. Or make sure you don't call multiple open().
	The robot program cannot communicate with the system administrator.	
	Reason	An unexpected error occurred.
	Measure	Re-apply power to the controller. If there is no improvement, contact the service center..
	There are no emergency stop exceptions.	
	Reason	There is no description of the try statement or the try statement is missing an except description.
	Measure	In the Robot program check to see if it is included try: ... except Robot_emo: or not .
	Abnormal termination of the Robot program's exit() method.	
	Reason	In a robot program, the argument to the exit() method specifies a non-zero value.
	Measure	On normal termination, the exit() method's argument is set to 0. rb=i611Robot() ... rb.exit (0)
	The robot program ended with an exception.	
	Reason	An exception occurred due to a programming error.
	Measure	Check error details and fix the faulty program.


4.Solving problems
2.Solving problems

E 16	There are no exceptions for deceleration to stop.	
	Reason	There is no description of the try statement or the try statement is missing an except description.
E 17	Measure	In the Robot program check to see if it is included try: ... except Robot_stop: or not .
	The system has not completed the shutdown process.	
E 18	Reason	Handle interrupt (Robot_emo) when emergency stop time expires.
	Measure	Set the emergency stop interrupt processing to complete within 5 seconds and terminate the program.
E 18	Unable to access memory I/O.	
	Reason	The I/O connector is not connected to properly or the Control Manager is disconnected abnormally.
E 18	Nguyên nhân	Thực thể của lớp i611Robot được tạo nhiều lần trong một quy trình.
	Measure	Trong chương trình robot, một số thực thể của lớp i611Robot được mô tả. Check the connection status of the I/O connector.
E 20	Measure	Check if you are calling multiple instances of the i611Robot class in a single process.
	open() of the i611Robot class is executed multiple times in a single process.	
E 21	Reason	Described some open() of the i611Robot class in the Robot program.
	Measure	Please check if open() of class i611Robot is called multiple times in one process..
E 21	The inconsistent API call occurred in another thread.	
	Reason	Calling a method that has been prohibited from being called in another thread or without creating an entity.
E 21	Measure	Create an entity and call. The API of the i611Robot class can be called from another thread: abort(), stop(), pause() and restart().

E40	The teaching process ended abnormally..	
	Reason	Teaching Manager terminated abnormally.
E53	Measure	Re-apply power to the controller. If there is no improvement, contact the service center..
	Usage of home directory (/home/i611usr) has exceeded the limit..	
E99	Reason	The controller's home directory is incomplete.
	Measure	Free up space in the folder, move unnecessary files in /home/i611usr to /home/i611usr/ex.
E99	Another error occurred.	
	Reason	An unexpected error occurred.
E99	Measure	Re-apply power to the controller. If there is no improvement, contact the service center..

MEMO

MEMO



Service center

Zeus: 132 Annyeongnam-ro, Hwaseong-si, Gyeonggi-do

e-mail : zero@globalzeus.com