




General Purpose Robot Arm for Industry Use

ZERO

Delta Robot Installation Guide



| | |
|---------------------------------------|----|
| Introduction | 2 |
| Safety Precautions | 4 |
| 1. Mounting the Manipulator | 6 |
| 2. Controller Installation | 8 |
| 3. JOG Stick | 12 |
| 4. Teaching Pendant | 13 |
| 5. Connecting Controller and PC | 15 |
| 6. Wiring and Connections | 18 |
| 7. Turning on the Power | 20 |
| 8. JOG Operation | 24 |
| 9. ABS Homing | 26 |
| Preparing for Teaching | 29 |
| Troubleshooting | 31 |

Document Number : M-0102-211018

October 2021

Introduction



Thank you for your purchase of the general-purpose industrial robot "ZERO"



- Using this product requires "the special education on industrial robots", "qualifications for electrical work", knowledge and skills for robots and a programming language "Python".
 - For safe and proper use of the product, please read the product manuals carefully.
 - Product specifications are subject to change without notice (due to potential future product improvement initiatives).
- We recommend keeping the product manuals handy at all times for easy access.
 - The contents of this document are subject to change without notice.
 - Reproducing or copying the information contained herein, in whole or in part, without prior approval of ZEUS CO., LTD is strictly prohibited.

Purpose of this Guide

The installation guide is a quick guide to help you with installation procedures from mounting the robot "ZERO" through ABS Homing operation.

The next step of ABS Homing is teaching the robot.


For safe use of the product "ZERO", please read the manuals as well as this manual carefully.

Product Overview

This product comprises a manipulator and a controller as shown below.

"ZERO" (= Robot)


"ZERO" consists with a manipulator and a controller



Manipulator

The manipulator is an 3-axis (optional 4-axis) parallel robot actuated by servo motors.

Attaching different end-effectors to the manipulator-tip allows the robot to be adapted for various tasks.



Controller

The controller is a control board that includes control circuitry and a power supply board.

The controller handles communications with the host controller through I/O interfaces, and comprehensively controls motions of the manipulator.

Introduction



Checking Items Upon Unpacking

Please compare the actual items received with your product purchase order.
Should you have any problems, please contact the customer service.

Introduction

| | | |
|----------------------|--|-----------------------------|
| <h3>Manipulator</h3> | | <p>Manipulator</p> <p>1</p> |
|----------------------|--|-----------------------------|

| | | | |
|----------------------------|---|--|---|
| <h3>Controller</h3> | | <p>User's Guide & Safety Guide</p> <p>1 Copy</p> | <p>I/O Connectors & Safety Connectors</p> <p>(20 pins)</p> <p>4</p> |
| <p>Controller</p> <p>1</p> | <p>Installation Guide (this document)</p> <p>1 Copy</p> | <p>Coding profile keys</p> <p>1 set (6 keys)</p> | <p>Jumper Connector</p> <p>1</p> <p>For automatic operation, this needs to be connected to CN2.</p> |
| | | <p>Manipulator Cable</p> <p>1</p> | <p>Ferrite Core</p> <p>2</p> <p>For Power cable</p> |



The C. CODE is unique to each robot. Connect the controller with its C. CODE matching manipulator.

Connect only a C. CODE matching pair of the manipulator and the controller to each other.





Safety Precautions





Safety Signs









This manual uses the signs below to indicate serious but avoidable problems caused by misuse of the product. One is for death or serious bodily harm. The other is for bodily injury or product or equipment damage.

| | |
|--|--|
|  Danger | Identifies information about imminent hazards that will result in death or serious injury. |
|  Caution | Identifies information about hazards that could result in injury or equipment damage. |

Throughout this document, the safety precautions that users must follow are marked as follows.

| | |
|---|---|
|  | Safety Precaution - "Prohibited Action" |
|  | Safety Precaution - "Mandatory Action" |

The following symbols used in this manual identify information about anticipated hazards.

| | |
|---|--|
|  | <u>Cautions and Dangers</u> Causes unexpected, unstable, or uncontrolled motions. Compromises the performance or reliability of the product. Shortens the product life. |
|  | <u>Electric shock hazard</u> |
|  | <u>Burn hazard</u> |
|  | <u>Fire hazard</u> |
|  | <u>Injury hazard</u> |
|  | <u>Failure and damage hazard</u> |
|  | <u>Collision hazard</u> |
|  | <u>Trip and fall hazard</u> |

Safety Precautions



Releasing the Brake in an Emergency

In case of emergency, you can manually release the brake of any manipulator joint and move the manipulator.


| | | |
|--|--|--|
| | <p>Do not enter the area under the arm when releasing the brake.. Ensure that there are no people in the robot's range of operation. The arm may drop under its own weight when you release the brake manually</p> | |
| | <p>If there is potential hazard such as interference with surroundings, take a non-hazardous position and release the brake.</p> | |

How to release the brake

Connect the controller and the manipulator using the manipulator cable, and turn on the power to the controller. Power to the robot becomes present. Note that the brakes cannot be released unless the robot is powered on. To release a brake, press the brake release button located at each joint.

Brake Release Button

The robot brakes could not be turned off when it has no power.




The brake releases while pressing the brake release button.


Bolts/Screws and Torque Tightening

| Size | Torque Tightening (N·m) (1.8T, vehicle/engine use) |
|------|---|
| M3 | 1.14 |
| M4 | 2.7 |
| M5 | 5.4 |
| M8 | 22.0 |

1. Mounting the Manipulator




Component Features




The shape of the frame is an example. The shape and dimension can be changed due to product improvement or circumstances.

Details of the tool center point



Mounting the Manipulator



Precautions for Installation

| | | |
|--|--|--|
| | <p>Observe the mounting styles specified below and mount the manipulator properly.</p> <p>To mount on the frame, using all 6 bolts is recommended.</p> | |
|--|--|--|

Packing and Shipping

- Controller
Lift the lower part to avoid any impact on the front and intake vent.
- Manipulator
Don't hold the joint part and the end effector.

Mounting Configurations

OK Floor-mount

NG Ceiling-mount

NG Wall-mount


Precautions for Installation

Watch out for interference of the manipulator and the cable.



Carefully read details and precautions for the dimensions of installation space, the work envelope, arm postures, the end-effector design, and arm I/O.

Mounting the Manipulator


2. Controller Installation



Component Features



Controller Installation



7-Segment Display Panel and LED Indicators

The 7-segment display panel and three LED indicators display states of the robot. The period blinking in the bottom right corner of the 7-segment display panel indicates that the controller system is in operation.


| Display | Description |
|---------|--|
| | Starting the controller |
| | Initializing the controller |
| | READY state (stand-by) |
| | ABS Lost state (*1) |
| | Teach Mode |
| | JOG Operation Mode |
| | Executing User program |
| | Pausing User Program |
| | Processing Power OFF |
| | System-Defined Error (*2, *4) |
| | System-Defined Error Fatal (*2, *5) |
| | User-Defined Error (*3, *4) |
| | User-Defined Error Fatal (*3, *5) |

- *1) When started for the first time, the manipulator is in a state of the absolute position being lost.
- *2) For more information on system-defined errors, refer to "Troubleshooting." P.28
- *3) Any user-defined errors can be created using Python programming.
- *4) For a non-fatal error, eliminate the cause, and then recover with "Error reset signal."
- *5) For a fatal error, eliminate the cause, then power cycle.

LED Indicators


LED

- Solid Green: Controller power ON
- Solid Green: Executing the user program
- Blink: Logging
- Solid Green: in a state of Servo-ON



Period blinking:
System in operation

Controller Installation




Mounting



Provide sufficient space for installation.
Refer to the clearance around the controller illustrated below.


We recommend using mount screws (M3 at 4 spots) to the side of the controller as a fall prevention measure.
Do not install a manipulator in an enclosed space. Do not block the exhaust (or intake) vent(s).

When designing metal fittings, take it into consideration that the cover fixing screws are 20 mm away from the controller mount holes. In addition, do not let metal fittings block the air intake vents.



*) user-supplied

Controller Installation



Safety Connector



Connect the safety connector correctly.

If not, the manipulator cannot be operated.

CN6: Safety Connector Pinout



| Terminal | Signal Name | Description | Terminal | Signal Name | Description |
|----------|---------------|--|----------|----------------|--|
| 1A | EMS1_H+ (P24) | Emergency stop switch 1a, Controller 24V | 1B | E MS1_L+ (P24) | Emergency stop switch 1a, Controller 24V |
| 2A | EMS1_H- | Emergency stop switch 1a | 2B | EMS1_L- | Emergency stop switch 1a |
| 3A | EMS2_H+ | Emergency stop switch 2a | 3B | EMS2_L+ | Emergency stop switch 2a |
| 4A | EMS2_H- | Emergency stop switch 2a | 4B | EMS2_L- | Emergency stop switch 2a |
| 5A | MODE_H+ | Mode switch | 5B | MODE_L+ | Mode switch |
| 6A | MODE_H- | Mode switch | 6B | MODE_L- | Mode switch |
| 7A | SVON_MON+ | Servo-ON monitor output | 7B | SVON_MON- | Servo-ON monitor output |
| 8A | READY_H | READY contact output | 8B | READY_L | READY contact output |
| 9A | SVON_H+ | Servo-ON input | 9B | SVON_H- | Servo-ON input |
| 10A | NC | Not use | 10B | G24 | Controller 24 V GND |

Safety Connector (*)


Product Number:DFMC 1,5/10-ST-3,5-LR
1790564

(from PHOENIX CONTACT)

*) same as I/O connectors 1, 2, and 3



Wiring Example of Safety Connector



Install more than one emergency stop switch.

Attach jumper wires to the EMS input terminals which will not be used.

required

Emergency Stop Switch/Mode Switch

If only one end of these redundant circuits is connected, an error will be detected. Please also short circuit the MODE terminals.

optional

Servo-ON monitor

optional

READY monitor

required

Servo-ON input



Do not connect any connector



*) Use EMS2 terminals for interlocks and light curtains which will prevent workers from entering the robot work area.

For the equipment to be connected, use a product that conforms to the applicable standards such as IEC61496. Use the product correctly according to its user guide and be sure that it can make an emergency stop.

If more than one piece of equipment are to be connected, wire them in series.


3. JOG Stick



Component Features

Use a Jog Stick (optional product) to jog each axis of the manipulator.

Jogging operation is used for Homing and Teaching.




Jumper Connector (included accessory)



When you are not using a Jog Stick, connect the jumper connector (included accessory) to the controller.


The robot operation mode depends on whether or not a Jog Stick is connected to the controller.

Do not power up the controller without the CN2 connector connected.



| Operation Mode | Function |
|----------------|---|
| Remote | The jumper connector is connected to the controller. ⇒ Automatic operation mode |
| Teaching | The Jog Stick is connected to the controller. ⇒ JOG or TEACH operation using the Jog Stick |

4. Teaching Pendant



Teaching Pendant



Do not use external power adapter terminals and UBS terminals when operating the manipulator using the teaching pendant.



5. Connecting Controller and PC




Downloading the Software

This section describes the software required for the PC to be connected to the controller.



「FFFTP」: FTP Client Software

Use FTP (File Transfer Protocol) to transfer files between the PC and the controller.



Depending upon your PC's OS, select either the 32-bit or 64-bit version.

Do not change the initial settings for installation.


(The BSD New License of FFFTP is owned by Jun Sota, FFFTP Project.)

URL <https://osdn.net/projects/ffftp/>



「TeraTerm」: Terminal Software

Tera Term is a remote access client which allows you to operate the controller by executing motion programs with telnet protocol.



Do not change the initial settings for installation.

(The BSD License of Tera Term is owned by T. Teranishi and Tera Term Project.)

URL <https://osdn.net/projects/ttssh2/>

Connecting Controller and PC



Setting Up the Software

Set up the software for the controller connection.

Start "FFFTP".

Click on **New Host ...** to configure host settings.

Host settings

| | |
|-------------------|--------------------|
| Profile Name | i611 (or any name) |
| Host Name/Address | 192.168.0.23 |
| UserName | i611usr |
| Password/Phrase | i611 |

Click on **Connect**

(The screenshots are from Windows 10)

Connecting Controller and PC

Launch "Tera Term".

Host settings

| | |
|-------------|--------------|
| Host : | 192.168.0.23 |
| Service : | Telnet |
| TCP port #: | 23 |

(The controller must be powered on.)

Controller Authentication

| | |
|-----------|---------|
| login: | i611usr |
| Password: | i611 |

Connecting Controller and PC



Setting up Connection to the Controller

Step 1

Go to Start > Control Panel > Network and Internet > Network and Sharing Center. Click Change Adapter Settings.

Step 2

Right-click on Ethernet, and then select Properties.

Step 3

View the property of Internet Protocol Version 4 (TCP/IPv4).

Step 4

Enter the IP address and the subnet mask, then click **OK**.

| | |
|--------------|------------------|
| IP address: | 192. 168. 0. XX |
| Subnet mask: | 255. 255. 255. 0 |

(Enter any two-digit number other than 23 in XX.)

(The screenshots are from Windows 10)

Viewing the TEACH window using Google Chrome:


- Start the web browser (Google Chrome) in privacy mode.
- To open the TEACH window, enter the IP address.

MEMO

6. Wiring and Connections



System Configuration Diagram




Wiring and Connections



Wiring and Connections

I/O Controller

(customer-supplied)




20 pins

Connect to I/O connectors 1, 2, and 3.
 CN3 : I/O1 input
 CN4 : I/O2 output
 CN5 : I/O3 output

For wiring work, refer to the signal pinouts and the circuit diagram.


An input signal is detected at a rising edge of the input. When an output becomes ON, its corresponding output port will be High.




Input Signal

Safety Circuit

(customer-supplied)



20 pins



Emergency Stop Switch Servo-ON Switch

Connect to the safety connector.

! Connect an emergency stop switch or a Servo-ON switch. Improper connections disable Servo-ON.

I/O Cable


(customer-supplied)

!


- Provide sufficient separation from high voltage lines and motor power lines.
- AWG16-24
- Take noise into account and keep the wire length within 15 meters.

Manipulator Cable

(included)
 Cable length 3m




Ferrite Core (included)




Do not remove any of the included ferrite cores.

!

The C. CODE is unique to each robot. Connect the controller with its C. CODE matching manipulator. Check the C. CODE labels on the manipulator and the controller. Only a C. CODE matching pair of them may be connected.



7. Turning on the Power



Charging the Absolute Encoder

| | | |
|--|--|--|
| | Before turning on the power, verify that wiring is all complete. | |
| | Do not hot-swap any connectors. | |

Upon shipment, the robot is in an "ABS LOST"


| | |
|--|--|
| | When starting up the robot for the first time, charge the backup battery for the absolute encoder. Do not power up the controller without the CN2 connector connected. |
|--|--|

Charging Method

1. Connect the controller and the manipulator.
2. Charging starts when the controller is powered up.


Connect the controller and the manipulator as shown in the wiring diagram below.
 Wiring doesn't have to be complete like the [System Configuration Diagram](#) in [6. Wiring and Connections](#).

Example of Wiring for Charging



when finished... Charging starts even while the controller is in an error state. All of the manipulator joints have one backup battery each.

| | |
|--|---|
| | Always perform ABS Homing after charging is complete. |
|--|---|



Before Turning on the Power

There are different ways of preparation, depending on your target operation.

For ABS Homing

Using the alignment marks at the joints, align all axes manually or by jogging the robot.

Method 1

Manually release the brakes and move the manipulator arms.



Releasing the Brake in an Emergency



Method 2

Perform Jogging operation to move each joint of the manipulator.




Starting JOG Operation Mode




For Automatic Operation

AUTO mode where the robot is automatically controlled by the Python program

Connect the jumper connector to the controller.



Jumper Connector (included)




Controller




Do not power up the controller without the CN2 connector connected.






For teaching the robot (JOG Stick)

connect a Jog Stick to the controller.



Jog Stick
(optional)



Controller

For teaching the robot (Teachig Pendant)


Teaching pendant cable consists of two strands of cable.
Connect communication cable to the controller's Ethernet 0(below).
Connect main cable to the controller's CN2.



Teaching Pendant
(optional)

Connect communication cable

Connect main cable




Controller



Do not power up the controller without the CN2 connector connected.





Turning on the power

When the power is turned on, the following status codes will appear on the 7-segment display panel.



7-Segment Display Panel

| | |
|---|--|
| | Starting the controller |
| ↓ (approximately 10 seconds) | |
| | Initializing the controller |
| ↓ (approximately 10 seconds) When initialization is completed, one of the following will appear. | |
| | The absolute home positional data is lost (ABS Lost). This will appear when the system is <u>powered on for the first time</u> or <u>ABS Lost</u> has occurred. Perform <u>ABS Homing</u> . (*) |
| | Ready (standby state) This code indicates that <u>ABS Homing</u> has been completed. The robot is in a <u>standby state</u> . |
| | Error Check the error code and fix the error. |
| | |

*) When the manipulator is powered on for the first time, it is missing the absolute positional data.

8. JOG Operation



Starting/Ending JOG Operation Mode

JOG operation mode enables you to operate the manipulator safely. Use this mode for aligning the joints via the alignment marks in order to recover the absolute position.


Start

Step 1 Connect

For connections, see the figure to the right.

Connect the safety connector circuit to CN6. (*)
(Emergency stop switch and MODE switch)


*) customer-supplied




Step 2 Start

Turn on the controller while long pressing the push button of the Jog Stick.

Keep holding down the push button until **JOG** appears on the 7-segment LED display on the controller.



Push Switch



In the Event of an Error




JOG operation error

Recovery Method

Power cycle the controller.

End

Turn off the controller power.




JOG Operation



JOG Operation

Use a Jog Stick (optional product) to jog each joint of the manipulator. An operation of jogging a robot is used for Homing and Teaching.




Step 1 Change the right slide switch position to the **Top**.


Step 2 Press the Enable switch to turn the servo on.

Step 3 Tilt the control lever to start jogging a robot.




Toggle the left slide switch between **Top** **Center** **Bottom** to select the target joint to operate.






JOINT Coordinate System



Joint J1, J2




Joint J3, Rz





JOG Operation



WORLD Coordinate System



X, Y axis



Z, Rz axis



When the WORLD coordinate system is used, unreachable points may exist even within the work envelope, due to the structure of manipulator. Use the JOINT coordinate system to avoid or recover from singularity points.

The JOINT Coordinate System enables the robot to move anywhere in the work envelope.

9. ABS Homing



ABS Homing



When turning on the robot for the first time, be sure to perform ABS Homing.

- ABS Homing must be done in a Servo-OFF state.
- "Manually" or "by JOG operation", align all axes via the alignment marks. (*)
- The servo needs to be turned on in the midst of ABS Homing. Prior to ABS Homing, connect the Jog Stick or a switch for turning on the servo.



Homing is required if the robot is in an ABS LOST state (e.g., upon unpacking). Homing does not have to be performed regularly.

*) The home position varies depending on the model of manipulator. Check the alignment marks carefully.




*) When performing ABS Homing for each specific joint, be sure to align the alignment marks of the joint specified.

*) The alignment marks are enlarged in the drawings throughout this document. Use them as reference for the locations of actual alignment marks.

Step 1 Initial home positioning of the manipulator

By "Manual" or "JOG Operation", align all axes via the alignment marks.

(Example of ZRC-0306R homing posture)



(continue to the next page)

ABS Homing



ABS Homing

Step 2 Executing the robot program "enc_reset.py"

Connect with the controller via Telnet.

Execute the ABS Homing program.

To specify all joints at once,

\$enc_reset.py

To specify one or more joints,

Enter a space followed by a joint number(s).

\$enc_reset.py 23 ← Specify Joint 2 and 3

The following confirmation message will appear.

Target Joint(s) : All ← To specify all joints at once,

OK? [Y/n] Y_ ← Enter "Y" (in uppercase).

The following message will appear.

Reset target = 3F ← To specify all joints at once,

Please turn servo power on to continue

A confirmation message will appear when the SERVO-ON is completed.

Enter Y to turn servo power off

Ready? [Y/n] Y_ ← Enter "Y" (in uppercase).

The following message will appear.

Please adjust each joint position to the bar label.


Done? [Y/n] Y_ ← Enter "Y" (in uppercase).

The following message will appear.

[OK] Reset encoder success!

Please reboot controller...


You are prompted to restart the controller.



(Example of specifying all joints at once for ABS Homing)



Turn on the servo.

Press the Enable switch.



Step 3 Restarting the Controller

When ABS Homing is completed, the 7-segment display panel on the controller will turn "rdy".



ABS Homing



Checking ABS Homing Result



After ABS Homing, follow the procedure described below and confirm that the manipulator is indeed in the home position.



Step 1 Execute the confirmation program "confirm_home.py"

Connect with the controller via Telnet.

Execute the confirmation program.

```
$confirm_home.py
```

Keep on pushing on the Enable-switch of JOG stick then execute "confirm_home.py".

The following confirmation message will appear.

```
Are you ready to move? (y/n) y
```

Enter "y" (lowercase).

Enter "y" and press Enter. All joints will return to the home position (i.e. the alignment marks will be aligned).
Note that As for the speed of the "confirm home.py", the speed of joint moving the longest distance is 1% of fastest.

The following confirmation message will appear when the homing motion is complete.

```
Position OK? (y/n) y
```

Enter "y" (lowercase).

```

192.168.0.23 - Tera Term VT
메뉴(F) 수정(E) 설정(S) 제어(O) 창(W) 도움말(H)
$ enc_reset.py

192.168.0.23 - Tera Term VT
메뉴(F) 수정(E) 설정(S) 제어(O) 창(W) 도움말(H)
$ confirm_home.py
Target Joint(s): All


New target (SN=***** )
initial_offset = [0,0, -775680, 0, 0, 0]
adjust_offset = [0, 0, 0, 0, 0, 0]
move_pulse = [0,0, -775680, 0, 0, 0]
Current Pls: [xxx, xxx, xxx, xxx, xxx, xxx]
Target Pls : [0,0, -775680, 0, 0, 0]
Are you ready to move? (y/n) y

adjust_offset = [0, 0, 0, 0, 0, 0]
move_pulse = [0,0, -775680, 0, 0, 0]
Current Pls: [xxx, xxx, xxx, xxx, xxx, xxx]
Target Pls : [0,0, -775680, 0, 0, 0]
Are you ready to move? (y/n) y
Position OK? (y/n) y
    
```

Step 2 Check the execution result of "confirm_home.py"

Check the pair of alignment marks at each joint are indeed aligned.

Example results of executing "confirm_home.py"



The alignment marks are off.

Preparing for Teaching




Overview of Teaching Procedure

After ABS Homing is complete, proceed with teaching the robot. During teaching operation, any target position that you move the robot to is recorded as a taught point. These taught points will be used in your robot motion program.

To teach the robot, you need to connect the controller and your PC using the LAN cable, and use our dedicated software named TEACHING PENDANT in the web browser.

Before teaching the robot, connect a Jog Stick to the CN2 port on the controller.



Preparing for Teaching

| | | |
|--|--|--|
| | <p>When operating the manipulator for the first time, select the JOINT Coordinate System.</p> <p>Before teaching the robot, be sure that there are no obstacles in the work envelope of the robot. Keep an eye on the manipulator all times while teaching the robot. In the event of emergency, press the emergency stop switch on the Jog stick to stop the manipulator motion.</p> <p>Do not power up the controller without the CN2 connector connected.</p> | |
| | <p>Do not power off the controller while the manipulator is still in motion.</p> | |



Preparing for Teaching

Teaching Procedure

Open the web browser Google Chrome and enable private browsing.
Enter the controller IP address and start up the TEACH window.

Step 1 Open Google Chrome and start a new Incognito window.

(The screenshots are from Google Chrome version 61 or later (64-bit))

Step 2 Connecting the controller and the PC

Connects the LAN cable to Ethernet 0.

Ethernet 0
The lower port:
192.168.0.23 · · ·

Enter the controller IP address.

Controller IP address


http://192.168.0.23

After connecting to the controller, the index window will appear.

(index window)



Click on the Teach main icon to bring up the operation window.

Troubleshooting



System-Defined Errors List


When a system-defined error is detected, its corresponding error code will appear on the 7-segment display panel. Check the detected error type and code in the following list.

| | | | |
|--|--|--|--|
|  (Below) | System-Defined Error Eliminate possible causes, then recover with "Error Reset signal". |  (P29, 30) | Fatal System-Defined Error Eliminate possible causes, then "power cycle" the controller. |
|--|--|--|--|

System-Defined Error

| Error Code | Description |
|------------|---|
| E01 | "init.py" not found |
| E02 | Error in "init.py" |
| E03 | Unable to execute the robot program |
| E04 | Robot program was not set-up |
| E05 | Unable to execute the robot program in the current mode |
| E06 | The robot motion API was used before executing i611 Robot class open() |
| E07 | The robot program was executed during ABS Lost |
| E08 | Robot program aborted |
| E09 | The i611 Robot class open() was executed during E-stop |
| E10 | The i611 Robot class open() was executed during Servo-OFF |
| E11 | The robot program has no permission for operation |
| E12 | Robot program unable to communicate with System Manager |
| E13 | Exception for E-stop was not detected |
| E14 | The exit() method of the robot program ended abnormally |
| E15 | Robot program ended with exception |
| E16 | Exception for deceleration stop was not detected |
| E17 | System end processing was not completed correctly |
| E18 | Unable to access Memory I/O |
| E19 | Multiple instantiations of i611Robot Class in one process |
| E20 | open() i611Robot class was executed more than once in one process |
| E21 | An illegal call for API from another thread occurred |
| E40 | Teaching was aborted |
| E53 | The usage of the home directory (/home/i611usr) folder exceeded the upper limit |
| E99 | Unknown error |

Troubleshooting




System-Defined Errors List






















Fatal System-Defined Error

| Error Code | Description |
|------------|---|
| c01 | System Manager start failed |
| c02 | System Manager ended with fault |
| c03 | System Manager unable to communicate with Control Manger |
| c04 | An error occurred in JOG operation mode |
| c05 | Control Manager was aborted |
| c06 | Memory overflow in the controller |
| c10 | (Joint) Circuit Fault |
| c11 | (Joint) Over current error |
| c12 | (Joint) Brake Fault (Servo OFF → ON) |
| c13 | (Joint) Excessive torque |
| c14 | (Joint) An overload (thermal) error |
| c15 | (Joint) Actuation voltage drop |
| c16 | (Joint) AC power supply error |
| c17 | (Joint) Servo communication error |
| c18 | (Joint) Servo-ON check error 1 (normal operation is not possible) |
| c19 | (Joint) Servo-ON check error 2 (Z-phase cannot be detected) |
| c20 | (Joint) ABS Lost: Speed out of range upon power turning off |
| c21 | (Joint) ABS Lost: Encoder saving error |
| c22 | (Joint) Encoder signal detection abnormal error |
| c23 | (Joint) Encoder Pattern error |
| c24 | (Joint) ABS Lost: Battery of Multi-turn sensor voltage drop error |
| c25 | (Joint) State transition failed |
| c26 | Error at the Tip I/O |
| c28 | Error in internal monitor processing |
| c29 | The cooling fan stopped |
| c30 | Regenerative resistor 1 overheat |
| c31 | Main circuit relay fault |
| c32 | Wiring error of "E-stop circuit" |
| c33 | Wiring error at "Mode circuit" |
| c34 | Error in Control power |

Troubleshooting




System-Defined Errors List

| Error Code | Description |
|---|--|
|  c35 | Inrush current limiting resistor overheat |
|  c36 | Regenerative resistor 2 overheat |
|  c37 | Regenerative resistor 3 overheat |
|  c39 | Robot internal communication was lost |
|  c40 | Redundant signal disagreement occurred in the "Door circuit" |
|  c41 | Redundant signal disagreement occurred in the "Mode circuit" |
|  c42 | Slave error due to a state transition timeout |
|  c43 | Communication error due to an interrupt |
|  c44 | Overspeed error at a slave |
|  c58 | Error in SPI circuit |
|  c59 | The robot definition file was faulty |
|  c60 | Task error |
|  c89 | (Joint) EtherCAT communication error |
|  c91 | (Joint) Position deviation or speed error |
|  c92 | (Joint) Joint parameter error |
|  c93 | (Joint) ABS Lost: Encoder communication error |
|  c94 | (Joint) The control board became overheated |
|  c95 | (Joint) EtherCAT communication synchronization error |
|  c96 | (Joint) Control synchronization error |
|  c98 | Power supply failure |
|  c99 | Unknown error |



Error logs are saved in the controller. You can download the error logs to your PC for further investigation.



Customer service center

ZEUS : 132, Anyeongnam-ro, Hwaseong-si, Gyeonggi-do, South Korea

e-mail : zero@globalzeus.com
